

## **Transmitter Tune-up (Alignment) Procedure**

Note: These procedures are taken from the complete adjustment procedures contained in the Operator's Manual, Section 5. Adjustments not relating to the transmitter have been omitted.

### **5.2 Transmitter Unit**

Note: there are no RF tuning adjustments for the transmitter. It is a broadband circuit.

#### 1. FVR201 alignment

This potentiometer determines the modulation balance. Carefully align this potentiometer to obtain equal deviation on the lowest and the highest RF frequency programmed into the transmitter.

#### 2. FVR202 alignment

This potentiometer determines the low frequency (below 300Hz) deviation. When POCSAG, CTCSS or DCS are used, it is necessary to adjust to have enough deviation at low frequency.

#### 3. FVR203 alignment

This potentiometer sets the maximum deviation, normally set at 5KHz. Programming can set 2KHz or 2.5KHz deviation for narrow spacing.

#### 4. FVR204 alignment

Adjust the transmitter output power to 30 W or less.

#### 5. VCO alignment

The VCO has already been aligned at the factory; however if you need to re-adjust, set the VCO voltage at 10.5V at the highest sub band frequency.

### **5.3 Power Amplifier (PA Unit)**

#### 1. FVR501

Terminate KG506 with 50 ohm load, and adjust this potentiometer for the minimum level of reverse power.

#### 2. FVR502

This potentiometer sets the SWR alarm threshold when the transmitter is terminated with 50 ohms load. Set just slightly past the alarm point.

#### 3. FVR503

Adjust this potentiometer for the low power alarm threshold, usually -3dB. Turn power down to 12.5 watts (using FVR504) and adjust FVR503 for alarm to trigger.

#### 4. FVR504

Adjust for maximum desired power output, but do not exceed 35 W.

### **5.4 Logic Unit**

#### 1. FVR1 adjustment

Not used.

#### 2. FVR2 adjustment

Adjusts the deviation level when the KG506 used as a repeater. Set to 3.5 KHz modulation with receiver modulated at 3.5 KHz .

#### 3. FVR3 adjustment

Adjusts the TX output power (hi power level), usually set to 25 W. Will not exceed level set in Step 5.3.4.

#### 4. FVR4 adjustment

Adjusts Low Power level when program calls for low power. Usually set to 10 to 15 W.