

Index

—A—

Altitude and temperature, 2-8

Antennas

Characteristics, 2-12

Installing, 3-23, 3-24

Overview, 3-23

—C—

Cables

Cable usage table, 3-10

Recommended cables, 3-11

CBS

Cable usage table, 3-10

Characteristics, 2-10

Connecting secondary CBSs, 3-18

Data connectors, 3-13

Installing, 3-5, 3-16

Kit numbers, A-3

LEDs, 3-14

Model number and codes, A-1

Parts order information, A-1

Power connectors, 3-13

Power supply characteristics, 2-11

Recommended cables, 3-11

System cable connections, 3-5, 3-7

Type 1 (lab) installation, 3-18

Chapter summaries, 1-2

Characteristics

Antennas, 2-12

CBS, 2-10

CBS power supply, 2-11

ESLs, 2-13

Customer responsibilities, 2-2

—E—

Electrical requirements, 2-3

Environmental requirements, 2-6

Altitude and temperature, 2-8

Health and safety, 2-9

Temperature and humidity, 2-6

ESL

Characteristics, 2-13

Displays and symbols, 2-15

—G—

Grounding requirements, 2-4

—H—

Hardware installation, 3-1

Health and safety, 2-9

—I—

Installation

Antennas, 3-23

CBS, 3-5

CBS power supply, 3-21

CBS power supply to primary CBS,
3-21

Hardware, 3-1
Recommendations, 3-2
Windows NT software, 4-2

—K—

Kit numbers, A-3

—L—

Licensed Product Identification Numbers
(LPINs)
NCR UNIX, 5-2
Windows NT, 4-2
LPINs
NCR UNIX, 5-2
Windows NT, 4-2

—N—

NCR UNIX
LPINs, 5-2
System environment, 5-1

—P—

Power requirements, 2-3, 2-4

—R—

Reference materials, 1-3

—S—

Site certification tools, 1-3
Site preparation, 2-1
Software
NCR UNIX, 5-2
Windows NT, 4-2
Software installation
Windows NT, 4-2
System environment
NCR UNIX, 5-1
Windows NT, 4-1, 5-1

—T—

Temperature and humidity, 2-6
Tools and supplies, 3-4

—W—

Windows NT
LPINs, 4-2
Software installation, 4-2
System environment, 4-1, 5-1