



Insert Universal Dock Adapters:

Insert the appropriate Universal Dock Adapter for your iPod. The TuneView Dock includes three dock adapters for use with iPod : #3 - iPod mini (4GB or 6GB), #4 - 4G iPod (20GB or U2 Special Ed.), #6 - iPod with color display (20GB, 30GB, or U2 Special Ed.). If you have a 4G iPod (40GB) or an iPod with color display (40GB or 60GB), please purchase the appropriate dock adapter from Apple. If you have a newer iPod (such as a nano 1G, nano 2G, or 5G iPod with video), please use the dock insert that came with your iPod.

Once the dock adapter is installed, connect your iPod to the TuneView Dock.

Step 5 - Check For Communication / Finishing Up

At this point, you will see the Keyspan logo on your iPod's screen, your iPod is now charging and is ready to be used with the TuneView. Proceed to to the **Step 6**.

Troubleshooting Tip:

If you **do not see the Keyspan logo** on your iPod's screen, try disconnecting and reconnecting the iPod from the dock. You can also try removing the universal dock adapter and then connecting the iPod.



TuneView Dock Powered Via Your Computer's USB Port:

If you connected the TuneView Dock to your computer's USB port, your iPod will now sync and charge (ask indicated by the standard **DO NOT DISCONNECT** message on your iPod's screen). If you want to use the TuneView Remote to control your iPod, unmount/eject from your computer. This will give control of the iPod back to the TuneView dock. When you see the Keyspan logo appear on your iPod screen, proceed to to the **Step 6**.

Step 6 - Finishing Up

The TuneView LCD screen will now display the TuneView's Main Menu screen (see image).

Your TuneView for iPod is ready for use!

You can now use the remote to browse your iPod contents. For more details on how to use the the remote and information about its buttons, proceed to the next section, **Using Your TuneView Remote.**



Troubleshooting Tip:

If your TuneView Remote reports **iPod Not Connected**, try disconnecting and reconnecting the iPod from the dock. You can also try removing the universal dock adapter and then connecting the iPod. If the remote reports **iPod Busy**, your iPod is being controlled by another source (ie your computer). If you connected to the TuneView dock to your computer, make sure that you have ejected/unmounted the iPod from your computer. See the **Troubleshooting** section for more details and instructions.

Language Settings:

The TuneView Remote menu system can be displayed in **English** (default setting), **Spanish**, **French**, and **German**. This is set in the **Setup** screen under the the TuneView's Main Menu (navigate to **Main Menu > Setup >**).