

GIANT ELECTRONICS LTD.			
Title: Alignment Procedure			
Model: T7100		Document No.: ENG-T7100-08	Page: 2 / 7
A. PCB LEVEL (Test Condition: under CH14, CH15)			
NO	ITEM	ALIGNMENT METHOD	REMARK
1.	LCD display (Should enter test mode)	1. Press and hold the '+' key and 'Menu' key together. 2. Turn on the radio power until a good key chirp is heard, and the backlight is on for about 500 ms finally, the LCD should be display '1'. 3. Press 'DOWN' key, then all LCD segments should be anticlockwise displayed. 4. Finally, all the LCD segments should be shown for about 500ms as follows: 28⁸⁸ .	
2.	Standby current	1. Set A-METER, and RX mode. 2. Check the standby current <50mA DC for FRS.	
3.	Talk on current	1. Set A-METER, and TX mode @50ohm load. 2. Check the talk on current <550mA DC for FRS 3. Check the talk on current <1300mA DC for GMRS.	
4.	VCO	1. Set TEST mode 2. Check TP01 to provide 0.6 ~ 3.1VDC. 3. Adjust L14 to provide 2.1-3.1VDC at TP01 if VCO level are more than 3.1VDC on TX mode CH14	
5.	TX Power	1. Set TX mode. 2. Check transmit power 32.3~33.6dBm for GMRS. 3. Adjust VR04, check transmit power to provide 25 ~ 28dBm for FRS.	Tx Power Tune-up
6.	CTCSS Tone Frequency	1.Set CH1/CODE1. 2.Set TX mode. 3.Check TP03 to be within 66.8Hz to 67.2Hz.	
7.	TX Frequency	Adjust TC01 to provide 467.7125MHz \pm 50Hz.	
8.	CTCSS Tone Dev.	1. Set CH8/CODE1、AF input level to off, check DEV to be 350Hz~ 600Hz. 2. Set CH8/CODE38、AF input level to off, check DEV to be 350Hz~ 600Hz.	FILTER SET: 1.50HZ~300 HZ 2.750 μ s De-emp ON 3. PK+
9.	TX Modulation & distortion	0.Set CH7/CODE1. 1.Set 100mv AF level at TP08; 1KHz,Adjust VR02 to provide Max TX deviation 2.2KHz to 2.3KHz. 2.Check input Mic level in 10 mV to provide normal deviation 1.3-1.7KHz. 3.Check the demodulation distortion <= 5%. 4. Audio Frequency Response. a) Input a 5.0mV 1KHz audio frequency to TP08 and press 'PTT' switch. b) Check the response compare to 1KHz tone. i) 500Hz : -5.0 dB to -8.0 dB. ii) 2.0KHz : +4.0 dB to +7.0 dB .	FILTER SET: 1.HPF 50Hz 2.LPF 15KHz 3. PK +

THE CONTENT OF THIS DOCUMENT IS GIANT ELCT.LTD. INTELLECTUAL PROPERTY AND IS THE PROPERTY OF GIANT, IT IS TO BE TREATED AS STRICTLY AND IS NOT BE DISCLOSED, REPRODUCED, OR USED EXCEPT AS AUTHORIZED IN WRITING BY GIANT ELECTRONIC LTD. IN CONNECTION WITH THE MANUFACTURE, MAINTENANCE AND USE OF THE GIANT EQUIPMENT WHICH IT PERTAINS. COPYRIGHT @GIANT ELECT. LTD, ALL RIGHTS RESERVED.

GIANT ELECTRONICS LTD.			
Title: Alignment Procedure			
Model: T7100		Document No.: ENG-T7100-08	Page: 3 / 7
A. PCB LEVEL (Test Condition: under CH1)			
NO	ITEM	ALIGNMENT METHOD	REMARK
10.	Rx Audio test	<ol style="list-style-type: none"> 1. Set RX mode CH8. 2. Set SG RF level to -50dBm with 1.5KHz deviation 1KHz modulation Signal. 3. Rotate the volume switch to the position, which give a Max audio output at TP11. 4. Check Max audio output level >1500mV. 5. Check Rx current <180mA. 6. Check the 1KHz distortion <= 3.5%. 7. Set SG RF level to -119dBm with 1.5kHz deviation at 1KHz audio frequency. <ol style="list-style-type: none"> a). Check SINAD sensitivity <= -119dBm. @12dB SINAD at TP11. 8. Audio frequency response. <ol style="list-style-type: none"> a) Set SG RF level to -50dBm with 1.5kHz deviation at 1KHz audio frequency. b) Change SG RF deviation to 1.0kHz Rotate the volume switch to the position, which give an output 100mV± 5mV at TP11. c) Vary the audio frequency from 300Hz to 3KHz. d) Check the RX response compare to 1KHz tone. <ol style="list-style-type: none"> i) 500Hz : +8.0 dB to +14.0 dB. ii) 2.0KHz : -10.0 dB to -16.0 dB. 9. Maximum and Minimum Audio Output Power. <ol style="list-style-type: none"> a) Set SG RF level to -50dBm with 1.5kHz deviation at 1KHz audio frequency. b) Rotate the volume switch to the position, which give a maximum output. c) Check the voltage at TP11 >=1500mV. d) Set maximum audio output to 0dB, rotate the volume switch to the position, which give a minimum output. e) Check the minimum voltage -23dB to -40dB at TP11 	
11.	Noise- Detector	<ol style="list-style-type: none"> 1. Set SG to -120dBm with 1.5KHz deviation, 1KHz AF on CH8. 2. Adjust VR01 for transient state @ 10dB SINAD. 3. Check high state @ 8 to 13dB SINAD. 	
12.	CTCSS tone Detect	<ol style="list-style-type: none"> 1. Set CH1/CODE1 and SG to -122dBm with 67Hz tone frequency, 400Hz deviation. 2. Check the TP04 to below, and high for RF modulation off. 3. Repeat item 1 and 2 for code38 (250.3Hz). 4. Repeat item 1 and 3 for CH22. 	

THE CONTENT OF THIS DOCUMENT IS GIANT ELCT.LTD. INTELLECTUAL PROPERTY AND IS THE PROPERTY OF GIANT, IT IS TO BE TREATED AS STRICTLY AND IS NOT BE DISCLOSED, REPRODUCED, OR USED EXCEPT AS AUTHORIZED IN WRITING BY GIANT ELECTRONIC LTD. IN CONNECTION WITH THE MANUFACTURE, MAINTENANCE AND USE OF THE GIANT EQUIPMENT WHICH IT PERTAINS. COPYRIGHT @GIANT ELECT. LTD, ALL RIGHTS RESERVED.

GIANT ELECTRONICS LTD.			
Title: Alignment Procedure			
Model: T7100		Document No.: ENG-T7100-08	Page: 4 / 7
A. PCB LEVEL (Test Condition: under CH1)			
NO	ITEM	ALIGNMENT METHOD	REMARK
13.	Batter level Detector	Provide DC at TP+. 1. Alkaline battery. 1.1 3 segments; >5.0V. 1.2 2 segments; 4.75-5.0V. 1.3 1 segment; 4.50-4.75V. 1.4 shell; 4.35-4.50V 1.5 shutdown; <4.35V. 2 Rechargeable battery pack. 2.1 3 segments; >5.30V. 2.2 2 segments; 5.05-5.30V. 2.3 1 segment; 4.90-5.05V. 2.4 shell; 4.35-4.90V. 2.5 shutdown; <4.35V.	
14.	VOX Detector	1. Set VOX level at 1. 1.1 Set AF level at 13.2 +/- 0.8 mV, 1KHz at TP08. 1.2 Unit start to transmit. 1.3 Set AF level at 11.0 +/- 0.8mV, 1KHz at TP08. 1.4 Unit stop to transmit. 2. Set VOX level at 2. 2.1 Set AF level at 8.2 +/- 0.7mV, 1KHz at TP08. 2.2 Unit start to transmit. 2.3 Set AF level at 6.2 +/- 0.7mV, 1KHz at TP08. 2.4 Unit stop to transmit. 3. Set VOX level at 3 3.1 Set AF level at 3.2 +/- 0.6mV, 1KHz at TP08. 3.2 Unit start to transmit. 3.3 Set AF level at 2.0 +/- 0.6mV, 1KHz at TP08. 3.4 Unit stop to transmit.	

THE CONTENT OF THIS DOCUMENT IS GIANT ELCT.LTD. INTELLECTUAL PROPERTY AND IS THE PROPERTY OF GIANT, IT IS TO BE TREATED AS STRICTLY AND IS NOT BE DISCLOSED, REPRODUCED, OR USED EXCEPT AS AUTHORIZED IN WRITING BY GIANT ELECTRONIC LTD. IN CONNECTION WITH THE MANUFACTURE, MAINTENANCE AND USE OF THE GIANT EQUIPMENT WHICH IT PERTAINS. COPYRIGHT @GIANT ELECT. LTD, ALL RIGHTS RESERVED.

GIANT ELECTRONICS LTD.			
Title: Alignment Procedure			
Model: T7100		Document No.: ENG-T7100-08	Page: 5 / 7
B. CASING LEVEL			
NO	ITEM	ALIGNMENT METHOD	REMARK
1.	Current Consumption	1. Set A-METER. With volume switch OFF, check the OFF current <10 μ A 2. With volume switch ON, check the standby current <50mA. Press 'PTT' switches and check the TX current <550mA.	
2.	TX Frequency	1. Check CH15=462.5500MHz -/+500Hz; 2. Check CH14 =467.7125MHz -/+500Hz.	
3.	Noise- Detector	1. Set the distance between antennas of SG and checked unit to 0.3M ~ 0.5M. 2. The antennas of SG and checked unit should be parallel to make the electromagnetic field of SG. 3. radiate equally to the antenna of checked unit . 4. Set SG to -90dBm with 1.5KHz deviation, 1KHz tone on CH8. 5. Adjust VR01 for HIGH state : 8 ~ 13 dB SINAD .	When adjusting Noise-Det., Should reduce any interference from other Instruments and body.

THE CONTENT OF THIS DOCUMENT IS GIANT ELCT.LTD. INTELLECTUAL PROPERTY AND IS THE PROPERTY OF GIANT, IT IS TO BE TREATED AS STRICTLY AND IS NOT BE DISCLOSED, REPRODUCED, OR USED EXCEPT AS AUTHORIZED IN WRITING BY GIANT ELECTRONIC LTD. IN CONNECTION WITH THE MANUFACTURE, MAINTENANCE AND USE OF THE GIANT EQUIPMENT WHICH IT PERTAINS. COPYRIGHT @GIANT ELECT. LTD, ALL RIGHTS RESERV

GIANT ELECTRONICS LTD.			
Title: Alignment Procedure			
Model: T7100		Document No.: ENG-T7100-08	Page: 6 / 7
B. CASING LEVEL			
NO	ITEM	ALIGNMENT METHOD	REMARK
4.	Audio RX Path CH8	<ol style="list-style-type: none"> 1. Set SG RF level to -50dBm with 1.5kHz Dev.; 1kHz AF, Rotate the volume switch to the position, which give an Max output. 2. Check speaker O/P level >85dBspL(30cm distance). 3. Set SG RF level to -60dBm with 1.5kHz Dev.; 1kHz AF. 4. Plug the dummy speaker and dummy microphone into audio jet. 5. Rotate the volume switch to the position, which give an output 900+/-50mv. 6. Set SG RF level to -90dBm with 1.5kHz Dev.; 1kHz AF. 7. Check the radiated sensitivity correlate to the golden sample. 8. Audio frequency response. <ol style="list-style-type: none"> a) Set SG RF level to -60dBm with 1.5kHz deviation at 1KHz audio frequency. b) Rotate the volume switch to the position, which give an output 100mV \pm5mV (voltage difference of dummy speaker). c) Vary the audio frequency from 300Hz to 3KHz. d) Check the RX response compare to 1KHz tone. <ol style="list-style-type: none"> i) 500Hz : + 8.0 dB to +14.0 dB. ii) 2.0KHz : -10.0 dB to -16.0dB. 9. Maximum and Minimum Audio Output Power. <ol style="list-style-type: none"> a) Set SG RF level to -60dBm with 1.5kHz deviation at 1KHz audio frequency. b) Rotate the volume switch to the position, which give a maximum output with distortion <5%. c) Check the voltage difference of dummy speaker \geq900mV. d) Set maximum audio output to 0dB, rotate the volume switch to the position, which give a minimum output. e) Check the voltage difference between of dummy speaker -23dB to -40dB. 	
5.	Audio TX Path CH1	<ol style="list-style-type: none"> 1. Check the radiated power correlate to golden sample. 2. Plug the dummy speaker and dummy microphone into audio jet. 3. Standard TX Deviation. <ol style="list-style-type: none"> a) Input mic level to dummy microphone and press 'PTT' switch. b) Check max. Dev. 2.0KHz < max. Dev. < 2.4KHz. c) Check input level in 0.5~15mV to provide normal deviation 1.5KHz. 4. Audio Frequency Response. <ol style="list-style-type: none"> a) Input a 2.0mv@1KHz audio frequency to dummy microphone and press 'PTT' switch. b) Check the response. <ol style="list-style-type: none"> i) 500Hz : -5.0 dB to -8.0 dB. 2.0KHz : +4.0 dB to +7.0 dB 5.Repeat CH14. 	Filter set : 1.HPF 50Hz 2.LPF 15HHz 3. PK +

THE CONTENT OF THIS DOCUMENT IS GIANT ELCT. LTD. INTELLECTUAL PROPERTY AND IS THE PROPERTY OF GIANT, IT IS TO BE TREATED AS STRICTLY AND IS NOT BE DISCLOSED, REPRODUCED, OR USED EXCEPT AS AUTHORIZED IN WRITING BY GIANT ELECTRONIC LTD. IN CONNECTION WITH THE MANUFACTURE, MAINTENANCE AND USE OF THE GIANT WHICH IT PERTAINS. COPYRIGHT @GIANT ELECT LTD. ALL RIGHTS RESERVED.

GIANT ELECTRONICS LTD.			
Title: Alignment Procedure			
Model: T7100		Document No.: ENG-T7100-08	Page: 7 / 7
B. CASING LEVEL			
NO	ITEM	ALIGNMENT METHOD	REMARK
6.	Function check and Intercom function (between sample and production unit)	1. Turn on the radio power, the back-light should be on For a while and a good key chirp should be heard at the same time. 2. The LCD display should be clear, not miss the segment when pressing '+' and '-' or '-' key, the key tone should also be heard clearly. 3. Set channel of the sample and production unit CH=5. 4. Press 'PTT' switch to intercom between sample and Production unit, the LED should be light. 5. The sound quality between both should be clear and no metal sound. 6. Press 'CALL' key, the call tone should be heard clearly each other. 7. Change channel of the production unit to CH=15, then Press 'PTT' switch of sample. 8. Any noise should not be heard from the speaker of Production unit. 9. Press any key, the dead problem should not occur. 10. Set CH1/code5, SG to be CH1/code4 and code6, check the speaker mute. 11. Set CH1/code37, SG to be CH1/code36 and code38, check the speaker mute. 12. Repeat item 10 and 11 for CH22.	

* Remark:

TX mode :

1. Press and hold PTT button

RX mode :

1. Release PTT button

Power supply: Min DC 4.0v; Normal DC5.5v; Max DC6.0v

THE CONTENT OF THIS DOCUMENT IS GIANT ELCT.LTD. INTELLECTUAL PROPERTY AND IS THE PROPERTY OF GIANT, IT IS TO BE TREATED AS STRICTLY AND IS NOT BE DISCLOSED, REPRODUCED, OR USED EXCEPT AS AUTHORIZED IN WRITING BY GIANT ELECTRONIC LTD. IN CONNECTION WITH THE MANUFACTURE, MAINTENANCE AND USE OF THE GIANT EQUIPMENT WHICH IT PERTAINS. COPYRIGHT @GIANT ELECT. LTD, ALL RIGHTS RESERVED