
1. INTRODUCTION

Thank you for your purchase of Skylink® remote transmitter, Model MM-318.

The following items are included in this package:

- One of MM-318 Remote
- Lithium Battery CR-2032 (Installed)
- Mounting accessories
- User's Instructions



Follow one or more instructions below to program transmitter MM-318 to the Skylink® receiver or Skylink® garage door opener you want to control.

2. PROGRAMMING


2a. PROGRAMMING A REMOTE TRANSMITTER TO THE SKYLINK® GARAGE DOOR OPENER – ATOMS™ SERIES

Connect the opener to an approved power source. The dot in the LED display stays on.	
2. Press the [Set] button for one second, and release the button until the LED Display shows the letter "P".	Learn wireless control
Within 30 seconds, press any button on the remote that you would like to program to the opener.	Button [1] Button [2]
Note: [•] = Button 1, [• •] = Button 2, [• • •] = Button 3	Button [3]
Once the button on the remote is programmed. The LED segment will off and emits one beep indicating the programming successfully	8

2b. PROGRAMMING A REMOTE TRANSMITTER TO THE SKYLINK® RECEIVER - GB-318

Refer to the receiver Smart Button[™] GB-318 user's instruction to set up the unit.

- 1. Press the learn button on the side of the Smart Button[™] GB-318.
- 2. Once the learn button is pressed, the LED will flash quickly. Release the learn button.
- 3. Within 30 seconds, press any one of the 3 buttons on the transmitter that you want to program to the receiver.
- 4. Once the remote control is programmed, the LED will flash slowly, in the same way as it flashes in standby mode.
- 5. You may now operate the garage door opener with this new remote control.
- 6. To program this transmitter to control another receiver, repeat process (1) to (4) to program another button on the remote transmitter.



3. OPERATION


Press the programmed button to open/close the garage door or receiver.

4. BATTERY REPLACEMENT

The remote come with a 3 Volt lithium battery (CR 2032) installed. It is time to change the battery when the red LED on the transmitter does not turn on when either button is pressed.

To replace the battery:

- 1. Undo the screw on the back of the remote.
- 2. Pry out the back cover from the remote
- 3. Take out the old battery.
- 4. Place the new battery in position. Be sure the polarity is correct.
- 5. Close the back cover with the screw.





▲ Battery Disposal - Dispose used battery according to local regulation.

5 WARNING

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- 1) this device may not cause harmful interference, and
- 2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme aux CNR exempts de licence d'Industrie Canada. Le fonctionnement est soumis aux deux conditions suivantes:

- (1) Ce dispositif ne peut causer des interférences; et
- (2) Cet appareil doit accepter toute interférence, y compris les interférences qui peuvent causer un mauvais fonctionnement de l'appareil.

6. WARRANTY

If, within one year from date of purchase, this product should become defective (except battery), due to faulty workmanship or materials, it will be repaired or replaced, without charge. Proof of purchase and a Return Authorization are required.

7. CUSTOMER SERVICE

If you would like to

- find out the up-to-date specifications
- know more about features and applications
- download documents, i.e. user's instructions
- order Skylink products

or if you have difficulty getting products to work, please:

- 1. visit our FAQ section at www.skylinkhome.com, or
- 2. email us at support@skylinkhome.com, or
- 3. call our toll free at 1-800-304-1187 from Monday to Friday, 9 am to 5 pm EST. Fax (800) 286-1320

CUSTOMER SERVICE

17 Sheard Avenue, Brampton, Ontario, Canada L6Y 1J3 Email:support@skylinkhome.com http://www.skylinkhome.com ©2016 SKYLINK GROUP