

## INSTALLATION INSTRUCTIONS

### Wireless Garage Door Sensor

Model : GS-MT2



Congratulations on your purchase of the Skylink Wireless Garage Door Sensor model GS-MT2. The sensor is designed to monitor the status of your garage door and work with the Skylink M series Receiver. You will find the installation to be simple and be able to get the system up and running with little effort.

### ONE YEAR WARRANTY

This product is guaranteed to be free of defects in materials and workmanship for 1 year from the date of purchase. If this product is defective, call 1-800-304-1187 for repair or replacement parts. Guarantee does not include normal wear and tear or batteries.



If you have any questions, problems or missing parts, please call Skylink Customer Support: 9:00am – 5:00pm EST, Monday-Friday.

**1-800-304-1187**

Or e-mail us at [support@skylinkhome.com](mailto:support@skylinkhome.com)  
[www.skylinkhome.com](http://www.skylinkhome.com)

P/N:101Yxxx Rev0

GS-MT2 Series

### SAFETY INFORMATION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

#### WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme aux CNR exempts de licence d'Industrie Canada. Le fonctionnement est soumis aux deux conditions suivantes:

(1) Cet dispositif ne peut causer des interférences; et

(2) Cet appareil doit accepter toute interférence, y compris les interférences qui peuvent causer un mauvais fonctionnement de l'appareil.

### CE

Declaration of Conformity

This equipment complies with the requirements relating to electromagnetic compatibility, EN 301489-1, EN301489-3, EN300220-1, EN300220-2 and EN60950-1. This equipment conforms to the essential requirement of the 1999/5/EC R&TTE Directive.



### Package Contents



Parts	Description	Quantity
A	Garage Door Sensor	1
B	Mounting Accessories	1

## Section 1- Programming the Sensor

**Note:** Battery for the sensor is not included.

**Note:** Each zone can program up to 4 sensors. If you try to program a fifth sensor into a zone, the first programmed sensor will be erased.

The sensor must be programmed to the Control Panel before they can communication. You may program the sensor to one of the 4 zones in the Control Panel. Follow the steps below to program a sensor to a specific zone;

1. Insert one AA type battery (optional) to the Sensor based on the polarity specified in the Sensor.
2. Refer the details of the user's instructions to power up the Control Panel.
3. Press and hold the Learn Button on the Control Panel for 5 seconds until the zone 1 red LED stays on. You may release the Learn Button.
4. If you would like to program the sensor to zone 1, activate the sensor while the zone 1 red LED is flashing. Tilt the sensor from vertical to horizontal to activate it.
5. If you would like to program the sensor to other zones, press the Learn Button again, until the red LED flashes at the zone you want to program the sensor to, then activate the sensor.
6. Once the sensor is programmed, the corresponding zone red LED will be off.




## Section 2 – Installation of the Sensor

**WARNING :** Unplug the power cord of your garage door opener before installation to ensure power is not connected.

**Note:** Ensure the mounting surface is smooth and clean.

1. Mount the sensor near the top panel of your garage door or the appropriate location by either double sided tape or screws.


**Note:** Screw the mounting plate to the frame or the panel of the garage door if the mounting surface is not flat enough. Then apply the double sided tape.



### Section 3- Operation of the Sensor

The sensor is used to monitor the status of your garage door. Once detect the door is open, the sensor will transmit signal to the Control Panel to notify the user.

1. The sensor will transmit the signal to the Control Panel when detect the door is open, the Control Panel will beep / alarm and the corresponding zone LED will flash.



### Section 4- Sensor Failure / Low Battery Indication

**Note:** The corresponding zone LED in the Control Panel will flash if the sensor failure or low battery is occurred.

When the sensor failure occurs, try the following:

1. Check if the sensor is located at where it should be.
2. Check if there is any physical damage to the sensor.
3. Move the Control Panel closer to the sensor, if the red LED stops flashing, that means the Control Panel or sensor needs to be relocated.
4. Replace the battery of the sensor if the Control Panel does not respond when the sensor is activated within short range.

**Note:** Risk of explosion if battery is replaced by an incorrect type. Dispose used batteries according to local authority.

### Section 5- FAQ

Q: The control panel does not respond to the sensor.

A: You must program the sensor to the control panel before they can work together.

Q: Can I erase just one sensor from a zone?

A: You must erase all the sensors in that zone and then program the sensor you want to keep.

Q: I have multiple sensors in a zone and the zone LED keep flashing that is a sensor failure or low battery, how do I know which sensor is having the problem?

A: You need to test each sensor individually.

## INSTALLATION INSTRUCTIONS

### Wireless Door/Window Sensor

Model : WD-MT2



Congratulations on your purchase of the Skylink Wireless Door/Window Sensor model WD-MT2. The sensor is designed to monitor the status of your windows or door and work with the Skylink M series Receiver. You will find the installation to be simple and be able to get the system up and running with little effort.

### ONE YEAR WARRANTY

This product is guaranteed to be free of defects in materials and workmanship for 1 year from the date of purchase. If this product is defective, call 1-800-304-1187 for repair or replacement parts. Guarantee does not include normal wear and tear or batteries.



If you have any questions, problems or missing parts, please call Skylink Customer Support: 9:00am – 5:00pm EST, Monday-Friday.

**1-800-304-1187**

Or e-mail us at [support@skylinkhome.com](mailto:support@skylinkhome.com)  
www.skylinkhome.com

P/N:101Yxxx Rev0

WD-MT2 Series

### SAFETY INFORMATION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

#### WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme aux CNR exempts de licence d'Industrie Canada. Le fonctionnement est soumis aux deux conditions suivantes:

(1) Cet dispositif ne peut causer des interférences; et

(2) Cet appareil doit accepter toute interférence, y compris les interférences qui peuvent causer un mauvais fonctionnement de l'appareil.

### CE

Declaration of Conformity

This equipment complies with the requirements relating to electromagnetic compatibility, EN 301489-1, EN301489-3, EN300220-1, EN300220-2 and EN60950-1. This equipment conforms to the essential requirement of the 1999/5/EC R&TTE Directive.

### Package Contents



Parts	Description	Quantity
A	Door/Window Sensor	1
B	Mounting Accessories	1

## Section 1- Programming the Sensor

**Note:** Battery for the sensor is not included.

**Note:** Each zone can program up to 4 sensors. If you try to program a fifth sensor into a zone, the first programmed sensor will be erased.

The sensor must be programmed to the Control Panel before they can communication. You may program the sensor to one of the 4 zones in the Control Panel. Follow the steps below to program a sensor to a specific zone;


1. Insert one AA type battery (optional) to the Sensor based on the polarity specified in the Sensor.
2. Refer the details of the user's instructions to power up the Control Panel.
3. Press and hold the Learn Button on the Control Panel for 5 seconds until the zone 1 red LED stays on. You may release the Learn Button.
4. If you would like to program the sensor to zone 1, activate the sensor while the zone 1 red LED is flashing. Tilt the sensor from vertical to horizontal to activate it.
5. If you would like to program the sensor to other zones, press the Learn Button again, until the red LED flashes at the zone you want to program the sensor to, then activate the sensor.
6. Once the sensor is programmed, the corresponding zone red LED will be off.



## Section 2 – Installation of the Sensor

**Note:** Ensure the mounting surface is smooth and clean.

1. Place the sensor in the appropriate location: i.e. Window or Door. Mount the Door/Window sensor on your window or door with the provide screws or double sided tape.




**Note:** Screw the mounting plate to the frame or the panel of the window or door if the mounting surface is not flat enough. Then apply the double sided tape.

### Section 3- Operation of the Sensor

The sensor is used to monitor the status of your window or door. Once detect the window or door is open, the sensor will transmit signal to the Control Panel to notify the user.

1. The sensor will transmit the signal to the Control Panel when detect the door is open, the Control Panel will beep / alarm and the corresponding zone LED will flash.



### Section 4- Sensor Failure / Low Battery Indication

**Note:** The corresponding zone LED in the Control Panel will flash if the sensor failure or low battery is occurred.

When the sensor failure occurs, try the following:

1. Check if the sensor is located at where it should be.
2. Check if there is any physical damage to the sensor.
3. Move the Control Panel closer to the sensor, if the red LED stops flashing, that means the Control Panel or sensor needs to be relocated.
4. Replace the battery of the sensor if the Control Panel does not respond when the sensor is activated within short range.

**Note:** Risk of explosion if battery is replaced by an incorrect type. Dispose used batteries according to local authority.

### Section 5- FAQ

Q: The control panel does not respond to the sensor.

A: You must program the sensor to the control panel before they can work together.

Q: Can I erase just one sensor from a zone?

A: You must erase all the sensors in that zone and then program the sensor you want to keep.

Q: I have multiple sensors in a zone and the zone LED keep flashing that is a sensor failure or low battery, how do I know which sensor is having the problem?

A: You need to test each sensor individually.