

## LITHIUM POLYMER BATTERY SAFE USAGE

This device is equipped with a lithium polymer (LiPo) rechargeable battery that is non-replaceable. Please pay attention to the following cautions for safe use:

- Before recharging, allow the battery to cool for at least 10 minutes after use.
- Do not dispose of the battery in fire or extreme heat.
- Do not use or leave the battery near a heat source such as a fire or a heater.
- Do not strike or throw the battery against hard surfaces.
- Do not immerse the battery in water.
- Keep the battery in a cool, dry place.
- When recharging, only use the Micro-USB Cable specifically included for that purpose.
- Do not over-charge the battery.
- Do not directly solder the battery and pierce the battery with a nail or other sharp object.
- Do not disassemble or alter the battery.
- Charge the battery as necessary. Failure to charge the battery frequently may result in a battery that will no longer accept a charge.
- Do not transport or store the battery with metal objects such as necklaces, hairpins, etc.
- Please recycle a used battery after covering the battery wires/terminals with electrical tape or by inserting it into an individual poly bag. Check local laws and regulations for recycling and/or disposal information.
- Under the environment with electrostatic discharge, the product may malfunction and require the user to reset the product by turning it off and back on again.
- Rechargeable batteries are only to be charged by an adult.
- Adult shall regularly examine for damage to the cord, plug, enclosure and other parts, and that, in the event of such damage, the toy must not be used with this transformer until the damage has been repaired.
- This toy contains battery that is non-replaceable.
- Use only with charger input: 5V DC, current: 1000mA, output: 3.7V DC, 300mA

## FCC COMPLIANCE

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- Caution: Modifications not authorized by the manufacturer may void users authority to operate this device.
- CAN ICES-3 (B)/NMB-3(B).  
Frequency band: 2402-2480MHz  
Max. transmit power: 4.8 dBm

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.



'Let's care for the environment!'  
The wheelie bin symbol indicates that the product must not be disposed of with other household waste. Please use designated collection points or recycling facilities when disposing of the item. Do not treat old batteries as household waste. Take them to a designated recycling facility.

Please keep this manual as it contains important information.



0920-0-C  
Printed in China

www.LOLsurprise.com  
©2020 MGA Entertainment, Inc.  
L.O.L. SURPRISE!™ and L.O.L. SURPRISE! REMIX™ are trademarks of MGA in the U.S. and other countries. All logos, names, characters, likenesses, images, slogans, and packaging appearance are the property of MGA.

**Little Tikes Consumer Service**  
2180 Barlow Road Hudson, Ohio  
44236 U.S.A.  
1-800-321-0183



www.littletikes.com

ENG





# 16" BIKE

4+

SKU: 655425C  
ADULT ASSEMBLY REQUIRED  
ADULT SUPERVISION REQUIRED

## USER GUIDE

Before assembling, be sure you have all parts and hardware.



Illustrations are for reference only. Styles may vary from actual contents.  
Please remove all packaging including tags, ties & tacking stitches before giving this product to a child.

### IMPORTANT

- Read entire instructions carefully before assembling and riding this product.
- Keep these instructions for future reference.
- To prevent serious injury, children must not use the equipment until completely assembled.
- It is the responsibility of the parent to verify the bike has been properly assembled, and the child is properly trained and instructed in use of the bike before riding.
- This product is intended for outdoor domestic family use only.
- Periodically check that all fasteners and components are securely tightened.
- Do not attempt to modify or repair this product. For help contact Little Tikes Consumer Service.

**⚠ WARNING:** Adult assembly required. Choking hazard to children under 3 years – contains small parts prior to assembly.

**⚠ WARNING: TO AVOID SERIOUS INJURY OR DEATH:**

- Failure to properly assemble and maintain your bike could result in serious injury or death.
- Always wear a properly fitted helmet when riding this bike.
- Do not ride at night or in the dark.
- Do not ride in wet conditions.

# SAFETY WARNINGS

## ⚠️ WARNING:

**READ AND FOLLOW ALL INSTRUCTIONS TO ENSURE A SAFE RIDE.** Failure to read and understand all information in this manual increases risk of injury due to falls or other incidents. Riding a bike takes skill and must be learned under adult supervision. By riding this bike, users risk serious injury or death from collisions, falls or loss of control.

**PARENTS:** For your child's safety, it is your responsibility to ensure your child fully understands all warnings, cautions and instructions in this manual prior to riding the bike. Parental supervision is required at all times while your child is riding the bike. This unit is not a toy. Periodically review the information in this manual with young riders. Before each use, inspect the bike for any damage, and do not allow children to ride the bike if it is broken or damaged in any way. Properly maintain the bike in accordance with the instructions. Do not make modifications to the bike.

## RIDER'S RESPONSIBILITY

## ⚠️ WARNING:


**NOT FOR USERS UNDER THE AGE OF 4. NOT FOR CHILDREN WITH A BODY MASS OF MORE THAN 45 KG. DO NOT EXCEED THE WEIGHT LIMIT OF 45 KG (99 LBS)** - including backpacks and other heavy items when riding. Exceeding the weight limit could injure the rider and damage the unit. Keep this product away from children under the age of 4 and remember that this product is only intended for use by persons who are, at minimum, comfortable and competent while riding the unit.

- Check and understand the laws of bicycle usage in your area before riding.
- Before each ride, check that all bolts are secure and no components of the unit are broken.
- Periodically review this information and make sure that you and the rider understand all safety warnings and instructions.
- Do not let others ride until they have read this entire manual.
- Only one rider is permitted at a time.
- There are many different types of bicycles and each are designed for different uses. Make sure you know the type of bike you have purchased and do not exceed its service limitations.
- Be sure to check and fully understand the bicycle classifications set forth, including size of the unit that is proper for the rider to insure good control when riding.

**CHILDREN'S BIKES:** These bikes are intended for use by children in safe areas with riding surfaces that are in good condition and free of traffic. Children must always ride within their abilities under parental supervision and should wear a safety helmet and other safety gear at all times.

**WARNING:** AS WITH ALL MECHANICAL COMPONENTS, THE BICYCLE IS SUBJECTED TO WEAR AND HIGH STRESSES. DIFFERENT MATERIALS AND COMPONENTS MAY REACT TO WEAR OR STRESS FATIGUES IN DIFFERENT WAYS. IF THE DESIGN LIFE OF A COMPONENT HAS BEEN EXCEEDED, IT MAY SUDDENLY FAIL, POSSIBLY CAUSING INJURIES TO THE RIDER. ANY FORM OF CRACK, SCRATCHES OR CHANGE OF COLORING IN HIGHLY STRESSED AREAS INDICATE THAT THE LIFE OF THE COMPONENT HAS BEEN REACHED AND SHOULD BE REPLACED.

**CAUTION:** ALWAYS WEAR A PROPERLY FITTED HELMET WHEN YOU RIDE YOUR BICYCLE. DO NOT RIDE AT NIGHT. AVOID RIDING IN WET CONDITIONS.




## ⚠️ WARNING:

**READ AND FOLLOW THESE RULES OF THE ROAD** In the interest of safe cycling, make sure you read and understand the owner's manual. In this manual you will find **DANGER, WARNING, CAUTION, IMPORTANT** or **NOTICE**. These are important signal words telling you to pay special attention to that text as rider safety is involved. **DANGER** and **WARNING:** Pay special attention to these since failure to do so could result in injury or death to the rider or others. **CAUTION:** If not followed, these instructions could result in injury, or mechanical failure or damage to the bicycle. **NOTE** or **NOTICE** or **IMPORTANT:** These specify something that is of special interest. **CAUTION** Before you ride the bicycle, check the brake and other parts of the bike. Make sure all parts are tightened, assembled correctly and working properly.

# PAIRING SPEAKER

- 1 TURN ON:** Press and hold the power button to turn on the speaker. The indicator light will flash in blue.
- 2 CONNECTING TO DEVICE:**
  1. Turn on your device (not included).
  2. Open the settings menu on your device.
  3. Select wireless connectivity and make sure it is on.
  4. Your device will search for the speaker.
  5. Select the device name "Soundtrack Speaker" to connect to your device.
  6. The blue light will stay on once it is activated and it will flash while it is playing the music.




**DISCONNECTING THE SPEAKER:** There are two ways to disconnect the speaker.

1. Press and hold the play/pause.
2. In the settings on your device, select the device name and disconnect the speaker.

### IMPORTANT INFORMATION:

Not all devices are compatible with the speaker. Your device must have wireless connectivity capabilities.

# WIRELESS SPEAKER




## SPEAKER GUIDE:

Before using, fully charge the speaker and pair it with your device.


- Press and hold the power button (⏻) to turn the speaker on or off. (Always turn the speaker off when not in use to conserve battery power.)
- Press the play/pause button (▶||) once to pause or play music. (Note: Holding the button will disconnect the speaker from your device.)
- Press and hold the volume (+) button to increase the volume. Pressing it once will skip to the next song.
- Press and hold the volume (-) button to decrease the volume. Pressing it once after the song has started playing will reset the song. To go back to the previous song, press it as soon as the song starts playing.

## ANSWERING/ENDING CALLS:

When receiving calls, press the play/pause (▶||) button once to answer or end calls.



The tires will come inflated and should feel firm. If it needs to be inflated, remove the screw on the valve and use a bicycle pump with the correct pump head (not included) to inflate the tires.  
**Do not over-inflate.** Regularly check tires and inflate if necessary.



Place the speaker into the mount. The holder on top of the speaker should be inserted onto the hook on the mount.

# SAFETY WARNINGS

Take your first ride in a large, open, level area. If you have a problem, check the assembly instructions and follow the maintenance procedures in this manual. If you do not feel comfortable with your skills in assembling or adjusting the bike, please take it to a professional bike repairman.

- Adult Supervision Required.
- Protective equipment should be worn.
- Not to be used in traffic.
- Not intended for use on public roads.

## WARNING:

1. The condition of the riding surface is very important. If the surface is wet, or has sand, leaves, small rocks or other loose debris on the surface where you plan to ride, carefully decrease the speed of the bicycle and ride with extra caution. It will also take a longer time and more distance to stop. Apply the brake earlier than normal and with less force, rear brake followed by the front brake, if equipped, to help keep the bicycle from sliding or falling.
2. Also wear shoes when riding a bicycle and avoid loose fitting clothes. Long sleeves, long pants, gloves, eye protection, a good helmet, elbow and knee pads are recommended. Helmet use is required by law in many states and is always a good idea.
3. **CAUTION: WET WEATHER WARNING:** Check your brakes frequently. The ability to stop is critical. Pavement can be slippery in wet weather so avoid sharp turns and allow more distance for stopping. Brakes may become less efficient when wet. Leaves, loose gravel and other debris on the road can also affect stopping distance. **DO NOT RIDE IN WET CONDITIONS.** Vision and control are impaired, creating a greater risk of accidents and injury.
4. **CAUTION:** A bicycle rider's best defense against accidents is to be alert to road conditions and traffic in the area. Do not wear anything that restricts your vision or your hearing. Ride at a safe speed. Watch for cars.
5. When riding, ALWAYS WEAR A CPSC APPROVED BIKE HELMET.

6. Never carry passengers or packages. This is dangerous and it makes the bicycle harder to control.
7. Always be alert. Animals or people may dart in front of you. Give pedestrians the right-of-way. Don't ride too close to pedestrians, and don't park your bicycle where it can get in the way of foot or vehicle traffic.
8. Never stunt ride or jump on your bike. Avoid head-on impacts with curbs and other fixed objects.
9. Do not ride your bicycle if the chain cover is not attached, or if any of the bicycle's mechanical systems are not functioning properly.
10. If any components become loose while riding, STOP!! Immediately and tighten or bring to a mechanic for repair.

## BEFORE RIDING:

Your new bike was assembled and tuned in the factory and then partially disassembled for shipping. The following instructions will enable you to prepare your bicycle for years of enjoyable cycling. For more details on inspection, maintenance and adjustment of any parts of the bicycle, please refer to the relevant sections in this manual. **If you have questions about your ability to properly assemble this bicycle, please consult a professional bicycle mechanic before riding.**


## WARNING:

**TO AVOID INJURY, THIS PRODUCT MUST BE PROPERLY ASSEMBLED BEFORE USE. WE STRONGLY RECOMMEND THAT YOU REVIEW THE COMPLETE ASSEMBLY GUIDE AND PERFORM CHECKS SPECIFIED IN THE OWNER'S MANUAL BEFORE RIDING.**

## NECESSARY TOOLS:

- 5mm Allen wrench (included)
- Wrench (included)
  - 13mm
  - 15mm

## ADJUST SEAT AND HANDLEBAR



**CORRECT PLACEMENT**  
 The seat's post has a mark to indicate the minimum it should go into the frame.

To adjust the seat, open the clamp under the seat and slide the seat up or down.



Close the clamp to secure the seat. If the clamp feels too tight, turn the knob on the other side to loosen the clamp. Tighten the knob after closing the clamp.




To adjust the handlebar, remove the four Allen bolts using the included Allen wrench.



Move the handlebar down or up so the child can reach the handles. Then, replace the bolts and tighten.

## CHARGING SPEAKER

Before using fully charge the speaker. Here's how:  
 1. Plug the Micro-USB cable into the USB port on your computer (not included) or a 5V DC adapter (not included). Do not use an adapter with a voltage higher than 5V.  
 2. Open the flap on the bottom of the speaker and plug the other end of the cable into the speaker.  
 3. The indicator light on the speaker will turn red. The light will turn off when it is fully charged.  
 Charging takes approximately 2 hours. A fully charged speaker will last approximately 2-4 hours. To conserve battery power, the speaker will turn off after 10 minutes of inactivity.



# SAFETY WARNINGS

## BEFORE EVERY RIDE:

**Just a minute** spent before each ride can significantly improve your safety and the enjoyment of your ride. So, each time before you ride, make a habit of performing the following safety checks.

- Stand in front of the bicycle facing rearward and hold the front wheel securely between your legs. Try to twist the handlebars and verify that they do not move. Then pull the handlebars up, trying to lift the bike. There should be no movement of these components.
- Try to push the front wheel from side to side in the fork and confirm that it feels right and will not wobble. Lift the front wheel up by the handlebars and strike the wheel downward with the heel of your hand and confirm that it is tight. Spin the front wheel and confirm that it does not wobble or contact the fork or brake pads.
- Try to lift, push down on and twist the seat to confirm that it is tight.
- Look at the connections of the pedal to the crank arm. The pedal should feel firm.
- Apply your brake(s) and make sure that they feel firm to the touch, and then spin the wheel(s). Apply the brakes. They should stop the wheel(s).

Now, put on your bicycle safety helmet and enjoy your ride. Your safety is well worth **just a minute**. Also, be sure to read and follow the warnings and instructions in the Assembly, Maintenance and other sections of this manual.

## MAINTENANCE

Regularly examine all parts for wear or damage before use.

- Before each ride, check for cracks or other damage to the bike.
- Check tires and all hardware such as bolts, nuts, cables, fasteners and other parts to ensure they are secure and properly assembled. If you hear any rattling from loose parts, the unit is damaged and should not be used.
- Immediately replace any damaged, missing, or badly worn parts with original equipment.
- Only use parts and accessories approved by the manufacturer and included with the product at the point of sale. Other accessories are not approved for use with the bike and could damage the unit or cause injury to the rider.
- Tires wear down over time and can be pierced by sharp objects or rough surfaces. The back tire is subject to wear and tear due to braking. Regularly inspect the tires and replace with tires approved by the manufacturer.
- Under-inflated tires will cause wear. If needed, use a bike pump (not included) to inflate the tires. The maximum tire pressure is 35 psi. Tires should feel firm. DO NOT over-inflate, as it will cause the tires to rupture.
- Wipe the unit clean with a damp cloth. Do not use harsh chemicals or abrasive cleaning materials to prevent damaging the paint and decals.

## MAINTENANCE CHECKLIST

### Before every ride:

- Check wheel and pedal tightness.
- Check brake operation.
- Make sure all fasteners are tightened.

### After every ride:

- Quick wipe down with damp cloth.

### Monthly:

- Check brake adjustment (if applicable).
- Check tire wear.
- Check that wheels are true.
- Check hub, head set and crank bearings for looseness.
- Check pedals and handlebars are tight.
- Check seat and seat post are tight and comfortably adjusted.
- Check frame and fork are true.
- Check all nuts and bolts are tight.

## COASTER BRAKE

It is not necessary to assemble any part of your coaster brake, but it is important to understand how your coaster brake works.

### OPERATION:


Push the pedals backward to move the chain backward. The chain activates the coaster mechanism that is inside the rear hub. As you push the pedals backward with increasing force, the braking action of the coaster increases.

If your bicycle has a caliper brake(s) in addition to the coaster brake, always use the coaster brake as the main brake to stop the bike.

## FITTING THE RIDER TO THE BICYCLE



To determine the correct size of bicycle for the rider:

- Straddle the assembled bike with feet shoulder width apart and flat on the ground.
- There must be at least 1 inch (2.5 cm) of clearance (1) between the highest part of the top tube (2) and the crotch of the rider with tires properly inflated.
- The minimum leg-length for the rider is the highest part of the top tube plus one inch (3).




# ASSEMBLY


Before beginning, remove the protectors on the bike and handlebar.



Slide the handlebar's (B) pole into the bike (A).




Tighten the bolt on the handlebar using the 13mm side of the included tool.




Locate the left pedal (C). It will have the letter "L" engraved on it. Screw in the left pedal to the left side of the bike and tighten it with the 15mm side of the tool.

NOTE: When screwing the left pedal, turn to the left to tighten.




Screw in the right pedal (D) to the right side of the bike and tighten it with the 15mm side of the tool. Right pedal will have "R" engraved on it.

NOTE: When screwing the right pedal, turn to the right to tighten.



Using the 15mm side of the tool, turn the bolt (3) to the left and remove. Then, remove the washer (2). **Do not remove the plate (1).** Repeat on the other side.



Place the training wheel. Then, insert the washer and bolt. Tighten the bolt using the 15mm side of the tool. Repeat on the other side.