

LT328A (NOV 98)

TA990009-0451



Sprint PCS™

Personal Communication Services

User Guide



Sprint PCS
touchpoint™
The phone with the mouse™

Sprint PCS[®]

The clear alternative to cellular.SM



Sprint PCS[®]

Welcome to Sprint PCS

Only Sprint PCS built an all-digital, nationwide network from the ground up, for a new level of clarity. We've built our network to give you what we believe you really want from a wireless phone: clear sound, private conversations and time saving features. But Sprint Personal Communication ServicesSM also has the potential to do something even more far-reaching – simplify your life. Our advanced technology is designed to grow with your communications needs so that one day, you will be able to rely entirely on your phone to stay connected.

This guide will introduce you to our technology and our new phone through easy-to-follow instructions. For additional help, just stop by any Sprint PCS Center or call Sprint PCS Customer Care by dialing *** 2 OK** (in southern California dial *** 6 1 1 OK**) or by calling 1-888-211-4PCS (4727) (in southern California call 1-800-455-4551).

Thanks for choosing Sprint PCS.

This phone will work only with service from Sprint PCS which must be purchased separately. See Terms and Conditions of Service. Use only Sprint PCS-approved accessories with your Sprint PCS Phone.

© 1998 Sprint Spectrum L.P. All rights reserved. No reproduction in whole or in part without prior written approval. Sprint and the diamond logo are registered trademarks of Sprint Communications Company L.P., Sprint PCS and Sprint Personal Communication Services are trademarks of Sprint Communications Company L.P., used under license. Sprint PCS is a service mark of Sprint Communications Company L.P., used under license.

Printed in USA.

First things first: Read this before you do anything else

Determine if your phone is pre-activated

If you received your phone in the mail or purchased it at a Sprint PCS Center, your phone may already be activated. If so, it simply needs to be unlocked before you can begin using it. (See “How To Unlock Your Phone” on the next page.)

Activate your phone

There are two ways to activate your phone.

1. The fastest way is to call from your new Sprint PCS Phone:
 - Dial *** 2 OK** while in a Sprint PCS Service Area. You will be connected to a Sprint PCS Customer Care Advocate who will guide you through the activation process. In southern California, dial *** 6 1 1 OK**.
2. Another option is to call Sprint PCS Customer Care from any phone other than your new Sprint PCS Phone.
 - Call us toll-free at 1-888-715-4588 (In southern California, call 1-888-PCS-6699).

What you should know before you call

The call typically takes about 30 minutes, but may take longer at peak times.

Your Sprint PCS Touchpoint™ phone will be ready for use about one hour after this call is finished.

What you should have handy

- ▶ Your new Sprint PCS Touchpoint™ phone
- ▶ The original packaging for your new phone
- ▶ Your billing address
- ▶ Your social security number or tax ID number
- ▶ Your driver's license number
- ▶ Pen and paper to write down your new Sprint PCS Phone Number

During this call, a Sprint PCS Customer Care Advocate will collect your information as well as help you select your Sprint PCS Service Plan.

Once you've made all your selections, they'll guide you through the activation process.

How to unlock your phone

If you received your Sprint PCS Touchpoint™ phone in the mail or if a Sprint PCS Representative activated your phone when you purchased it, you need to unlock your phone before you can begin making calls. Simply follow these steps:

1. Find the On/Off switch near the antenna, on top of the phone.
Turn the phone on.
2. Highlight **Unlock** and press **OK**.
3. Enter the four-digit lock code you selected when you placed your order. For safety purposes, your code will not be visible as you type. (If you can't recall your code, try using the last four digits of your Sprint PCS Phone Number or the last four digits of your social security number or tax ID number. If that doesn't work, take your phone to the nearest Sprint PCS Center for assistance.)

How to get help

If you need assistance at any time, call Sprint PCS Customer Care at 1-888-211-4PCS (4727). In southern California, call 1-800-455-4551. You can also dial ***** **2** **OK** from your activated Sprint PCS Touchpoint™ phone (in southern California, dial ***** **6** **1** **1** **OK**). A Sprint PCS Customer Care Advocate will answer 24 hours a day and will be happy to assist you.

One more important detail: Our services are provided to you under certain terms and conditions – all of which are listed in the brochure included in the box in which your Sprint PCS Touchpoint™ phone came.

Table of Contents

Welcome to Sprint PCS i

First things first:

Read this before you do anything else ii

Determine if your phone is pre-activated	ii
Activate your phone	ii
What you should know before you call	iii
What you should have handy	iii
How to unlock your phone	iii
How to get help	iv

Getting to know your phone 1

Highlights	1
Easy Menu Navigation Control	1
Alpha Entry Using Keypad	2
Front View of Phone	4
Display Icons	6
Incoming Call Notification	6
Antenna	7
Keeping Tabs On Signal Strength	7
Battery	8
Installing the Battery	8
Charging the Battery	8
Using the AC Adapter	9

Using Your Phone:

Basic operations to place and receive calls 10

Turning Your Phone On and Off	10
Power Save Mode	10
Standby Display	11
Placing a Call	11
Correcting Dialing Mistakes	11
Answering Calls	12

User Options During a Call (In-call state/status)	12
Mute	12
Redialing Last Outgoing Number	13
Dialing Sprint PCS Directory Assistance	13
Dialing Sprint PCS Operator Services	13
Dialing Sprint PCS Customer Care	14
Prepaid Calls	14
Making Emergency Calls	15
Handy tips for easier everyday usage	16
Adjusting the Volume	16
Displaying Your Phone Number	16
Greeting	16
Backlight/Contrast Setting	17
Using Caller ID	17
Saving and Storing a Phone Number in your Phone Book	18
Finding a Name in the Phone Book	19
Setting the Vibrating Ringer	19
Getting the most from Sprint PCS Service	20
Voicemail and Text Messages:	
Setting Up Your Sprint PCS Voicemail	20
Finding Out You Have A Message	21
Retrieving Voicemail Messages	21
Message Clear Count	22
Page/Text Messages	22
Page/Text Number Extraction	22
Message Storage	23
Call Waiting	23
Three-Way Calling	24
Roaming Onto Other Digital Service Providers	24
Getting the most from your phone	25
Menu Map	25
Call Logs	26
Missed Call Notification	27

Erasing Individual or All Call Logs	28
Phone Book	28
Find Name	29
Find Entry Number	30
Recall	30
Add New Entry	30
Adding Multiple Phone Numbers to an Existing Entry	32
Editing an Existing Phone Book Entry	32
Secret Phone Book Entries	33
Speed Dialing	34
4-Digit Dialing	34
Find Phone Number	35
Changing Phone Book Speed Dialing Numbers	35
Prepend Dialing	36
Pause Feature	36
Storing a Number With Pauses	37
My Phone Number	37
Scheduler: How to Set Up An Appointment	38
Add Call Alarms	40
View Schedule and Alarms	41
Erase All Alarms	42
Sounds and Display:	
Volume (Ringer and Key Beep)	42
Ringer Types	42
Tone Length	44
Security:	
Lock Phone	44
Unlock Phone	45
Change Lock	45
Restrict Calls	45
Special Numbers	46
Erase Phone Book	46
Reset Phone	47

KeyGuard	47
Breakaway Flip	48
Auto Answer For The Hands-Free Car Kit	48
Any Key Answer	48
Accessories	49
Cigarette Lighter Adapter	49
Hands-Free Car Kit	49
Standard Battery	49
Extended Battery	50
Battery Care and Storage	50
Disposal of Batteries	51
Desktop Charger	51
Subscriber Information Manager (SIM-100) Software	51
Headset	52
Leather Case	52
Important safety and warranty information	53
Understanding How Your Phone Operates	53
Following Safety Guidelines	53
Using Your Phone While Driving	53
Turn Your Phone Off Before Boarding An Aircraft	54
Radio Frequency Safety	54
Using Your Phone Near Other Electronic Devices	55
Pacemakers	56
Hearing Aids	56
Other Medical Devices	56
FCC Notice	56
Blasting Areas	57
Potentially Explosive Atmospheres	57
Restricting Children's Access To Your Phone	58
Cautions	58
Owner's Record	58
User Guide Proprietary Notice	59
Index	60

Getting to know your phone

Highlights

Congratulations on your purchase of the Sprint PCS Touchpoint™ phone. This phone is lightweight, easy-to-use, reliable, and offers many significant features:


- Seven line, backlit display screen
- Icons and text prompts inform you of messages, events and status of your phone
- Easy-to-use mouse key allows you to navigate easily through the menu options without opening the flip
- High voice quality and inherent call privacy through CDMA (digital) encoding
- Active flip allows you to answer and end calls by simply opening or closing the flip
- 300 phone numbers can be assigned to 98 different phone book entries (up to 9 phone numbers per entry)
- Multiple ringer types you can assign to phone book entries, enabling you to recognize the caller by the ring
- Built-in scheduler and call alarms

Easy Menu Navigation Control

The mouse key allows you to easily scroll through the menu. As you navigate throughout the menu, the menu options will be highlighted (**Highlighted Text**). Once you've highlighted

your desired feature, simply press **OK**. The mouse key and **OK** key are also used to change your phone's settings. The upper half of your phone's display screen is dedicated to providing you with various notifications and prompts. The lower half of the screen is dedicated to the phone's menu items. A scroll bar has conveniently been placed to the right of the menu items. This allows you to keep track of your position in the menu at all times. Intuitive prompts are displayed to guide you through each step. For example:

If you want to view your last incoming call, use your mouse key to highlight **Call Logs** and press **OK**.



Then highlight **Incoming Log** and press **OK**.

Alpha Entry Using Keypad

Press a number several times until the desired letter appears.

Letters scroll in the following order:


1 [envelope icon]	.?, ' & - @ () 1	6 MNO	P Q R S 7 p q r s 7
2 ABC	A B C 2 a b c 2	7 PQRS	T U V 8 t u v 8
3 DEF	D E F 3 d e f 3	8 TUV	W X Y Z 9 w x y z 9
4 GHI	G H I 4 g h i 4	9 WXYZ	0
5 JKL	J K L 5 j k l 5	0 OPER	Space
6 MNO	M N O 6 m n o 6	# →	Backspace

After two seconds, the cursor will automatically advance to the next space once a character has been entered. To expedite the process, use your mouse key (right) to move the cursor forward or enter any character not in the same key. If you make a mistake, press **CLR** or use the mouse key (left) to correct the last letter you entered. To clear the whole name, hold down **CLR** for about two seconds.

For example, to enter the letter "K", press **5** key twice in rapid succession. To enter the letter "Z", press the **9** key four times. (Note: The first character of each word entered defaults to uppercase, the following characters default to lowercase.)








Front View of Phone

1. On/Off Switch: Lets you power the phone on or off
2. Antenna: Calls are clearest when it's fully extended
3. Power Indicator/Dual-Color LED: Illuminates green when the phone is powered on and/or when you receive incoming calls. Flashes red when you have messages
4. Headset Jack: Provides connection for an optional headset
5. Volume Control: Lets you adjust the sound level, both voice (during a call) and ringer (when in standby)
6. Mouse Key: Lets you navigate through the menu (up, down, left, right)
7. OK: Lets you place a call, receive a call, and select menu options
8. CLR: Lets you clear your entry and back-up in the menu
9. Flip: Lets you receive and end calls



Display Icons

Display icons are all the symbols your phone uses to communicate important information. They are as follows:

ICON	DESCRIPTION
	Signal Strength Indicator
	In Use
	Digital Mode
	Roaming (occurs when in a non-Sprint PCS area)
	No Service May result from one of the following: <ul style="list-style-type: none"> • searching for system • no service • maintenance required
	New voicemail or page/text message(s)
	Battery Charge Status

Incoming Call Notification

Your phone will notify you of incoming calls in the following ways:

- The phone will ring or vibrate, depending on your settings



The backlight will come on, unless it's set "off"

- The screen will display an incoming call message
- The green LED light will flash
- The name and number of the caller will be displayed if the Caller ID feature is available

Antenna

The antenna should be extended to provide better reception when the phone is in use and retracted when the phone is not in use.

To extend the antenna, simply grasp the end and pull. The antenna extends approximately three inches. To retract, simply push the antenna back into the case.

Keeping Tabs On Signal Strength

The voice quality of your Sprint PCS Touchpoint™ phone will always be at its best when the antenna is fully extended. If you're inside a building, reception may be better near a window.



The quality of each call you make or receive depends on the signal strength in your area. Your phone will inform you of the current strength by displaying a number of bars in the signal strength icon. The more bars, the stronger the signal.



Battery

Your Sprint PCS Touchpoint™ phone is equipped with a Lithium Ion (Li-Ion) battery. This feature allows you greater talk (3 hours) and standby (48 hours) time, and allows you to recharge your battery before it is fully drained.

Installing the Battery

To install the battery pack, place the battery into the opening at a 45° angle and rotate the battery down until the latch clicks.

To remove the battery pack, locate the opening on the back of the phone, press down on the battery release latch and simultaneously lift the battery up and out of the phone.

Charging the Battery

When using the standard battery, your phone provides you with three hours talk time or 48 hours of standby time.

To charge your batteries, you should use only the Sprint PCS approved AC Adapter, Desktop Charger, Cigarette Lighter Adapter or Hands-Free Car Kit. (FOR MORE INFORMATION ON THESE ACCESSORIES, SEE THE PRODUCT USER GUIDE FOR EACH INDIVIDUAL ACCESSORY.)

When the phone reaches the low battery state (about 2% capacity), the phone will beep and the battery icon will blink. A warning will also appear on your screen prompting you to recharge your battery.



If the phone is in use, your phone will beep and a warning message will be displayed, prompting you to end your call and recharge your battery.

Using the AC Adapter

For easy desktop charging, place the phone in the charging cradle provided with your phone. Attach the AC Adapter to the connector on the back side of the cradle.

To charge the battery, simply attach one end of the AC Adapter to the connector at the bottom of your phone and plug the other end into a standard wall outlet. When your phone is powered off, a text message

Battery charging - Power Off

will appear on your screen.

The battery display icon will change continuously regardless of whether the phone is on or off. If your battery's charge is completely run down, it will take approximately two to three hours to fully recharge. It isn't necessary to let the battery completely run down before recharging. When the battery is fully charged, the battery icon will stop changing.



Using Your Phone: Basic operations to place and receive calls

Turning Your Phone On and Off

Begin by making sure the battery has been installed correctly and has adequate charge, or that you have external power (Cigarette Lighter Adapter, etc.).

To turn your phone on, move the On/Off switch to the "ON" position. At that time your phone will perform a short self-test to let you know the phone is operational.

To turn your phone off, move the On/Off switch to the "OFF" position. The power off screen will be displayed and the phone will power down shortly.

Power Save Mode

When in a no-service area for 15 minutes, your phone will stop looking for service and will enter into a Power Save mode. If your phone is "ON", it will periodically recheck service availability, or you can do so manually by pressing any key. The message

Power Save

will be displayed on your screen when the phone activates this feature.

Standby Display

When your phone has acquired service, the greeting/banner will be displayed along with the date and time. The menu options will be displayed on the lower half of the screen. This is known as the standby display or standby state. While in the standby state, use the mouse key to highlight the menu option you wish to select, or enter a phone number using the keypad.

Placing a Call

Whenever you make a call, follow these simple steps:

1. With the phone powered on, check the display icons to see if you are in a Sprint PCS Service Area. For best voice quality, fully extend the antenna.
2. Open the flip (if the number you are calling is not already programmed in your Phone Book).
3. Enter phone number, highlight **Call** and press **OK**.
(Note: It is not necessary to enter a "1" before the area code when dialing long distance.)
4. When you are finished with your call, highlight **End Call**, and press **OK** or close the flip.

Correcting Dialing Mistakes

Press **CLR** or mouse key (left) to delete one digit at a time, or press and hold **CLR** to delete all digits entered.

Answering Calls

The flip may be open or closed. An incoming call can be answered by either opening the flip or pressing **OK**.

Warning: If you open the flip and then press **OK**, you will hang up on the caller.

User Options During a Call (In-call state/status)

During a call your phone provides you with access to all the menu items you have in the standby state. You will also notice three additional menu items or in-call options. The three in-call options (End Call, Mute, and 3-Way Call) appear on your screen immediately after your call is connected. To select one of the three options simply highlight the option you wish to select and press **OK**.

(See page 24 for detailed instructions on using 3-way calling.)

Mute

The mute function on your Sprint PCS Touchpoint™ works just like your phone at home. While your call is muted the party on the other end of your call will not be able to hear you.

While in a call:

1. Highlight **Mute** and press **OK**.

To unmute the call:

1. Highlight **Unmute** and press **OK**.

Redialing Last Outgoing Number

Highlight **Call Logs**, press and hold **OK** for about 2 seconds.

Dialing Sprint PCS Directory Assistance

To obtain residential, business and governmental listings; to get help completing local or long-distance calls; or to obtain movie listings, hotel, shopping and major local event information, contact Sprint PCS Directory Assistance by dialing

4 1 1 OK. Or...

1. From the menu, highlight **Phone Book** and press **OK**.
2. Highlight **Services** and press **OK**.
3. Highlight **Dir Assist** and press **OK**.
4. Highlight **Call** and press **OK**.

You can obtain more than one number at a time from Sprint PCS Directory Assistance. Sprint PCS will connect your call for no additional charge.

Dialing Sprint PCS Operator Services

Dial **0**, highlight **Call** and press **OK** for assistance with placing collect calls or calls billed to a calling card or to a third party.

Note: You cannot charge calls made through operator services to your Sprint PCS account.

Dialing Sprint PCS Customer Care

Sprint PCS Customer Care can be reached by dialing *** 2 OK** (in southern California dial *** 6 1 1 OK**) or by calling 1-888-211-4PCS (4727) (in southern California call 1-800-455-4551). Or...

1. From the menu, highlight **Phone Book** and press **OK**.
2. Highlight **Services** and press **OK**.
3. Highlight **Customer Care** and press **OK**.
4. Highlight **Call** and press **OK**.

A Sprint PCS Customer Care Advocate will answer 24 hours a day and will be happy to assist you.

Prepaid Calls

Prepaid Customers can access the Prepaid Options Menu* to receive account balance notification, replenish their account or speak with Sprint PCS Customer Care. There are two ways to access the Prepaid Options Menu, free of charge:

1. Dial *** 7 2 9 OK**, or

If you can't recall the phone number, you can access the Prepaid Options Menu through your Phone Book menu, by:

1. From the menu, highlight **Phone Book** and press **OK**.
2. Highlight **Services** and press **OK**.
3. Highlight **Prepaid** and press **OK**.
4. Highlight **Call** and press **OK**.

*Note: Only available to Sprint PCS Customers that have a Prepaid Account.

Making Emergency Calls

You can place calls to 911, Customer Care (*** 2 OK**) or any of the other three user-specified special numbers even if your phone is locked. To call 911 simply dial **9 1 1** and press **OK**.

Handy tips for easier everyday usage

Adjusting the Volume

The volume keys on the side of your Sprint PCS Touchpoint™ phone can perform two different functions. They let you:

- Adjust the earpiece volume during a call.
- Adjust the ringer volume in the standby state.

Displaying Your Phone Number

1. From the menu, highlight **Phone Book** and press **OK**.
2. Highlight **My Phone #** and press **OK**.

Greeting

This feature allows you to put whatever you want on your phone's display screen – just as long as it's no more than 12 characters. Your greeting will be displayed on the top line whenever your phone is on. To change your greeting:

1. From the menu, highlight **Display** and press **OK**.
2. Highlight **Greeting** and press **OK**.
3. Highlight **Change** and press **OK**.
4. Using your **CLR** key, delete the existing greeting and enter your custom greeting.
5. Highlight **Save** and press **OK**.

Backlight/Contrast Setting

Your Sprint PCS Touchpoint™ phone allows you to customize the backlight and contrast setting.

To change the backlight setting:

1. From the menu, highlight **Display** and press **OK**.
2. Highlight **Backlight** and press **OK**.
3. Depending on your preference, highlight **8 Seconds**, **15 Seconds**, **30 Seconds**, or **Off** and press **OK**.

Note: For maximum battery life the backlight setting should be set to "Off".

To adjust your phone's display contrast:

1. From the menu, highlight **Display** and press **OK**.
2. Highlight **Contrast** and press **OK**.
3. Depending on your preference, highlight **Highest**, **High**, **Medium**, **Low** or **Lowest** and press **OK**.

Using Caller ID

This feature tells you who is calling by displaying the caller's number when the phone rings. If the caller's name and number are stored in your phone's internal phone book, the name you've stored will be displayed along with the number.

If you call someone who also has Caller ID, your Sprint PCS Phone Number will be displayed on their phone.

To block your Sprint PCS Phone Number from being displayed for a particular outgoing call, follow these steps:

1. Dial *** 6 7**.
2. Dial the outgoing phone number and press **OK**.

Saving and Storing a Phone Number in your Phone Book

Your Sprint PCS Touchpoint™ phone provides you with multiple ways of adding numbers to your phone book. An easy way to get started with your phone book is to follow these simple instructions:

1. From the menu, highlight **Phone Book** and press **OK**.
2. Highlight **Add New Entry** and press **OK**.
3. Enter name (up to 12 characters) associated with phone number and press **OK**. To enter the name, press the key that corresponds to the letter you want to display. See “Alpha Entry using Keypad” on page 2 for more information.
4. Enter phone number (up to 44 digits). We suggest that you save numbers using the area code so you can easily dial them from your phone book while traveling outside your Sprint PCS Home Service Area.
5. Highlight **Next Step** and press **OK**.
6. Highlight desired label (**Home**, **Work**, **Mobile**, **Pager**, **Fax**, or **No Label**) and press **OK**.
7. To store your entry in the next available memory location simply press **OK**.

(For more advanced phone book features and alternative ways to enter phone book entries, see pages 28-37.)

Finding a Name in the Phone Book

1. From the menu, highlight **Phone Book** and press **OK**.
2. Highlight **Find Name** and press **OK**.
3. Enter the name of the number you want to find. Once a letter is entered, the phone book will automatically display all the entries that start with that particular letter. The search will continue to narrow as you enter more letters.
4. Once the name you wish to call is displayed, use your mouse key to highlight the name and press **OK**.
5. Highlight **Call** and press **OK**.

Setting the Vibrating Ringer

The vibrating ringer feature allows you to receive incoming calls without disturbing others. You can select this feature by either of the methods below:

1. While in the standby state, press either the up or down volume key and the Ringer Volume Setting will appear on the upper half of the screen. Five ringer settings are available: **High**, **Medium**, **Low**, **Off**, and **Vibrate**. Using the volume keys select **Vibrate** and your phone will use the vibrating ringer to notify you of incoming calls.
2. From the menu, highlight **Sounds** and press **OK**. Highlight **Volume** and press **OK**. Highlight **Ringer** and press **OK**. Highlight **Vibrate** and press **OK**.

Getting the most from Sprint PCS Service

Voicemail and Text Messages:

Setting Up Your Sprint PCS Voicemail

Voicemail allows callers to leave a message when you don't answer your Sprint PCS Touchpoint™ phone. We suggest you set up your voicemail box soon after your phone is activated. To activate your voicemail:

1. In the standby state either press and hold **1** for about 2 seconds, or highlight **Messages** and press and hold **OK** for about 2 seconds.


2. Follow the system prompts.

The first time you access the voicemail system from your Sprint PCS Touchpoint™ phone, it will prompt you to:

- ▶ Create your own personal pass code. Make sure that you pick a number that is easy to remember.
- ▶ Create the greeting that people will hear when they call you.
- ▶ Initialize your name announcement.
- ▶ Choose whether to activate One-Touch Access.

After you have set up your voicemail box, it will automatically record messages whenever someone calls and you don't answer. Whenever you need to call your voicemail from your home or business phone, you should dial your Sprint PCS Phone Number, press ***** and enter your pass code.

Finding Out You Have A Message

Your Sprint PCS Touchpoint™ phone alerts you when you have new messages: If you have new messages, your phone will ring and you will be notified with a  icon, and message notification on your screen, along with a red flashing LED light.

Note: If you are out of the Sprint coverage area you will not be notified of your messages.


Retrieving Voicemail Messages

You can listen to your messages by following any of the three methods.

1. In the standby state press and hold **1** for about 2 seconds, or
2. From the menu, highlight **Messages** and press and hold **OK** for about 2 seconds, or
3. From the menu, highlight **Messages** and press **OK**. Highlight **Voicemail** and press **OK**. Highlight **Call** and press **OK**.

Follow the system prompts.

Message Clear Count

To clear the  icon from your display screen:

1. From the menu, highlight **Messages** and press **OK**.
2. Highlight **Voicemail** and press **OK**.
3. Highlight **Clear Count** and press **OK**.
4. Highlight **Yes** and press **OK**.

Page/Text Messages

Text Messages can be retrieved by following these simple steps:

1. From the menu, highlight **Messages** and press **OK**.
2. Highlight **Page/Text** and press **OK**.
 - Use your mouse key (up/down) to scroll through messages.
 - Press **OK** to read your messages.

When reading a message:

- Use your mouse key (left/right) to navigate to the previous or next message.
- Pressing **OK** when reading a message (or the down arrow key at the end of the message) will bring up the options for the message.

Page/Text Number Extraction

When you receive a page/text message on your Sprint PCS Touchpoint™ phone that contains phone numbers you can extract those numbers, making it easy to place a call or save the numbers. To extract a phone number:

1. While reading a message, press **OK** to view the message option menu.
2. Highlight **Extract #'s** and press **OK**.
3. The phone will display all the numbers extracted from the message.

4. Highlight the appropriate number and press **OK**.
5. Depending on what you want to do, highlight Call, Save, or Next, and press **OK**.

Message Storage

Your Sprint PCS Touchpoint™ phone is capable of storing up to 20 text messages and numeric pages. When the message memory is 75% full, a warning message will be displayed, prompting you to erase messages in order to obtain more memory space.

Call Waiting

When there is a call waiting, you will hear a beep and a text message, including the caller's name (if the caller is programmed into your phone book) and phone number, will appear on your screen. To answer the call:

1. Highlight **Flash** and press **OK**.

To toggle between the two callers, simply highlight **Flash** again and press **OK**.

If you do not want to be interrupted during a particular call, you can temporarily disable Call Waiting by dialing *** 7 0** before dialing the phone number. When the call is finished, Call Waiting will be reactivated automatically.

To permanently disable Call Waiting for all calls, contact Sprint PCS Customer Care.

Three-Way Calling

Three-Way Calling lets you talk with two people at the same time.

1. Dial the first number, highlight **Call** and press **OK**.
2. When connected, highlight **3-Way Call** and press **OK**.
3. Dial the second number, highlight **Call** and press **OK**.
4. When the second party answers, highlight **Flash** and press **OK** again to begin your Three-Way call.

When you use this feature, you will be charged normal airtime rates for each call. Each call will appear as a separate item on your bill.

Note: Three-Way calls may also be placed through the Call Logs, Phone Book, or Message menus.

Roaming Onto Other Digital Service Providers


Roaming may occur when the phone is outside the Sprint PCS Service Area and there is another PCS service provider in that area. In addition to the **D** icon, the roaming icon **R** is displayed along with a text message

Digital Roam


whenever this situation occurs; otherwise the no service icon **X** will be displayed.

Getting the most from your phone

Menu Map



Menu Map (cont'd)



Call Logs

Your Sprint PCS Touchpoint™ phone captures the last 10 incoming calls, 10 outgoing calls, and 10 missed calls in the Call Logs menu. Calls can be placed through the Call Logs menu, providing a quick and easy way to call frequently used numbers. Numbers in your Call Logs can also be saved to your Phone Book (see page 28 for more information on your Phone Book). Additional information, such as the time and date a particular call was made, received, or missed may also be viewed once a number is selected.

To review this list, follow these steps:

1. From the menu, highlight **Call Logs** and press **OK**.
2. Highlight either **Outgoing Log**, **Incoming Log**, or **Missed Log** and press **OK**.
3. Use your mouse key to scroll through the last ten dialed, received, or missed calls.

To view time and date information:

1. Highlight the call you wish to receive information about and press **OK**.
2. Once you've selected a number in the Call Log menu, highlight **Time/Date** and press **OK** to display the date and time that particular call was made, received or missed.

To place a call from this list simply following these steps:

1. Highlight the number you want to call and press **OK**.
2. Highlight **Call** and press **OK**.

Note: Once you've selected a call from the Outgoing, Incoming or Missed log, you can scroll through all the calls in that log using your mouse key (left/right).

Missed Call Notification

When an incoming call is not answered, the missed call will be logged into the "Missed Log". The missed call information shall continue to be updated and displayed until canceled explicitly by pressing **CLR** when in the missed call information display.

Erasing Individual or All Call Logs

To erase an individual call log...

1. From the menu, highlight **Call Logs** and press **OK**.
2. Highlight **Erase Logs** and press **OK**.
3. Highlight the log you wish to erase (**Outgoing Log**, **Incoming Log**, or **Missed Log**) and press **OK**.
4. Highlight **Yes** and press **OK**.

To erase all call logs (Outgoing Log, Incoming Log, and Missed Log)...

1. From the menu, highlight **Call Logs** and press **OK**.
2. Highlight **Erase Logs** and press **OK**.
3. Highlight **All Logs** and press **OK**.
4. Highlight **Yes** and press **OK**.

Phone Book

Your Sprint PCS Touchpoint™ phone has 98 Phone Book memory locations capable of storing up to 300 phone numbers. This allows you to organize your phone book, storing up to 9 phone numbers under one person's name. You will no longer have to look for a person's home number one place and their work number in another. (Each memory location will accept up to 12 characters per entry name and 44 digits for the phone number.)

Once you have entered a name and number, you are given the option of attaching a label (Home, Work, Mobile, Pager, Fax, or No Label) to the entry. When you search the phone book, either by name or entry, the selected phone number will appear in the upper half of the display. If a label has been attached to the phone number, a small icon/label will appear before the phone number. This feature provides you with a convenient method of identifying the phone number as the person's home, work, mobile, pager or fax number. See "Add New Entry" on page 30 for more information.

Find Name

1. From the menu, highlight **Phone Book** and press **OK**.
2. Highlight **Find Name** and press **OK**.
3. From here you have two options, you can either use your mouse key to scroll through your phone book entries or enter the letter(s) of the entry you want to find (more information on alpha-entry can be found on page 2).
4. If you entered the letters manually, your Sprint PCS Touchpoint™ phone will automatically search for entries with those letters and display a list of matches.
5. To place a call, highlight the name you wish to call and press **OK**.
6. Highlight **Call** and press **OK**.

Note: Once you've selected a phone book entry you can scroll through all your existing entries using your mouse key (left/right).

Find Entry Number

1. From the menu, highlight **Phone Book** and press **OK**.
2. Highlight **Find Entry** and press **OK**.
3. From here you have two options, either use your mouse key to scroll through your phone book entries or enter the two-digit memory location to display the number.
4. To place a call, highlight the name you wish to call and press **OK**.
5. Highlight **Call** and press **OK**.

Note: Once you've selected a phone book entry you can scroll through all your existing entries using your mouse key (left/right).

Recall

The Recall function provides a quick way of selecting a phone book entry.

1. Enter a phone book entry's memory location number or speed dialing number.
2. Highlight **Recall** and press **OK**.

Add New Entry

1.
 - a. From the menu, highlight **Phone Book** and press **OK**.
 - b. Highlight **Add New Entry** and press **OK**.
 - c. Enter a name to correspond with the number (use the alpha-entry method described on page 2).

- d. Once the name is entered correctly, press **OK**.
 - e. Enter the phone number you want to save. We suggest that you save numbers using ten digits (area code + number) so you can dial them from your phone book while traveling outside your Sprint PCS Home Service Area.
 - f. Highlight **Next Step** and press **OK**.
 - g. Highlight the appropriate label (**Home**, **Work**, **Mobile**, **Pager**, **Fax**, **No Label**) for your entry and press **OK**.
 - h. The entry # will automatically default to the next available number. Press **OK** to confirm or use the mouse key to highlight another entry # and press **OK**.
2.
 - a. From the standby state, enter a phone number using your phone's keypad.
 - b. Highlight **Save** and press **OK**.
 - c. Follow the phone's prompts.
3. At the conclusion of a phone call, both incoming and outgoing, you have the option of saving that particular number.
 - a. Once you have ended your call, highlight **Save** and press **OK**.
 - b. Follow the phone's prompts.

4. a. From the menu, highlight **Call Logs** and press **OK**.
- b. Highlight **Outgoing Log**, **Incoming Log**, or **Missed Log**.
- c. Highlight the number you want to save and press **OK**.
- d. Highlight **Save** and press **OK**.
- e. Follow the phone's prompts.

Adding Multiple Phone Numbers to an Existing Entry

Once an entry has been added to your phone book you can enter multiple phone numbers (up to 9) to that entry.

1. Select the Phone Book entry you wish to add phone numbers to. See "Find Name" and/or "Find Entry Number" on Pages 30-31 for detailed instructions on selecting a phone book entry.
2. Highlight **Add Phone #** and press **OK**.
3. Enter phone number, highlight **Next Step** and press **OK**.
4. Highlight the appropriate label (**Home**, **Work**, **Mobile**, **Pager**, **Fax**, or **No Label**) and press **OK**.

Editing an Existing Phone Book Entry

To edit an existing phone book entry:

1. Select the entry you wish to edit (See "Find Name" and/or

"Find Entry Number" for detailed instructions on selecting a phone book entry).

2. Highlight **Edit** and press **OK**.
3. Highlight the feature (**Phone #**, **Name**, or **Entry #**) you want to edit and press **OK**.
4. Follow the phone's prompts.

Secret Phone Book Entries

Your Sprint PCS Touchpoint™ phone allows you to make certain phone book entries "secret". Once "secret", the entry will still be displayed in your phone book, however, the entry's phone number will not be displayed.

To make a phone book entry secret:

1. Select an existing phone book entry (See "Find Name" and/or "Find Entry Number" for detailed instructions on selecting a phone book entry).
2. Highlight **Edit** and press **OK**.
3. Highlight **Make Secret**, and press **OK**.
4. Highlight **Yes**, and press **OK**.

To make a secret phone book entry not secret:

1. Select the secret phone book entry you wish to change (See "Find Name" and/or "Find Entry Number" for detailed instructions on selecting a phone book entry).

2. Highlight **Edit** and press **OK**.
3. Enter your 4-digit lock code.
4. Highlight **Make Secret** and press **OK**.
5. Highlight **No** and press **OK**.

Speed Dialing

Every phone book entry is assigned an entry number or speed dialing number. To dial a phone book entry using the entry's speed dialing number, simply:

1. Dial the one or two digit speed dialing number assigned to the phone book entry you wish to call.
2. Highlight **Speed Dial** and press **OK**.

See page 35 for instructions on how to change the entry's Speed Dialing number.

4-Digit Dialing

4-Digit dialing is another form of speed dialing. If you cannot remember your phone book entry's speed dialing number, but remember the last four digits of the entry's phone number, all you have to do is:

1. Dial the last four digits of a phone book entry's phone number.
2. Highlight **4-Digit Dial** and press **OK**.

Find Phone Number

Your Sprint PCS Touchpoint™ phone is so user-friendly it will even search for phone numbers containing certain numbers. For example, let's say you can only remember the first three numbers of the phone number you wish to call; your phone can pull up all the phone numbers that begin with those numbers in your phone book.

1. Dial the numbers
2. Highlight **Find** and press **OK**.
3. Using your mouse key (up/down), scroll through the list of phone numbers containing the numbers you entered.
4. Highlight the number you wish to call and press **OK**.
5. Highlight **Call** and press **OK**.

Changing Phone Book Speed Dialing Numbers

The first phone number entered when entering a new phone book entry is automatically set as the speed dialing number for that particular entry. For example, if the first phone number you entered was the person's work number, that number will be the entry's speed dialing number. To change the speed dialing phone number of a specific phone book entry:

1. Select an existing phone book entry (See "Find Name" and/or "Find Entry Number" for detailed instructions on selecting a phone book entry).
2. Highlight **Edit** and press **OK**.

3. Highlight **Set Speed Dial** and press **OK**.
4. Highlight the number you wish to set as your default and press **OK**.

Prepend Dialing

Prepend dialing allows you to prepend a phone number in your phone book with additional numbers that you can enter. For example, if your phone book entry was entered without an area code and you are out of town, you can prepend that entry with the appropriate area code. A second example would be if you wanted to make a phone call using a calling card. You would prepend the calling card number before the phone number of the person you want to call.

1. Select the phone book entry or call log using one of the previously described methods.
2. Highlight **Prepend** and press **OK**.
3. Enter the digits you wish to prepend.
4. Highlight **Call** and press **OK**.

Note: Use the prepend function to view your long phone numbers (over 13 digits).

Pause Feature

When you call automated systems (such as voicemail or credit card billing numbers), you often have to enter a series of numbers. Instead of entering the numbers by hand, you can store the numbers in your phone book separated by special characters called pauses:

- **Hard Pauses** - Once your call is connected, highlight **Send Tones** and press the **OK** key to send the next string of numbers.
- **2 Second Pauses** - Your phone will send the next set of numbers after two seconds. Each additional timed pause will add two more seconds to the pause length.

Storing a Number With Pauses

1. Enter the number you wish to call.
2. Highlight **Hard Pause** or **2 Second Pause** and press **OK**.

Note: Hard Pauses will be displayed on your screen as a "P", while 2-Second pauses will be displayed as a "T".

3. Enter additional numbers (e.g. pin number, credit card number).
4. To dial the number, highlight **Call** and press **OK**. To save the number in your phone book, highlight **Save**, press **OK**, and follow the phone's prompts.

My Phone Number

Sprint PCS has provided an easy way to display your phone number in case you forget it.

1. From the menu, highlight **Phone Book** and press **OK**.
2. Highlight **My Phone #** and press **OK**.

(Note: An easy way to remember your number and keep it displayed at all times is to set your phone number as your Greeting/Banner. For information on how to change your greeting, see page 17.)

Scheduler: How to Set Up An Appointment

You may store up to 25 events in your scheduler.

1. From the menu, highlight **Scheduler** and press **OK**.
2. Highlight **Add Event** and press **OK**.
3. Highlight **Schedule** and press **OK**.
4. Using your keypad, enter a description of the event (up to 32 characters).
5. Highlight **Next Step** and press **OK**.
6. Enter the time and date of the event. Using your mouse key (left/right), move the cursor to select the time or date field you wish to change and use your keypad to enter the appropriate digits. To change AM to PM or vice versa, use your mouse key (up/down) to highlight **AM/PM** and press **OK**.
7. Once you've selected the proper date and time of the event, highlight **Next Step** and press **OK**.
8. Enter the duration of the event, following the same instructions of the previous step.
9. Highlight **Done** and press **OK**.

Once your phone notifies you of your scheduled appointment you will have three options displayed on your screen:

1. **Details** – allowing you to view the details (time, date, etc.) of your event. To view the “Details”, simply highlight **Details** and press **OK**.
2. **Snooze** – this works just like your alarm clock at home. By selecting Snooze the alarm will quit and begin again in 10 minutes. To select Snooze, highlight **Snooze** and press **OK**.
3. **OK** – by selecting OK you acknowledge the alarm and your schedule entry will be erased from your phone's memory. To select “OK”, highlight **OK** and press **OK**.

Note: Your scheduler will not work when in a No-Service area.

Add Call Alarms

Call alarms can be set to remind you to place important calls.

1. From the menu, highlight **Scheduler** and press **OK**.
2. Highlight **Add Event** and press **OK**.
3. Highlight **Call Alarm** and press **OK**.
4. Using your keypad, enter the name you want to set your alarm to call, or use your mouse key to scroll to that number. Once a letter is entered, the phone book will display all the entries that start with that particular letter. The search will continue to narrow as you enter more letters.
5. Once you've highlighted the appropriate name, press **OK**.
6. Enter the date and time. (For detailed instructions see step 6 of "How to set up an appointment" on page 39.)
7. Highlight **Next Step** and press **OK**.

You may also add call alarms from the phone book. To do so, simply:

1. Select an existing phone book entry. (See "Find Name" and/or "Find Entry Number" for detailed instructions on selecting a phone book entry.)
2. Highlight **Call Alarm** and press **OK**.
3. Enter time and date. (For detailed instructions see Step 6 of "How to set up an appointment on page 39.)
4. Highlight **Next Step** and press **OK**.

When the Call Alarm sounds, 3 menu options will appear on your screen:

1. Call – Select "Call" to dial the number. Highlight **Call** and press **OK**.
2. Snooze – this works just like your alarm clock at home. By selecting Snooze the alarm will quit and begin again in 10 minutes. To select Snooze, highlight **Snooze** and press **OK**.
3. OK – by selecting OK you acknowledge the alarm and your schedule entry will be erased from your phone's memory. To select "OK", highlight **OK** and press **OK**.

Note: Your Call Alarms will not work when in a No Service area.

View Schedule and Alarms

1. From the menu, highlight **Scheduler** and press **OK**.
2. Highlight **View Events** and press **OK**.
3. All your scheduled alarms and events will be listed.
4. Highlight the alarm or event you wish to view and press **OK**.
5. Use your Mouse Key (left/right) to navigate to the previous or next alarm entry.

Once selected you can edit or erase the scheduled alarm.

Erase All Alarms

To erase all your scheduled alarms follow these simple steps:

1. From the menu, highlight **Scheduler** and press **OK**.
2. Highlight **Erase All** and press **OK**.
3. Highlight **Yes** and press **OK**.

Sounds and Display:

Volume (Ringer and Key Beep)

1. From the menu, highlight **Sounds** and press **OK**.
2. Highlight **Volume** and press **OK**.
3. Highlight **Ringer** or **Key Beep** and press **OK**.
4. Highlight **High**, **Medium**, **Low**, **Off** or **Vibrate** (Not applicable to Key Beep) and press **OK**.

Ringer Types

Your Sprint PCS Touchpoint™ phone provides you with multiple ringer types. Besides being fun to play with, this allows you to assign different ring types for Voice Calls (With Caller ID, No Caller ID, or Roaming), Messages (Voicemail or Page/Text), and Alarms. You can also customize different rings for individual phone book entries, making it easy to distinguish who is calling without having to look at your phone. Select a ring type by following these simple directions:

1. From the menu, highlight **Sounds** and press **OK**.
2. Highlight **Ring Type** and press **OK**.

3. Depending on which option you want to change, highlight **Voice Calls**, **Messages**, or **Alarms** and press **OK**.

a. If you selected Voice Calls:

- Highlight **With Caller ID**, **No Caller ID**, or **Roaming** and press **OK**.

b. If you selected Messages:

- Highlight **Voicemail** or **Page/Text**, and press **OK**.

4. Using your mouse key scroll through the list of ring types. Once you've highlighted the ring you want, press **OK**.

To customize different rings for your phone book entries:

1. Select a phone book entry.
2. Highlight **Set ID Ringer** and press **OK**.
3. Highlight the ring type you wish to assign to your entry and press **OK**.

Tone Length

Your phone provides you with two customization options for the tone length. To customize the tone length of DTMF tones sent after a call is connected:

1. From the menu, highlight **Sounds** and press **OK**.
2. Highlight **Tone Length** and press **OK**.
3. Depending on your preference, highlight either **Short** or **Long** and press **OK**.

Security: Lock Phone

You must enter your lock code to view the security menu. Typical default values are either the last 4 digits of your phone number or 0000. When your phone is locked, you can only make emergency calls (9-1-1 and your user-specified Special Numbers) or receive incoming calls. All other functions of the phone are disabled. If you forget your lock code, take your phone to the nearest Sprint PCS Center.

1. Highlight **Security** and press **OK**.
2. Enter lock code.
3. Highlight **Lock Phone** and press **OK**.
4. Depending on your preference, highlight either **Lock Now** or **On Power Up** and press **OK**.

Unlock Phone

1. Highlight **Unlock** and press **OK**.
2. Enter lock code.

Change Lock

To change your Lock Code:

1. From the security menu, highlight **Change Lock** and press **OK**.
2. Enter your new code.

Re-enter your new code and your new code will be saved.

Restrict Calls

Your Sprint PCS Touchpoint™ phone allows you to restrict certain calls being placed to or from your phone.

1. From the security menu, highlight **Restrict Calls** and press **OK**.
2. Highlight **Outgoing** or **Incoming** and press **OK**.
3. Highlight **Allow All**, **PhoneBook Only**, or **Special # Only** and press **OK**.

By selecting "PhoneBook Only", your phone will restrict you from making or receiving calls to any number other than your phone book entries. By selecting "Special# Only", you will not be able to make or receive calls to any number other than special numbers.

Note: Emergency calls can still be made in this state.

To deactivate Restrict Calls:

1. From the security menu, highlight **Restrict Calls** and press **OK**.
2. Highlight **Off** and press **OK**.

Special Numbers

This feature allows you to store 3 important phone numbers that can be directly dialed even if your phone is locked. To add a phone number to your Special Numbers:

1. From the security menu, highlight **Special #s** and press **OK**.
2. Highlight the entry number where you would like to store the number and press **OK**.
3. Enter the phone number.
4. Highlight **OK** and press **OK**.

Note: There is no speed dialing option associated with special numbers.

Erase Phone Book

To erase the entire phone book:

1. From the security menu, highlight **Erase PhoneBook** and press **OK**.
2. If you're sure you want to erase your phone book, highlight **Yes** and press **OK**.

Reset Phone

Resetting your phone will restore all the factory defaults, including ringer types, display settings, etc. However, your Call Logs, Phone Book, Scheduler, Messages, and Call Alarms will not be affected.

1. From the menu, highlight **Security** and press **OK**.
2. Enter your 4-digit lock code and the security menu will appear.
3. From the security menu, highlight **Reset Phone** and press **OK**.
4. If you're sure you want to reset your phone, highlight **Yes** and press **OK**.

KeyGuard

KeyGuard allows you to keep the phone in your pocket or purse without the worry of accidentally dialing a number. While in this mode, incoming calls will temporarily disable KeyGuard. If you do not answer the call, your phone will return to the KeyGuard state.

To activate KeyGuard from the menu, highlight **KeyGuard** and press **OK**. To disable KeyGuard, press and hold **CLR** for about two seconds.

Breakaway Flip

Your Sprint PCS Touchpoint™ phone comes equipped with a breakaway flip. That is, the flip is designed to breakaway or detach from the phone. If your flip breaks away, simply line the hinges up with the flip openings and snap it back into place.

Note: Your phone is fully functional without the flip. It will act as if the flip is open.

Auto Answer For The Hands-Free Car Kit

While your phone is connected to your Sprint PCS Hands-Free Car Kit you can set your phone to auto answer. This feature will enable your phone to answer incoming calls automatically after 5 seconds; you do not have to press anything. (WARNING: While your phone is in the Auto Answer mode your phone will answer incoming calls regardless of whether you are present or not.) To activate this feature:

1. From the menu, highlight **Setup** and press **OK**.
2. Highlight **Car Use** and press **OK**.
3. Highlight **Auto Answer** and press **OK**.
4. Highlight **On** and press **OK**.

To disable Auto Answer, simply follow steps 1 – 3 and select Off.

Any Key Answer

Your phone can be set to answer incoming calls by pressing any key (Not including the **CLR** key, mouse key, or volume keys). To customize your phone to function this way, follow these simple instructions:

1. From the menu, highlight **Setup** and press **OK**.
2. Highlight **Any Key Answer** and press **OK**.
3. Highlight **On** and press **OK**.

Accessories

A variety of accessories are available for your new Sprint PCS Touchpoint™ phone. You can choose the accessories that best meet your personal communication needs. Accessories can be ordered by calling the Sprint PCS Accessories HotlineSM (1-800-974-2221) or **# A C C** from your Sprint PCS Touchpoint™ phone.

Cigarette Lighter Adapter

You can operate your Sprint PCS Touchpoint™ phone and charge the phone's battery from your vehicle by using the Cigarette Lighter Adapter. If your battery's charge is completely run down, it will take approximately two to three hours to recharge.

Hands-Free Car Kit

The Hands-Free Car Kit enables you to attach the phone to your car, providing you with hands-free operation as well as charging your phone's battery. If your battery's charge is completely run down, it will take approximately two to three hours to recharge.

Battery Care and Storage

For best battery performance, follow these guidelines:

- Only use Sprint PCS approved battery packs and charging devices. These chargers are designed to maximize battery life. Using other batteries or chargers will void your warranty and may cause damage as well.
- To avoid damage, charge the battery only in temperatures ranging from 32°F to 130°F.
- Do not use the battery charger in direct sunlight or in high humidity areas, such as the bathroom.
- Never dispose of the battery pack by burning.
- Keep the metal contacts at the top of the battery pack clean.
- Do not allow the battery contacts to touch metal materials.
- Do not attempt to disassemble or short-circuit the battery pack.
- Do not use battery if visibly damaged
- Keep the battery out of the reach of children or pets.
- You may need to recharge the battery if it has not been used for a long time.

Replace the battery when it no longer provides acceptable performance. It can be recharged hundreds of times before it will need to be replaced.

Disposal of Batteries

The Sprint PCS Touchpoint™ batteries are Lithium Ion (Li-Ion); please dispose of properly.

Note: In some areas, the disposal of rechargeable batteries in household or business trash may be prohibited.

Desktop Charger

The two-slot desktop charger provides a means for charging the phone and a spare battery at the same time. It consists of an AC/DC adapter, which provides the required DC power to a two-slot phone/battery cradle and charges a standard battery in approximately two hours, and the extended battery in approximately three hours.

The desktop charger also has a dual color LED for each slot. The lights will illuminate red when the battery and/or phone is charging and green when the battery and/or phone is fully charged.

Subscriber Information Manager (SIM-100) Software

The SIM-100 Software is a PC-windows based application used to manage your internal phone book, scheduler appointments and alarms, and user preferences of the Sprint PCS Touchpoint™ phone. This enables you to input your phone book and scheduler data directly into your PC and download that information from your PC to your Sprint PCS Touchpoint™ phone.

FAILURE TO FOLLOW THESE INSTRUCTIONS MAY LEAD TO SERIOUS PERSONAL INJURY AND POSSIBLE PROPERTY DAMAGE.

Turn Your Phone Off Before Boarding An Aircraft

You should turn off your phone before boarding any aircraft. To prevent possible interference with aircraft systems, US Federal Aviation Administration (FAA) regulations require you to have permission from a crewmember to use your phone while the plane is on the ground. To prevent any risk of interference, FCC regulations prohibit using your phone while the plane is in the air.

Radio Frequency Safety

In 1991-1992, the Institute of Electrical and Electronics Engineers (IEEE) and the American National Standards Institutes (ANSI) joined in updating ANSI's 1982 standard for safety levels with respect to human exposure to RF signals. More than 120 scientists, engineers and physicians from universities, government health agencies and industries developed this updated standard after reviewing the available body of research. In 1993, the Federal Communications Commission (FCC) adopted this updated standard in a regulation. In August 1996, the FCC adopted a hybrid standard consisting of the existing ANSI/IEEE standard and the guidelines published by the National Council of Radiation Protection and Measurements (NCRP).

The design of your Sprint PCS Touchpoint™ phone complies with these updated standards. Of course, if you want to limit RF exposure even further than the updated standard, you can choose to control the duration of your calls and operate your phone in the most power-efficient manner.

Using Your Phone Near Other Electronic Devices

Most modern electrical equipment is shielded from radio frequency (RF) signals. However, RF signals from PCS phones may affect inadequately shielded electronic equipment.

RF signals may affect improperly installed or inadequately shielded electronic operating and entertainment systems in motor vehicles. Check with the manufacturer or its representative to determine if these systems are adequately shielded from external RF signals. You should also check with the manufacturer regarding any equipment that has been added to your vehicle.

Consult the manufacturer of any personal medical devices (such as pacemakers and hearing aids) to determine if they are adequately shielded from external RF signals.

Turn off the phone in health care facilities and request permission before using the phone near medical equipment.

Pacemakers

The Health Industry Manufacturers Association recommends that a minimum separation of six (6") inches be maintained between a hand held wireless phone and a pacemaker to avoid potential interference with the pacemaker. These recommendations are consistent with the independent research by and recommendations of Wireless Technology Research. Persons with pacemakers:

- ▶ Should always keep the phone more than six inches from their pacemaker when the phone is turned ON.
- ▶ Should not carry the phone in a breast pocket.
- ▶ Should use the ear opposite the pacemaker to minimize the potential for interference.

Headset

The Sprint PCS Mobile Headset provides a convenient method of hands-free operation. When the headset is plugged into the headset jack, the phone automatically enters hands-free mode. In this mode, the earpiece and microphone on the phone are disabled to ensure privacy and reduce ambient noise.

Leather Case

The leather case protects your phone while still enabling you to use all the functions. You can also easily remove and replace the battery pack without taking the phone out of the case.

Important safety and warranty information

Understanding How Your Phone Operates

Your Sprint PCS Touchpoint™ phone is basically a radio transmitter and receiver. When it's turned on, it receives and transmits radio frequency (RF) signals. Your phone transmits in the frequency range of 1851.25 MHz to 1908.75 MHz and receives in the frequency range of 1931.25 MHz to 1988.75 MHz. The power level can reach a maximum of 600mW. When your phone is in use, the system handling your call controls the power level.

Following Safety Guidelines

To operate your phone safely and efficiently, you should always follow any special regulations in a given area and turn your phone off in areas where use is forbidden or when it may cause interference or danger.

Using Your Phone While Driving

Talking on the phone while you're driving may divert your attention from the road and is illegal in some states. Remember: SAFETY comes first.

When using your phone in the car:

- ▶ Focus on driving, not talking.
- ▶ Use a Hands-Free Car Kit (optional accessory).

If you must use the phone while driving, please use Speed Dial.

If you have any reason to suspect that interference is taking place, turn your phone OFF immediately.

Hearing Aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference you may want to consult your hearing aid provider.

Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if they are adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information.

Turn your phone OFF in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

FCC Notice

The phone may cause TV or radio interference if used in close proximity to receiving equipment. The FCC can require you to stop using the phone if such interference cannot be eliminated.

Blasting Areas

Turn your phone OFF when in a “blasting area” or in areas posted: “turn off two-way radio.” Obey all signs and instructions. Construction crews often use remote-control RF devices to set off explosives.

Potentially Explosive Atmospheres

Turn off your phone when you are in any area with a potentially explosive atmosphere and obey all signs and instructions. It is rare, but your phone or its accessories could generate sparks. Sparks could cause an explosion or a fire resulting in bodily injury or even death.

Areas with a potentially explosive atmosphere are often, but not always, clearly marked. They include fueling areas such as gas stations; below deck on boats; fuel or chemical transfer or storage facilities; areas where the air contains chemicals or particles such as grain, dust or metal powders; and any other area where you would normally be advised to turn off your vehicle engine.

Do not transport or store flammable gas, liquid or explosives in the compartment of your vehicle that contains your phone or accessories.

Vehicles using liquefied petroleum gas (such as propane or butane) must comply with the National Fire Protection Standard (NFPA-58). For a copy of this standard, contact the National Fire Protection Association, One Batterymarch Park, Quincy, MA 02269, Attn: Publication Sales Division.

Restricting Children's Access To Your Phone

Your phone is not a toy and should not be played with by children. They could hurt themselves and others, damage the phone or make calls that increase your telephone bills.

Cautions

Any changes or modifications to your Sprint PCS Touchpoint™ phone not expressly approved in this document could void your warranty for this equipment and void your authority to operate this equipment. Only use approved batteries, antennas and chargers. The use of any other type will invalidate the warranty.

To prevent fire or shock hazard, do not expose your phone and accessories to rain or moisture. If your phone does get wet, turn the power off immediately and remove the battery pack. If it is inoperable, return it to a Sprint PCS Center or call Sprint PCS Customer Care for service.

Owner's Record

The model number, regulatory number, and serial number are located on a nameplate inside the battery compartment. Record the serial number in the space provided below. This may be helpful if you need to contact us about your phone in the future.

Model: Sprint PCS Touchpoint™

Serial No.:

User Guide Proprietary Notice

CDMA Technology licensed by QUALCOMM Incorporated under one or more of the following Patents:

4,901,307	5,103,459	5,337,338	5,426,392
5,056,109	5,309,474	5,339,046	5,437,055
5,257,283	5,099,204	5,341,456	5,442,322
5,265,119	5,228,054	5,383,219	5,442,627
5,267,262	5,107,225	5,392,287	5,452,473
5,101,501	5,283,536	5,414,728	5,461,639
5,267,261	5,280,472	5,414,796	
5,109,390	5,289,527	5,416,797	

Index

A

AC Adapter: 9

Accessories

Cigarette Lighter Adapter: 49

Desktop Charger: 51

Extended Battery: 50

Hands-Free Car Kit: 49

Headset: 52

Leather Case: 52

Standard Battery: 49

Subscriber Information Manager (SIM-100): 51

Activation: ii

Alarms

Add: 40

Erase: 42

View Schedule: 41

Alpha Entry: 2

American National Standards Institutes (ANSI): 54

Antenna: 7

Auto Answer: 48

B

Backlight/Contrast Setting: 17

Battery

AC Adapter: 9

Charging: 9

Disposal: 51

Installing: 8

Low Battery State: 8

Removing: 8

Blasting Areas: 57



Caller ID: 17

Blocking: 18

Calls

Answering: 12

Call Logs: 26

Missed Call Log: 27

Missed Notification: 27

Pause Feature: 36

Placing a Call: 11

Three-Way: 24

Waiting: 23

Chargers. See AC adapter

D

Dialing

4-Digit Dialing: 34

Correcting Mistakes: 11

Prepend: 36

Redialing Last: 13

Speed Dial: 34

Digital Roam: 24

Display Icons: 6

E

Emergency Calls: 15

Erase All Call Logs: 28

Erase Individual Call Log: 28

Explosive Atmospheres: 57

F

Federal Aviation Administration (FAA): 54

Federal Communications Commission (FCC): 54, 56

G

Greeting: 16

H

Headset: 52
Hearing Aids: 56

I

Institute of Electrical and Electronics Engineers: 54

K

KeyGuard: 47

M

Menu Map: 25

Messages

Page/Text: 22
Storing: 23
Voice: 21

Mute. *See* **Volume:** mute

N

National Council of Radiation Protection and Measurement: 54

National Fire Protection Association: 57

O

Other Medical Devices: 56

P

Pacemakers: 55

Pause Feature: 36

Storing a Number With Pauses: 37

Phone

Activation. *See* **Activation**
Turning Off: 10
Turning On: 10
Unlocking. *See* **Unlocking**
Using While Driving: 53

Phone Book: 28

Add New Entry: 30
Adding Multiple Entries: 32
Editing an Entry: 32
Erase: 46
Find Entry Number: 30
Find Name: 29
Secret Entries: 33

Phone Number

Displaying: 16
Saving: 31

Power

External. *See* **AC adapter**
Power Save Mode: 10

Prepend. *See* **Dialing:** **Prepend**

R

Radio Frequency: 53, 54

Recall: 30

Redialing: 13

Reset Phone: 47

RF Exposure: 54

Ringer Types

Vibrating Ringer: 19

Ringer types: 42

S

Security

Erase Phone Book: 46
Lock: 44
Reset phone: 47
Restricting: 45

Signal Strength: 7

Snooze: 41

Sounds: 42

Ringer Types: 42
Tone Length: 44
Volume: 42

Speed Dial. *See* Dialing: speed dial
Sprint PCS Customer Care: iv, 14
Sprint PCS Directory Assistance: 13
Sprint PCS Operator Services: 13

T

Terms and Conditions: iv
Time and Date: 27

U

Unlocking: iii

V

Vibrating Ringer: 19

Voicemail: 20

Retrieving: 21

Setting Up: 20

Volume

Adjusting: 16

Mute: 12