

Sprint PCS[®]

The clear alternative to cellular.SM

FCC RF EXPOSURE INFORMATION

WARNING! Read this information before using your phone.

In August 1996 the Federal Communications Commission (FCC) of the United States with its action in Report and Order FCC 96-326 adopted an updated safety standard for human exposure to radio frequency electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies. The design of this phone complies with the FCC guidelines and these international standards.

Use only the supplied or an approved antenna. Unauthorized antennas, modifications, or attachments could impair call quality, damage the phone, or result in violation of FCC regulations.

Do not use the phone with a damaged antenna. If a damaged antenna comes into contact with the skin, a minor burn may result. Please contact your local dealer for replacement antenna.

Body-worn & Hand-held Speaker Operation

This device was tested for typical body-worn & mouth (rear speaker) operations with the back of the phone and the antenna kept at a minimum distance of 1.5 cm. from the body.

To maintain compliance with FCC RF exposure requirements:

1. Use only with a 1.5cm spacing between the belt-clip, holster or similar accessories that maintain a 1.5 cm. separation distance between the user's body and the back of the phone, including the antenna, whether extended or retracted. The use of third-party belt-clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

2. Hold the transmitter and antenna at least 1.5cm from your face and speak in a normal voice, with the antenna pointed up and away from the face.

For more information on RF exposure, please visit the FCC website at www.fcc.gov

© 2000 Sprint Spectrum L.P. All rights reserved. No reproduction in whole or in part without prior written approval. Sprint, Sprint PCS, Sprint PCS Phone, Sprint PCS Wireless Web and the diamond logo are trademarks of Sprint Communications Company L.P. All other trademarks are property of their respective owners.

Printed in the U.S.A.

Table of Contents

Welcome to Sprint PCS	1
1. Getting Started with Sprint PCS Service	3
Getting Started with Sprint PCS Service	4
Setting Up Your Voicemail	5
Getting Help	6
Understanding This User Guide	8
2. Getting to Know Your Sprint PCS Phone	9
Highlights	10
Position Location Overview	11
GPS Receiver	11
Enhanced 911 (E911) Wireless Service	11
Front View of Phone	12
Viewing the Display Screen	14
Turning Your Phone ON and OFF	15
Using the KeyGuard	15
Using the Battery	16
3. Understanding Roaming	19
Understanding How Roaming Works	20
Setting Your Phone's Roam Mode	21
Setting an Alert When Roam Charges Apply (Call Guard)	22
Setting the Time and Date in Analog Mode	23
4. Making and Answering Calls	25
Making Calls	26
Using the Speakerphone	26
Answering Calls	27
Missed Call Notification	27

Dialing Options	28	Three-Way Calling	49
In-Call Options	29	Forwarding Your Calls	50
Incoming Call Notification	30	8. Managing Messaging	51
End-of-Call Options	31	Setting up Voicemail	52
Saving a Phone Number	32	Knowing When you Have Messages	52
Finding a Phone Number	33	Message Types	52
Dialing and Saving Phone Numbers with Pauses	33	Sending Sprint PCS Wireless Web Messages	53
4-Digit Dialing	34	New Voicemail Message Alerts	53
Calling Emergency Numbers	34	Retrieving Your Voicemail Messages	54
Dialing from the Internal Phone Book	34	Clearing the Message Icon	54
Using One-Touch/Two-Touch Speed Dialing	35	New Sprint PCS Wireless Web Alerts	55
Displaying Your Phone Number	35	Displaying Sprint PCS Wireless Web Alerts	55
5. Adjusting Volume	37	New Numeric Page or Sprint PCS Wireless Web Messages	55
Changing Ringer Volume	38	Numeric Page and Sprint PCS Wireless Web Message Storage	56
Silencing the Ringer	38	Displaying Numeric Page and Sprint PCS Wireless Web Messages	56
Adjusting Volume During a Conversation	38	Numeric Page Options	57
Muting a Call	39	Sprint PCS Wireless Web Message Options	58
6. Managing Call History	41	Creating Folders for Page and Sprint PCS Wireless Web Messages	59
Viewing a Call Log (Incoming, Outgoing and Missed)	42	Setting or Changing the Maximum Number of Messages for Folders	60
Call Log Options	43	Adding or Changing Filters for Page and Sprint PCS Wireless Web Messages ..	60
Making a Call from a Call Log	43	Renaming Page and Sprint PCS Wireless Web Folders	61
Prepending a Phone Number from a Call Log	44	Deleting Page and Sprint PCS Wireless Web Message Folders	62
Saving a Phone Number from a Call Log	45	Moving Page and Sprint PCS Wireless Web Messages between Folders	62
Erasing Call Logs	46	Extracting Phone Numbers from Sprint PCS Wireless Web Messages	63
7. Using Sprint PCS Service Features	47	Prepending a Phone Number	64
Using Caller ID	48	Erasing All Page or Sprint PCS Wireless Web Messages	64
Responding to Call Waiting	48	9. Using Your Internal Phone Book	65
Disabling Call Waiting	48	Adding a New Internal Phone Book Entry	66

Finding Internal Phone Book Entries	67	Selecting a Tone Length	86
Internal Phone Book Entry Options	69	Changing the Backlight Time Length	86
Adding a Phone Number to an Internal Phone Book Entry	70	Changing the Contrast	86
Adding a Call Alarm from the Internal Phone Book	71	Setting the Alarm Mode	87
Call Alarm Alerts	71	Data/Fax Mode	87
Call Alarm Menu	72	Receiving a Fax	87
Editing an Internal Phone Book Entry	73	Receiving Data	87
Internal Phone Book Entry Details	74	Returning to Voice Mode	88
Editing an Internal Phone Book Entry Phone Number	74	Answering Your Phone with a Hands-Free Car Kit	88
Selecting a Ringer Type for an Entry	76	Selecting the Current Setup	89
Secret Internal Phone Book Entries	76	Copying Your Settings	90
Adding a New Phone Book Folder	77	11. Setting Your Phone's Security	91
Moving Internal Phone Book Entries into Folders	77	Accessing the Security Menu	92
Renaming Phone Book Folders	77	Locking Your Phone	92
Selecting Ringer Types for Phone Book Folders from the Phone Book Menu	78	Unlocking Your Phone	92
Deleting Folders	78	Changing the Lock Code	92
Sorting Internal Phone Book Entries	79	Restricting Calls	93
Dialing Sprint PCS Services	79	Unrestricting Calls	93
MySprint PCS Phone Number	79	Using Special Numbers	94
10. Changing Your Phone's Settings	81	Erasing the Internal Phone Book	94
Changing the Headline	82	Resetting Your Phone	94
Adjusting the Ringer and Key Beep Volume	82	12. Personal Information Management	95
Selecting Voice Prompt Volume	83	Adding an Event to the Scheduler	96
Ringer Types	83	Scheduled Event Alerts	97
Selecting Ringer Types for Voice Calls	84	Scheduled Event Alert Menu	98
Selecting Ringer Types for Messages	84	Adding a Call Alarm to the Scheduler	99
Selecting Ringer Types for Alarms, Data Calls and Fax Calls	85	Viewing Events and Call Alarms	100
Alert Notification	85	Editing Events	101

Editing Call Alarms	102	Using Commands	132
Adding To Do Items	102	Training Commands	132
Viewing To Do Items	103	Command Options	133
Editing To Do Items	104	Voice Dial Options	133
Adding a To Do Item as an Event	105	15. Navigating Through Menus and Entering Text	135
Deleting To Do Items	106	Menu Navigation	136
Viewing and Clearing Scheduler, Call Alarm or To Do List Memory	106	Shortcuts	136
Erasing Old Events or All Events, Call Alarms and To Do Items	107	Working within the Menu Structure	137
Going To Dates	107	Viewing the Menus	138
Viewing the Scheduler Calendar	107	Entering Characters by Tapping the Keypad	142
Event Type Icons	108	Entering Characters Using T9 Text Input	143
Using the Calculator	108	Entering Symbols and Numbers	144
Playing Games	109	16. Selecting Your Accessories	145
13. Experiencing Sprint PCS Wireless Web	111	Accessory Options	146
The Sprint PCS Wireless Web	112	How to Order	147
Sprint PCS Wireless Web Mail	112	17. Knowing Performance and Safety Guidelines	149
The Sprint PCS Wireless Web Browser	113	Getting the Most Out of Your Reception	150
Launching a Sprint PCS Wireless Web Browser Session	113	Maintaining Safe Use of and Access to Your Phone	152
Using the Sprint PCS Wireless Web Browser	115	Caring for the Battery	156
Setting up a Sprint PCS Wireless Web Connection	122	Acknowledging Special Precautions and the FCC Notice	157
Accessing Sprint PCS Wireless Web Updates	125	FCC Notice	157
14. Using the Voice Services of Your Sprint PCS Phone	127	Cautions	157
Using Voice Dialing	128	Body-Worn Operation	158
Recording Memos	128	Specific Absorption Rate (SAR) for Wireless Phones	158
Memo Options	129	FCC Radio Frequency Emission	159
Adding Memos to Your Scheduler	130	Owner's Record	159
Recording Ringers	131	User Guide Proprietary Notice	159
Recordable Ringer Options	131	18. Index	161

Welcome to Sprint PCS

Sprint PCS built the only all-digital, all-PCS nationwide network from the ground up for clearer calls, serving more than 300 major metropolitan areas. We built our network to give you what we believe you really want from a wireless phone: clear sound, private conversations and time-saving features.

And Sprint Personal Communications Services® can do something even more far-reaching – simplify your life. Our advanced technology is designed to grow with your communications needs so that one day, you'll be able to rely entirely on your Sprint PCS Phone™ to stay connected.

This guide will introduce you to our technology and your new Sprint PCS Phone through simple, easy-to-follow instructions. Since you're probably anxious to start using your phone, we encourage you to immediately flip to Section One – Getting Started With Sprint PCS Service. This section provides all the information you need to quickly activate your phone, set up your voicemail and much more. It also contains information on how to contact Sprint PCS should you have questions about service, want to purchase additional products or services, or just check your account balance.

Thank you for choosing Sprint PCS.

Getting Started with Sprint PCS Service

In this Section

- ▶ Activating Your Phone
 - ▶ Setting up Your Voicemail
 - ▶ Getting Help
 - ▶ Understanding This User Guide
-

This section walks you through the step-by-step basics of setting up service to your Sprint PCS Phone™, including activating or unlocking your phone, selecting your Sprint PCS Service Plan, receiving your new Sprint PCS Phone Number and setting up your voicemail.

Once you have completed this section, you're ready to explore the advanced features of your new phone.

**Tip:**

If you can't recall your lock code, try using the last four digits of either your Social Security number or Sprint PCS Phone Number or try 0000. If none of these work, call Sprint PCS Customer Care at 1-888-211-4PCS (4727).

Getting Started with Sprint PCS Service

Determine if Your Phone is Already Activated

If you received your phone in the mail or purchased it at a Sprint PCS Center, it is probably already activated. All you need to do is unlock your phone.

Unlocking Your Phone

Follow these steps to unlock your phone:

1. Press and hold **ⓂEnd** to turn the phone on.
2. Highlight **Unlock** and press **Ok**.
3. Enter your four-digit lock code. For security purposes, the code is not visible as you type.

Activating Your Phone

There are two ways to activate your phone. Follow these steps:

- ▶ The fastest way is to call from your new Sprint PCS Phone™.
1. Fully charge your battery (see instructions on page 17).
 2. Turn on your Sprint PCS Phone.
 3. Press ***** **2** **Ok** to reach a Sprint PCS Customer Advocate. You must be in a Sprint PCS Service Area when making this call.
- ▶ The other way is to call Sprint PCS Customer Care from any phone other than your new Sprint PCS Phone (which isn't yet activated). Call us toll-free at 1-888-715-4588.

During this call you will be guided through the activation process. The call typically takes approximately 30 minutes, but could be longer during peak times. You can streamline the process by reviewing the Clear and Simple Facts brochure and pre-selecting your Sprint PCS Service Plan.

What you Should have Handy When you Call:

- ▶ Your new Sprint PCS Phone
- ▶ The original packaging from your phone
- ▶ Your Social Security number or Tax ID number
- ▶ Your driver's license number
- ▶ Pen and paper to write down your new Sprint PCS Phone Number

Setting Up Your Voicemail

All unanswered calls to your Sprint PCS Phone are automatically transferred to voicemail, even if your phone is off or in use. To avoid missing any important messages, you will want to set up your Sprint PCS voicemail box and personal greeting as soon as your Sprint PCS Phone is activated.

To set up voicemail, follow these steps:

1. Press and hold **1** **Ⓜ**.
2. Follow the system prompts to create your pass code, record your greeting, record your name announcement and choose whether to activate One-Touch Message Access (a feature that lets you press one key to access messages and bypasses the need for you to enter your pass code).

For more information on accessing voicemail messages, see "New Voicemail Message Alerts" on page 53.

Note:

The activation process varies in certain affiliate areas.

Getting Started
1

Note:

The voicemail setup process may vary in certain affiliate areas.

Getting Help

Visit our Web Site

Stop by www.sprintpcs.com to get up-to-date information on Sprint PCS. You can also:

- ▶ Review coverage maps
- ▶ Learn how to use voicemail
- ▶ Access your customer account
- ▶ Purchase accessories
- ▶ Add additional options to your service plan
- ▶ Check out frequently asked questions
- ▶ And much more

Sprint PCS Customer Care

Sprint PCS Customer Advocates are available to assist you 24 hours a day, seven days a week. Simply dial 1-888-211-4PCS (4727) from any phone, or press *** 2 Ok** from your activated Sprint PCS Phone while on the Sprint PCS Nationwide Network.

Once you dial Sprint PCS Customer Care, you can access a number of helpful account services through our automated Customer Care line. By following the voice prompts, you'll be able to learn more about Sprint PCS Products and Services, get Sprint PCS coverage by zip code or request a copy of your invoice.



Tip:

If you need to reach Customer Care while you are off the Sprint PCS Network, dial 1-888-211-4PCS (4727).

Receiving Automated Billing Information

For your convenience, your phone gives you free access to billing information on your Sprint PCS Account. This information includes balance due, payment received, billing cycle and the amount of minutes used since your last billing cycle. Follow these steps to access this information:

1. Press *** 4 Ok**.
2. Follow the voice prompts to receive the information you want.

Sprint PCS Directory Assistance

Sprint PCS Directory Assistance provides a variety of services, including: residential, business and government listings; assistance with local or long-distance calls; movie listings; hotel, restaurant and shopping information and major local event information. There is a per call charge and you will be billed for airtime.

- ▶ Press **4 1 1 Ok**.

Sprint PCS Operator Services

Sprint PCS Operator Services can provide assistance in placing collect calls or calls billed to a local telephone calling card or a third party.

- ▶ Press **0 Ok**.

For more information or to see the latest in products and services, visit us online at www.sprintpcs.com.

Understanding This User Guide

This user guide introduces you to our technology and all the advantages of your new Sprint PCS Phone – through easy-to-follow instructions.

- ▶ Sections breakdown categories of information to progressively take you all the way from learning the basics to using the most advanced phone features.
- ▶ Tips highlight special shortcuts and timely reminders to help you make the most of your new phone.
- ▶ The Index helps you find specific information quickly.

We know that your time is valuable and that's why we've designed this guide to be used in a building block format or in stand-alone sections. You'll get the most out of your phone if you read each section. However, if you'd like to get right to a specific feature, you'll be able to locate the specific section using the colored tabs. Follow the instructions in that section and you'll be ready to use your phone in no time.

2

Getting to Know Your Sprint PCS Phone™

In This Section

- ▶ Your Phone's Highlights and Features
- ▶ Viewing the Display Screen
- ▶ Turning Your Phone ON and OFF
- ▶ Using the Battery

Your Sprint PCS Phone is packed with features that can simplify your life and expand your ability to stay connected to the people and information that are important to you. We know that you're anxious to start using it, so this section will give you a quick introduction to your new phone. Easy-to-follow instructions will guide you through the basics of the most common features of your phone and you'll be on your way to using it in no time.

Don't forget the other chapters in this guide. They're filled with information about the capabilities and benefits of your new Sprint PCS Phone. They include detailed step-by-step instructions to familiarize you with all the features, and how to customize your phone to meet your specific needs.

Highlights

Congratulations on the purchase of your Sprint PCS Touchpoint Phone™ (Model TP3300). This phone is lightweight, easy-to-use, reliable and offers many significant features:

- ▶ Dual-band capability provides access to other PCS CDMA and analog cellular networks where Sprint PCS has implemented roaming agreements (page 20).
- ▶ Sprint PCS Wireless Web™ connection offers wireless modem capabilities for your personal computer in digital mode (page 122).
- ▶ Sprint PCS Wireless Web™ Browser provides access to the wireless Internet in digital mode (page 115).
- ▶ Voice Services let you make calls or perform commands using your voice (pages 128 and 132).
- ▶ You can record voice memos and your own ringers (pages 128 and 131).
- ▶ Built-in Scheduler and Call Alarms remind you of events and important calls (pages 96 and 99).
- ▶ One hundred twenty Internal Phone Book entries store 300 phone numbers (page 66).
- ▶ Ninety-nine Speed Dial entries let you dial phone numbers by pressing one or two digits (page 35).
- ▶ Create folders and filters to store your numeric pages and Sprint PCS Wireless Web messages (page 59).
- ▶ T9® Text Input enables you to quickly type messages (English language only) using one key press per letter (page 143).
- ▶ The speakerphone provides clear audio for both you and your second party (page 26).
- ▶ Real-time clock function alerts you to scheduled events and Call Alarms even when your phone is turned off (pages 97 and 71).

Position Location Overview

The TP3300 enables the network to determine the handset location. The location information can be used for the following purposes:

1. Support enhanced 911 services
2. Provide the user with location information
3. Provide location-based network services

The TP3300's position location feature is only available under the following conditions:

- ▶ The phone is in digital service
- ▶ The carrier's network supports position location features

The TP3300's position location feature is maximized when:

- ▶ The antenna is fully extended
- ▶ The phone is outdoors
- ▶ The phone is not close to tall buildings

GPS Receiver

The TP3300 contains a Global Positioning System (GPS) receiver to assist the network in determining the position of the handset. GPS is a system of satellites orbiting the earth that provide positioning and timing information. The handset GPS receiver collects ranging information from these satellite signals and transmits this information to the network.

Enhanced 911 (E911) Wireless Services

Under the rules of the Federal Communications Commission, wireless companies are required to provide Automatic Location Identification (ALI) information that enables 911 callers to be located within 50 meters for 67% of the calls and 150 meters for 95% of the calls. The TP3300 is an ALI-capable phone designed to support 911 emergency services.

Front View of Phone



1. **Speaker:** Provides high-quality call or memo audio.
2. **Alert Key:** Displays the Alert In-Box.
3. **Volume Keys:** Adjusts the ringer volume in Standby mode, voice volume during a call or speaker volume during speakerphone operation.
4. **WEB:** Launches the Sprint PCS Wireless Web Browser.
5. **CLR:** Lets you clear an entry or back up in the menu.
6. **OK:** Lets you place a call, receive a call or select menu options.
7. **Antenna:** Provides optimum reception for 800 and 1900 MHz frequencies.
8. **Power On Indicator/Dual-Color LED:** Illuminates green when the phone turns on or when you receive incoming calls. Flashes red when you are recording memos or have scheduled alarms or messages.
9. **Headset Jack:** Provides connection for an optional headset.
10. **Voice Services Key:** Lets you use voice dialing, commands or record memos.
11. **Speaker Key:** Activates the speakerphone.
12. **Mouse Key:** Scrolls through menus, provides shortcut access and displays the next or previous message, entry or item.
13. **Power/End:** Lets you power the phone on or off, end calls or return to the main menu.
14. **Microphone:** Automatically adjusts for speakerphone or normal voice calls.



Tip:

The dual-color LED also lets you know when to speak during speakerphone operation (see page 27).

Getting to Know
Your Phone
2

**Tip:**

Display indicators let you know when you're off the Sprint PCS Nationwide Network and whether you're operating in digital or analog cellular mode.

Viewing the Display Screen

This list identifies the symbols you'll see on your display screen.

- ▶ shows your current signal strength. The more lines you have, the stronger your signal.
- ▶ means your phone cannot find a signal.
- ▶ tells you a call is in progress.
- ▶ indicates you are "roaming" off the Sprint PCS Nationwide Network.
- ▶ indicates you are "roaming" off the Sprint PCS Nationwide Network on an analog system.
- ▶ indicates you have voicemail messages waiting. Press **1** to call your voicemail box.
- ▶ indicates you have a numeric page or Sprint PCS Wireless Web message waiting.
- ▶ shows your current battery charge strength. (Icon shown full charged.)

Turning Your Phone ON and OFF

Turning Your Phone ON

- ▶ To turn your phone on, press **ⓈEnd** for approximately two seconds.

Once your phone is ON, it displays "Searching" while your phone looks for a signal. When your phone finds a signal, it automatically enters Standby mode – the phone's idle state. At this point, you're ready to begin making and receiving calls.

If your phone is unable to find a signal after 15 minutes of searching, a Power Save feature is automatically activated. When a signal is found, your phone returns to Standby mode.

Your phone searches for a signal periodically without your intervention. You can also initiate a search for Sprint PCS Service by pressing any key (when your phone is turned ON).

Turning Your Phone OFF

- ▶ Press **ⓈEnd** for two seconds until you see "Powering off" on the display.

Your screen remains blank while your phone is off, unless you're charging the battery.

Using the KeyGuard

The KeyGuard feature helps avoid accidental key presses without blocking incoming calls or messages. Keyguard is disabled when you receive an incoming call and is reactivated when the call is complete.

- ▶ To activate the KeyGuard, highlight **KeyGuard** in the main menu and press **Ok**.
- ▶ To disable KeyGuard, press and hold **Clr**.

**Tip:**

The Power Save feature helps to conserve your battery power when you are in an area where there is no signal.

Note:

Long backlight settings, searching for service, vibrate mode and MiniBrowser use affect the battery's talk and standby times.

**Tip:**

Be sure to charge your phone's battery and watch your indicator to ensure your levels are OK.

Using the Battery

Battery Capacity

Your Sprint PCS Touchpoint Phone™ is equipped with a Lithium Ion (LiIon) battery. It allows you to recharge your battery before it is fully drained. The battery provides approximately 3.75 hours of continuous digital talk time (one hour in analog) or approximately 200 hours of continuous digital standby time (25 hours in analog).

When the battery reaches 5% of its capacity, the battery icon blinks. When there are approximately two minutes of talk time left, the phone sounds an audible alert every 30 seconds and then powers down.

Installing the Battery

Your Sprint PCS Phone comes with a LiIon battery. Follow these steps to install it:

1. Place the battery in the opening at a 45-degree angle with the metal contacts at the top, facing downward.
2. Gently press down on the battery until the latch snaps into place.


Removing the Battery

To remove your battery for charging or for another reason, follow these easy steps:

1. Make sure the power is off so that you don't lose any stored numbers or messages.
2. Press the battery release latch down.
3. Remove the battery from the phone at a 45-degree angle.

Charging the Battery

Your Sprint PCS Phone comes with a rechargeable battery. You should charge the battery as soon as possible so you can begin using your phone.

Keeping track of your battery's charge is important. If your battery level becomes too low, your phone automatically turns off and you'll lose everything you were just working on. For a quick check of your phone's battery level, glance at the battery charge indicator located in the upper-right corner of your phone's display screen. If the battery charge gets too low, the battery icon  blinks and the phone sounds a warning tone.

Always use the Sprint PCS- approved Desktop Charger, Travel Charger or Cigarette Lighter Adapter to charge your battery.

Using the Desktop Charger

When you're ready to charge your battery, it is vital that you use only Sprint PCS-approved desktop chargers and AC adapter chargers. To use the desktop charger provided with your phone:

1. Plug the round end of the AC adapter into the charger holder and the other end into the electrical outlet.
2. Insert the phone (with the battery installed) into the slot. The battery status icon blinks during charging.

It generally takes about 2 hours to fully recharge a completely rundown battery. With the Sprint PCS-approved LiIon battery, it is okay to recharge the battery before it becomes completely run down.

Warning!

Using the wrong battery charger could cause damage to your phone and void the warranty.

Understanding Roaming

In This Section

- ▶ Understanding How Roaming Works
 - ▶ Understanding the Difference Between Roaming and Sprint PCS Calls
 - ▶ Setting Your Phone's Roam Mode
 - ▶ Setting and Using Call Guard
-

Roaming is the ability to make or receive calls while you're off the Sprint PCS Nationwide Network. Your new dual-band Sprint PCS Phone™ works anywhere on the Sprint PCS Nationwide Network and allows you to roam on analog cellular and digital networks where Sprint PCS has implemented roaming agreements.

This section explains how roaming works as well as special features that let you manage your roaming experience.

**Tip:**

Remember, when you're using your phone off the Sprint PCS Network, always dial numbers using 11 digits (1 + area code + number).

Note:

You will pay a higher per-minute rate for roaming calls.

**Tip:**

If you're on a call when you leave the Sprint PCS Network and enter an area where roaming is available (whether CDMA or analog cellular), your call is dropped. If your call is dropped in an area where you think Sprint PCS Service is available, turn your phone off and on again to reconnect to the Sprint PCS Nationwide Network.

Understanding How Roaming Works

Recognizing Icons on the Display Screen

Your phone's display screen always lets you know when you're off the Sprint PCS Network and whether your phone is operating in analog cellular or digital mode. The following chart indicates what you'll see depending on where you're using your phone.

	Roaming Indicator	Analog Indicator
Sprint PCS Nationwide Network		
Other CDMA Networks	R	
Analog Cellular Networks	R	📶

Roaming on Other PCS CDMA Networks

When you're roaming on other PCS CDMA networks, your call quality will be similar to the quality you receive when making calls while on the Sprint PCS Network. You may not be able to access certain calling features, such as Sprint PCS Wireless Web, however, all of your calls are still private and secure.

Roaming on Analog Cellular Networks

When you roam on analog cellular networks, you will experience the same quality provided by analog cellular carriers today. Although certain calling features, such as Sprint PCS Wireless Web, may be unavailable, you can still make and receive calls. You will experience a few differences including:

- ▶ You are more likely to experience static, cross-talk, fade-out and dropped calls.

- ▶ Some calling features that are standard on the Sprint PCS Network are unavailable.
- ▶ There are security and privacy risks (eavesdropping and cloning) that exist with conventional analog cellular services today.
- ▶ Your battery needs recharging sooner when you use your phone for analog cellular roaming.

Setting Your Phone's Roam Mode

Your Sprint PCS Phone allows you to control your ability to roam. By using the **Roaming** menu option, you determine which signals your phone accepts.

Set Mode

Choose from three different settings on your dual-band phone to control your roaming experience:

1. From the main menu, highlight **Roaming** and press **Ok**.
 2. Highlight **Set Mode** and press **Ok**.
 3. To select an option, highlight it and press **Ok**.
- ▶ **Sprint PCS:** This setting allows you to select the Sprint PCS Nationwide Network only and prevents roaming on other networks.
 - ▶ **Automatic:** This setting seeks Sprint PCS Service. When Sprint PCS Service is unavailable, it searches for an alternative system.
 - ▶ **Analog Only:** This setting forces the phone to seek an analog roaming system. The previous setting is restored the next time the phone is turned on.

Note:

Voice and Speed
Dialing are not
available when you
are roaming with the
Call Guard enabled.

Setting an Alert When Roam Charges Apply (Call Guard)

In addition to the roaming icon, Call Guard alerts you when roaming charges apply. The following settings apply to Call Guard.

Call Guard

This feature makes it easy to control when you roam by reminding you when you make or receive a roaming call. It also requires you to take additional steps before placing or answering a roaming call. These additional steps are not required when you make or receive calls while on the Sprint PCS Nationwide Network.

To Turn the Call Guard Feature On or Off:

1. From the main menu, highlight **Roaming** and press **Ok**.
2. Highlight **Call Guard** and press **Ok**.
3. Highlight **On or Off** and press **Ok**.

To Place Roaming Calls with Call Guard On:

1. From the main menu, dial 1 + area code + the seven-digit number. (You can also initiate a call from the Internal Phone Book, Call Logs, Numeric Pages or Sprint PCS Wireless Web messages.)
2. Highlight **Roam Call** and press **Ok**.

To Answer Incoming Roaming Calls with Call Guard On:

- ▶ From the main menu, highlight **Answer** and press **Ok**.

Remember if the Call Guard feature is set to On, you need to take extra steps to make and receive roaming calls even if you have selected the Analog Only setting (see page 21).

Setting the Time and Date in Analog Mode

The real-time clock in your phone is set automatically when you acquire Sprint PCS Service and keeps accurate time even when your phone is turned off. However, if the time has not been set since the battery was installed and you turn your phone on outside a Sprint PCS Service Area, you are prompted to enter the current time and date.

To enter the time and date when the Set Time and Date menu is displayed, press the appropriate keys on your keypad. Fields must be two digits, for example "05:07a 01/01/99." To toggle between AM and PM, highlight AM/PM and press **Ok**.

To select an option, highlight it and press **Ok**.

- ▶ **Set** to enter the time.
- ▶ **AM/PM** to toggle the time between AM and PM.
- ▶ **5 Minutes** to display the options again in five minutes. If your phone acquires Sprint PCS Service before five minutes, the time is automatically set.

Note:

If you do not enter the time and date when prompted in Analog mode, you are not notified of scheduled events or call alarms.

Making and Answering Calls

In This Section

- ▶ Making Calls
 - ▶ Using the Speakerphone
 - ▶ Answering Calls
 - ▶ Dialing Options
 - ▶ In-Call and End-of-Call Options
 - ▶ Using One-Touch/Two-Touch Speed Dialing
-

Your Sprint PCS Phone™ gives you different options for making calls so that you can use the method that works best for you. Once you learn the basics here, the possibilities are endless.

**Tip:**

To redial your last outgoing phone number, highlight Call Logs and press and hold **Ok**.

**Tip:**

When making calls off the Sprint PCS Network, always dial using 11 digits (1 + area code + phone number).

Warning!

Due to higher volume levels, do not place the phone near your ear during speakerphone use.

Making Calls

Your Sprint PCS Phone™ offers many ways to make calls, including using your voice. (See “Using Voice Dialing” on page 128.)

To make a call using your keypad:

1. Make sure your phone is on and that the antenna is fully extended for optimum reception. (When extending the antenna, make sure it is fully extended.)
2. Enter a phone number. (If you make a mistake while dialing, press **Clr** to erase one digit at a time. Or, press and hold **Clr** to erase the entire number.)
3. Press **Ok**. (To make calls when you are roaming and Call Guard is enabled, highlight **Roam Call** and press **Ok**. See “Call Guard” on page 22.)
4. When you're finished, press **End** or highlight **End Call** and press **Ok**.

Using the Speakerphone

The speakerphone feature lets you hear audio through the speaker and talk without holding the phone. For best acoustical performance, the phone should be lying face-up on a hard, flat surface. When the speakerphone is activated, use the volume control keys on the side of the phone to adjust the volume.

To activate the speakerphone during a call:

- ▶ Highlight **Speakerphone On** and press **Ok**.

To turn the speakerphone off:

- ▶ Highlight **Spkrphone Off** and press **Ok**.

Speaking during a conversation

Your phone uses the dual-color LED to let you know when the other party is speaking and cannot hear your voice.

- ▶ The phone's dual-color LED is green when the other party can hear what you are saying.
- ▶ The phone's LED is red when the other party is speaking and he or she cannot hear what you are saying.

Adjusting for background noise

If the LED is red even when the other party is not speaking, the other party may be in an area with excessive background noise. If this happens:

- ▶ Press the down volume control key on the side of the phone until the LED turns green

Answering Calls

1. Make sure your phone is on. If your phone is off, incoming calls go to voicemail.
2. When your phone rings, press **Ok**. (To answer incoming calls when you are roaming and Call Guard is enabled, highlight **Answer** and press **Ok**. See “Call Guard” on page 22.)
3. To disconnect the call, press **End** or highlight **End Call** and press **Ok**.

Missed Call Notification

When an incoming call is not answered, the Missed Call Log is displayed on your screen.

To display the Missed Call entry:

- ▶ Highlight the entry and press **Ok**.

To dial the Missed Call entry's phone number:

- ▶ Highlight the entry and press and hold **Ok**.

Note:

You cannot dial phone numbers identified as No ID, Restricted, Data or Fax calls.

**Tip:**

To speed dial a phone number from the main menu, press and hold the Speed Dial entry number. If the entry number is two digits, enter the first digit, then press and hold the second digit. (This feature will not work when you are roaming and Call Guard is enabled.)

Dialing Options

Dialing options are displayed when you enter numbers in the main menu.

To select an option, highlight it and press **Ok**.

- ▶ **Call** to dial the phone number. (If you are roaming and have the Call Guard feature activated, select **Roam Call**. See “Call Guard” on page 22.)
- ▶ **Save** to save the phone number in your Internal Phone Book. (See “Saving a Phone Number” on page 32.)
- ▶ **Find** to display Internal Phone Book entries that contain the entered numbers. (See “Finding a Phone Number” on page 33.)
- ▶ **Hard Pause** to insert a hard pause. (See “Dialing and Saving Phone Numbers with Pauses” on page 33.)
- ▶ **2-Second Pause** to insert a 2-second pause. (See “Dialing and Saving Phone Numbers with Pauses” on page 33.)
- ▶ **Exit** to return to the main menu.

Some options are displayed as you enter numbers. To select an option, highlight it and press **Ok**.

- ▶ **[An Internal Phone Book Entry]** to display the entry that contains the Speed Dial number assigned to the location you entered. Press and hold **Ok** to dial the Speed Dial number.
- ▶ **4-Digit Dial** to dial the phone number in your Internal Phone Book that ends with the four digits you enter. (See “4-Digit Dialing” on page 34.)

In-Call Options

During a call, your phone displays menu options in addition to the main menu.

To select an option, highlight it and press **Ok**.

- ▶ **End Call** to end the call.
- ▶ **Speakerphone On** or **Spkrphone Off**: Select Speakerphone On to route the phone’s audio through the speaker. You can adjust the speakerphone volume using the volume keys on the side of the phone. Select Spkrphone Off to route the phone’s audio through the earpiece
- ▶ **Mute** or **Unmute**: Select Mute to mute your phone’s microphone. Select Unmute to reactivate the microphone.
- ▶ **Dial 3-Way Call** to call a third party. (See “Three-Way Calling” on page 49.)
- ▶ **Flash** to answer an incoming Call Waiting call or connect a third party during Three-Way Calling.
- ▶ **Send Tones** to send the next set of numbers after a Hard Pause. Send Tones is displayed when you dial a phone number with a Hard Pause in it. (See “Dialing and Saving Phone Numbers With Pauses” on page 33.)

Warning!

Due to higher volume levels, do not place the phone near your ear during speakerphone use.

Note:

You can also mute the ringer by pressing the up or down volume key, Voice Services key or **Clr** .

Incoming Call Notification

Depending on your settings, your Sprint PCS Phone notifies you of incoming calls in the following ways:

- ▶ The phone rings and/or vibrates.
- ▶ The LED flashes green.
- ▶ The backlight illuminates.
- ▶ The screen displays an incoming call message.
- ▶ If the phone number is available, the phone number of the caller is displayed.
- ▶ If the phone number is in your Internal Phone Book, the Phone Book entry's name is displayed.

The following options are also displayed. To select an option, highlight it and press **Ok** .

- ▶ **Answer** to answer the call.
- ▶ **Silent Ringer** to mute the ringer.
- ▶ **Answer & Hold** to answer the call and place the caller on hold. The caller hears a recorded announcement while on hold. Highlight Answer Held Call and press **Ok** to speak to the caller.

End-of-Call Options

After receiving a call from or making a call to a phone number that is not in your Internal Phone Book, the phone number, the duration of the call and the following menu options are displayed.

To select an option, highlight it and press **Ok** .

- ▶ **OK** to return to the main menu. (You can also press **End** or **Clr** .)
- ▶ **Call** to dial the phone number.
- ▶ **Save Phone #** to save the phone number in your Internal Phone Book. (See "Saving a Phone Number" on page 32.)

After receiving a call from or making a call to a phone number that is in your Internal Phone Book, the Phone Book entry name and phone number, the duration of the call and the following menu options are displayed.

To select an option, highlight it and press **Ok** .

- ▶ **OK** to return to the main menu. (You can also press **End** or **Clr** .)
- ▶ **Call** to dial the phone number.
- ▶ **View PB Entry** to display the Internal Phone Book entry. (See "Internal Phone Book Entry Options" on page 69.)

Note:

The End-of-Call options are not displayed for calls identified as No ID or Restricted.

Note:

Phone numbers labeled Fax or Data can only be dialed through a personal computer.

Note:

After you have saved the number, the new Internal Phone Book entry is displayed. (See “Internal Phone Book Entry Options” on page 69.)

Saving a Phone Number

Your Sprint PCS Phone can store up to 120 Internal Phone Book entries. Phone Book entries can store up to a total of 300 phone numbers and the entry's first and last name can contain ten characters. Your phone automatically sorts the Internal Phone Book entries alphabetically.

To save a number from the main menu:

1. Enter a phone number.
2. Highlight **Save** and press **Ok**.
3. Select a label by highlighting **Home**, **Work**, **Mobile**, **Pager**, **Fax**, **Data** or **No Label** and press **Ok**.
4. Enter a first name for the entry, select an existing entry or highlight **Save w/o Name** and press **Ok**. (See “Entering Characters by Tapping the Keypad” on page 142.)
5. Enter a last name for the entry or highlight **Save w/o Name** and press **Ok**.
6. To select an option, highlight it and press **Ok**.
 - ▶ **Done** to create the Phone Book entry.
 - ▶ **Add Speed Dial** to add the phone number to your Speed Dial entries. Press **Ok** again to save the phone number in the first available Speed Dial location. (You can also enter the number of an empty location or highlight it and press **Ok**.)
 - ▶ **Add Voice Dial** to add a Voice Dial tag to the entry. Follow the voice prompts to record a Voice Dial tag for the entry. (See “Using Voice Dialing” on page 128.)
 - ▶ **Add to Folder** to add the entry to an Internal Phone Book folder (if you have created an additional folder). Highlight the folder you want to add the entry to and press **Ok**. (See “Adding a New Phone Book Folder” on page 77.)

Finding a Phone Number

You can search for Internal Phone Book entries with phone numbers that contain a specific string of numbers.

To find a phone number:

1. Enter one or more digits. The more numbers you enter, the more the search narrows.
2. Highlight **Find** and press **Ok**.
3. To display the phone number, highlight the Internal Phone Book entry that contains the number and press **Ok**. To dial the number, highlight the entry and press and hold **Ok**.

Dialing and Saving Phone Numbers with Pauses

You can dial or save phone numbers with pauses for use with automated systems, such as voicemail or credit card billing numbers. If you select a hard pause, the next set of numbers are sent when you press **Ok**. If you select a 2-second pause, your phone automatically sends the next set of numbers after two seconds.

To dial or save a phone number with pauses:

1. Enter the phone number.
2. Highlight **Hard Pause** or **2-Second Pause** and press **Ok**. Hard pauses are displayed as a “P” and 2-second pauses as a “T”.
3. Enter additional numbers.
4. Highlight **Call** or **Save** and press **Ok**.

When dialing a number with a hard pause, highlight **Send Tones** and press **Ok** to send the next set of numbers.

Note:

You can have multiple pauses in a phone number and combine 2-second and hard pauses.

Note:

4-Digit Dialing dials the first number in your Internal Phone Book that matches the four digits.

4-Digit Dialing

Enter four digits to display the 4-Digit Dialing option. If you select 4-Digit Dial, your phone dials the phone number in your Internal Phone Book that ends with the four digits you entered.

To use 4-Digit Dialing:

1. Dial the last four digits of an Internal Phone Book entry's phone number.
2. Highlight **4-Digit Dial** and press **Ok**.

Calling Emergency Numbers

You can place calls to 911, (dial **9** **1** **1** and press **Ok**) even if your phone is locked or your account is restricted. However, you cannot place calls to 911 when the KeyGuard is activated. (See "Emergency Calls" on page 151.)

Dialing from the Internal Phone Book

To dial directly from an Internal Phone Book entry:

1. Press the Mouse Key right. (For additional ways to display entries, see Chapter 9: Using your Internal Phone Book.)
2. Highlight the entry you want to call. (Press the Mouse Key left or right to display the labels of additional phone numbers.)
3. Press and hold **Ok** to dial the entry's default number.

Using One-Touch/Two-Touch Speed Dialing

With this feature, you can dial Speed Dial entries using one key press for locations 1-9 or two key presses for locations 10-99. (To add a Speed Dial entry, see "Adding a New Internal Phone Book Entry" on page 66. To add a Speed Dial location to an existing entry, see "Editing an Internal Phone Book Entry Phone Number" on page 74.)

To use **One-Touch Dialing** for Speed Dial locations 1-9:

- Press and hold the appropriate key for approximately two seconds. The display confirms that the number has been dialed when it shows "Connecting."

To use **Two-Touch Dialing** for Speed Dial locations 10-99:

1. Press the first digit.
 2. Press and hold the second digit for approximately two seconds.
- The display confirms that the number has been dialed when it shows "Connecting."

Displaying Your Phone Number

Just in case you forget your own number, your Sprint PCS Phone can remind you.

To display your phone number:

1. From the main menu, highlight **Phone Book** and press **Ok**.
2. Highlight **My Phone #** and press **Ok**.

Note:

Speed Dialing is not active when you are roaming with Call Guard enabled.

Shortcut:

You can also display your phone number from the main menu by pressing the Mouse Key left.

Adjusting Volume

In This Section

- ▶ Changing Ringer Volume
 - ▶ Silencing the Ringer
 - ▶ Adjusting Volume During a Conversation
 - ▶ Muting a Call
-

With all the things that demand your attention in today's fast paced world, it's important to tune-in to what really matters. Your Sprint PCS Phone™ gives you the ability to control your phone's volume with the touch of a button. Not only can you control what you hear, you can also control what your caller hears.

Changing Ringer Volume

To change the ringer volume, adjust the volume keys on the side of your phone when the phone is in Standby mode.

To change the ringer volume from the main menu:

1. Highlight **Settings** and press **Ok** .
2. Highlight **Sounds** and press **Ok** .
3. Highlight **Volume** and press **Ok** .
4. Highlight **Ringer** and press **Ok** .
5. Highlight a ringer volume or vibrate setting and press **Ok** .

Silencing the Ringer

To silence the ringer on incoming calls:

1. When the phone rings, press the Voice Services key, a volume key or **Clr** .
2. Press **Ok** to answer the call.

Adjusting Volume During a Conversation

Whether you need to hear more or less of a conversation, adjust the volume keys on the side of your phone during a call.

Muting a Call

There are times when it's necessary to mute a call so that your caller does not hear you or certain background noise. To use this function during a call:

1. Highlight **Mute**.
2. Press **Ok** .

► When the phone is muted, "Mute" appears on the display.

To unmute a call:

1. Highlight **Unmute**.
2. Press **Ok** .

Managing Call History

In This Section

- ▶ Viewing a Call Log (Incoming, Outgoing and Missed)
 - ▶ Call Log Options
 - ▶ Making a Call from a Call Log
 - ▶ Saving a Phone Number from a Call Log
 - ▶ Erasing Call Logs
-

The call logs help you manage your time more effectively. They keep track of incoming calls, calls made from your Sprint PCS Phone™ and missed calls. This section guides you through accessing and making the most of your call logs.

Note:

When you receive a call from or dial a phone number in the Missed Log, the entry is removed from the Missed Log. A new entry is stored in either the Outgoing or Incoming Log.

Viewing a Call Log (Incoming, Outgoing and Missed)

You'll find your call logs invaluable. They are a list of the last 10 phone numbers or Internal Phone Book entries for calls you placed, accepted or missed. Call logs make redialing a number fast and easy. They are continually updated as new numbers are added to the beginning of the list and the oldest entries are removed from the bottom of the list.

Each entry contains the call log number, phone number (if it is available) and Internal Phone Book entry name (if the phone number is in your Internal Phone Book). Duplicate calls (same number and type of call) may only appear once on the list.

To view a call log:

1. From the main menu, highlight **Call Logs** and press **Ok**.
2. Highlight **Outgoing Log**, **Incoming Log** or **Missed Log** and press **Ok**.
3. Highlight the Call Log you wish to view and press **Ok**.

Call Log Options

For additional information and options for a particular call, highlight a call log entry and press **Ok**.

To select an option, highlight it and press **Ok**.

- ▶ **Call** to dial the phone number.
- ▶ **View PB Entry** to display the Internal Phone Book entry (if the sender's phone number is in your Phone Book). If the phone number is not in your Internal Phone Book, the **Save Phone #** option is displayed.
- ▶ **Save Phone #** to save the sender's phone number if it is not already in your Internal Phone Book (if applicable). (See "Saving a Phone Number from a Call Log" on page 45.)
- ▶ **Time/Date** to see the time, date and duration of the call.
- ▶ **Prepend** to add numbers to the beginning of the phone number. (See "Prepending a Phone Number from a Call Log" on page 44.)
- ▶ **Erase** to delete the call log entry.
- ▶ **Next** to display the next call log entry.
- ▶ **Previous** to display the previous call log entry.

Making a Call from a Call Log

To place a call from the call logs, follow these steps:

1. From the main menu, highlight **Call Logs** and press **Ok**.
2. Highlight **Outgoing Log**, **Incoming Log** or **Missed Log** and press **Ok**.
3. Scroll through the list and highlight the phone number or Internal Phone Book entry that contains the phone number you want to call.
4. Press and hold **Ok** for two seconds to place the call.

**Tip:**

You can also view the next call log entry by pressing the Mouse Key right or view the previous entry by pressing the Mouse Key left.

Note:

You cannot make calls from the Incoming or Missed Log to entries identified as No ID or Restricted. Calls labeled Data or Fax can only be dialed through a personal computer.

Prepending a Phone Number from a Call Log

If you need to make a call from a call log and you happen to be outside your local area code, you can add the appropriate prefix by following these steps:

1. From the main menu, highlight **Call Logs** and press **Ok**.
2. Highlight **Outgoing Log**, **Incoming Log** or **Missed Log** and press **Ok**.
3. Highlight the entry you wish to call and press **Ok**.
4. Highlight **Prepend** and press **Ok**.
5. Enter the digits or pauses (see below) you want to add to the number. If you want to save the number, select the **Save Phone #** option. If not, the changes only apply to the current call.
6. To select an option, highlight it and press **Ok**.
 - ▶ **Call** to dial the phone number.
 - ▶ **Save Phone #** to store the phone number in your Internal Phone Book.
 - ▶ **Hard Pause** to insert a hard pause. (See “Dialing and Saving Phone Numbers with Pauses” on page 33.)
 - ▶ **2-Second Pause** to insert a 2-second pause. (See “Dialing and Saving Phone Numbers with Pauses” on page 33.)
 - ▶ **Exit** to return to the previous screen.

Saving a Phone Number from a Call Log

Your Sprint PCS Phone can store up to 120 Internal Phone Book entries. Phone Book entries can store up to a total of 300 phone numbers and the entry's first and last name can contain ten characters. Your phone automatically sorts the Internal Phone Book entries alphabetically.

To save a phone number from the Call Log:

1. From the main menu, highlight **Call Logs** and press **Ok**.
2. Highlight **Outgoing Log**, **Incoming Log** or **Missed Log** and press **Ok**.
3. Highlight the phone number you want to save and press **Ok**.
4. Highlight **Save Phone #** and press **Ok**.
5. Select a label by highlighting **Home**, **Work**, **Mobile**, **Pager**, **Fax**, **Data** or **No Label** and press **Ok**.
6. Enter a first name for the entry, select an existing entry or highlight **Save w/o Name** and press **Ok**. (See “Entering Characters by Tapping the Keypad” on page 142.)
7. Enter a last name for the entry or highlight **Save w/o Name** and press **Ok**.
8. To select an option, highlight it and press **Ok**.
 - ▶ **Done** to create the Phone Book entry.
 - ▶ **Add Speed Dial** to add the phone number to your Speed Dial entries. Press **Ok** again to save the phone number in the first available Speed Dial location. (You can also enter the number of an empty location or highlight it and press **Ok**.)

Note:

You cannot save phone numbers already in your Internal Phone Book or calls identified as No ID or Restricted.

Note:

Phone numbers labeled Fax or Data can only be dialed through a personal computer

- ▶ **Add Voice Dial** to add a Voice Dial tag to the entry. Follow the voice prompts to record a Voice Dial tag for the entry. (See “Using Voice Dialing” on page 128.)
- ▶ **Add to Folder** to add the entry to an Internal Phone Book folder (if you have created an additional folder). Highlight the folder you want to add the entry to and press **Ok** . (See “Adding a New Phone Book Folder” on page 77.)

After you have saved the number, the new Internal Phone Book entry is displayed. (See “Internal Phone Book Entry Options” on page 69.)

Erasing Call Logs

To erase individual call log entries, see “Call Log Options” on page 43.

To erase call logs:

1. From the main menu, highlight **Call Logs** and press **Ok** .
2. Highlight **Erase Logs** and press **Ok** .
3. Highlight **Outgoing Log**, **Incoming Log**, **Missed Log** or **All Logs** and press **Ok** .
4. Highlight **Yes** and press **Ok** .

7

Using Sprint PCS Service Features

In This Section

- ▶ Using Caller ID
- ▶ Responding to Call Waiting
- ▶ Three-Way Calling
- ▶ Forwarding Your Calls

Now that you’ve mastered the basics, you can begin to focus on where you want to go. This section guides you step-by-step through the calling features that enhance your Sprint PCS Service. From Caller ID to Call Forwarding, using these features will help you make the most of your Sprint PCS Service.

Note:

You don't have to worry about being interrupted during a Sprint PCS Wireless Web call because Call Waiting and Three-Way Calling are automatically disabled.

Using Caller ID

Caller ID lets you know who's calling by displaying the number of the person calling when your phone rings. If the caller's name and number are already stored in your Internal Phone Book, the corresponding name appears with the number. In the same way, if you call someone who has this feature, your phone number displays on their phone.

To block your phone number from being displayed for a specific outgoing call:

1. Press *** 6 7**.
2. Enter the number you want to call.
3. Press **Ok** (or highlight **Roam Call** and press **Ok**).

To permanently block your number, call Sprint PCS Customer Care.

Responding to Call Waiting

Call Waiting alerts you of incoming calls while you're on a call by sounding two beeps. The display screen informs you that a call is coming in and shows the caller's phone number (if it's available and you are in digital mode).

To respond to an incoming call while you're on a call:

- ▶ Highlight **Flash** and press **Ok**. This puts the first caller on hold and answer the second call.
- ▶ To switch back to the first caller, highlight **Flash** and press **Ok** again.

Disabling Call Waiting

For those calls where you don't want to be interrupted, you can temporarily disable call waiting by pressing *** 7 0** before placing your call. Call Waiting is automatically reactivated once you end the call.

Three-Way Calling

With Three-Way Calling, you can talk to two different people at the same time. When using this feature, the normal airtime rates will be charged for each of the two calls.

1. Enter a number you wish to call and press **Ok**.
2. Once you have established the connection, highlight **Dial 3-Way Call** and press **Ok** to put the first caller on hold.
3. Dial the second number you wish to call and press **Ok**.
4. When you're connected to the second party, highlight **Flash** and press **Ok** once more to begin your three-way call.

If one of the people you called hangs up, you and the remaining caller stay connected. If you initiated the call and are the first to hang up, all three callers are disconnected.

Tip:

You can also begin a Three-Way Call by selecting a phone number from your Internal Phone Book, call logs, numeric pages or Sprint PCS Wireless Web messages. To call the third party, highlight **3-Way Call** and press **Ok**.

Note:

You are charged a per-minute rate during calls you have forwarded.

Forwarding Your Calls

Call Forwarding lets you forward all your incoming calls to another phone number – even when your phone is turned off. You can continue to make calls from your phone with Call Forwarding activated.

To Activate Call Forwarding:

1. Press ***** **7** **2** .
2. Enter the area code and phone number to which your calls should be forwarded.
3. Press **Ok** . You will see a message and hear a tone confirming the activation of Call Forwarding.

To Deactivate Call Forwarding:

1. Press ***** **7** **2** **0** .
2. Press **Ok** . You will see a message and hear a tone to confirm the deactivation.

8

Managing Messaging

In This Section

- ▶ Setting up Voicemail
- ▶ Message Types
- ▶ New Message Alerts
- ▶ Message Options

Your Sprint PCS Phone™ is always working to help you stay connected even when you're unavailable. With three types of messaging, you can depend on your callers being able to notify you of important information. This section steps you through the messaging functions available on your phone including Sprint PCS Wireless Web Messaging.

**Tip:**



When you are roaming off the Sprint PCS Network, you may not receive notification of new voicemail messages. It is recommended that you periodically check your voicemail by dialing 1 + area code + your Sprint PCS Phone Number.

Setting up Voicemail

The first thing you'll want to do after activating your phone is to set up voicemail. See Section 1 page 5 for instructions.

Knowing When you Have Messages

There are several ways your Sprint PCS Phone alerts you of new messages:

- ▶ By displaying a message on the screen.
- ▶ By playing the assigned ringer type.
- ▶ By the LED blinking red.
- ▶ By displaying  at the top of your screen for voicemail messages or  for numeric pages, Sprint PCS Wireless Web messages or Web Alerts.

Message Types

There are four types of messaging functions available on your Sprint PCS Phone. You can receive voicemail, numeric pages and Sprint PCS Wireless Web messages and Web Alerts as long as your phone has enough memory locations to store them.

Voicemail captures calls automatically when you can't answer your phone or it is turned off. The voicemail system sends a notification to your phone letting you know when you have new voice messages waiting in your voicemail box.

Numeric Paging (appears on your phone's menu as **Page/Text** messages) allows a caller to enter a phone number into your voicemail box instead of a voice message. The phone number appears on your phone as a numeric page.

Sprint PCS Wireless Web Messaging (appears on your phone's menu as **Page/Text** messages) displays short alphanumeric messages on your phone's display screen. You must purchase a Sprint PCS Wireless Web Messaging Option to receive text messages on your Sprint PCS Phone.

Sprint PCS Wireless Web Alerts (appears on your phone's display as **Browser Msgs**) lets you know when you receive an alert from a web site. (Service may not be available at the time of printing.)

Sending Sprint PCS Wireless Web Messages

There are three ways to send a Sprint PCS Wireless Web message to a Sprint PCS Phone:

1. Email (yourphonenumber@messaging.sprintpcs.com).
2. Through the Sprint PCS Web site – www.sprintpcs.com. Select the wireless web messaging link.
3. Using a messaging software (TAP 1.5 compatible).

New Voicemail Message Alerts

When your voicemail box is empty and you receive a new voicemail message, your phone alerts you and displays the following options. To select an option, highlight it and press **OK**.

- ▶ **OK** to clear the alert.
- ▶ **Call** to dial your voicemail box.

Note:

Sprint PCS Wireless Web services may not be available in certain Affiliate areas.

**Tip:**

Your phone accepts messages even when it is turned off. However, you are only notified of new messages when your phone is turned on and you are in a Sprint PCS coverage area.

Note:

You are charged for airtime minutes when you are accessing your voicemail.

**Tip:**

You can also access your voicemail box from the main menu by highlighting **Messages** and pressing and holding **Ok**.

Retrieving Your Voicemail Messages

You can review your messages directly from your Sprint PCS Phone or from any other touch-tone phone. To dial from your Sprint PCS Phone, you can either speed dial your voicemail box or use the menu keys.

Using One-Touch Message Access:

1. Press and hold **1** . Follow the system prompts.

Using the Menu Keys on Your Sprint PCS Phone to Access Your Messages:

1. From the main menu, highlight **Messages** and press **Ok**.

2. Highlight **Voicemail** and press **Ok**.

3. Highlight **Call** and press **Ok**.

Using a Phone Other Than Your Sprint PCS Phone to Access Your Messages:

1. Dial your Sprint PCS Phone Number.
2. When your voicemail box answers, press *****.
3. Enter your pass code.

Clearing the Message Icon

Your phone may temporarily continue to display the icon after you have checked your voicemail messages.

To clear the icon from the display screen:

1. From the main menu, highlight **Messages** and press **Ok**.
2. Highlight **Voicemail** and press **Ok**.
3. Highlight **Clear Count** and press **Ok**.
4. Highlight **Yes** and press **Ok**.

New Sprint PCS Wireless Web Alerts

When you receive a new Sprint PCS Wireless Web alert, your phone notifies you and displays the following options. To select an option, highlight it and press **Ok**.

- ▶ **View** accesses the Sprint PCS Wireless Web Inbox and displays the message.
- ▶ **Skip** returns to the previous menu.

Displaying Sprint PCS Wireless Web Alerts

You are notified of new Sprint PCS Wireless Web alerts by the icon.

To display an alert from the main menu:

1. Highlight **Messages** and press **Ok**.
2. Highlight **Browser Msgs** and press **Ok**. The Sprint PCS Wireless Web Inbox is displayed.
3. To display the message, highlight it and press **Ok**. To delete the message, highlight the **Del** softkey and press **Ok**.

New Numeric Page or Sprint PCS Wireless Web Messages

When you receive a new page or Sprint PCS Wireless Web message, your phone alerts you and displays the following options. To select an option, highlight it and press **Ok**.

- ▶ **Read** to display the message.
- ▶ **Call** to dial the phone number of the sender (if applicable).
- ▶ **Exit** to return to the main menu. (You can also press **⓪End** or **⓪Clr**.)

Note:

You are charged for airtime minutes when accessing the Sprint PCS Wireless Web Inbox or wireless Internet sites.

Shortcut:

You can also display the Page/Text All Unread folder from the main menu by pressing the Mouse Key left and pressing **3**.

**Tip:**

You can view the next page or Sprint PCS Wireless Web message in the current folder by pressing the Mouse Key right or view the previous message by pressing the Mouse Key left.

Numeric Page and Sprint PCS Wireless Web Message Storage

Your Sprint PCS Phone can store a combination of up to 100 page or Sprint PCS Wireless Web messages. When the message memory is 75% full, a warning message prompts you to erase messages to obtain additional memory space.

Displaying Numeric Page and Sprint PCS Wireless Web Messages

To display a numeric page or Sprint PCS Wireless Web message from the new Page/Text Message menu, see “New Numeric Page or Sprint PCS Wireless Web Messages” on page 55.

To display a numeric page or Sprint PCS Wireless Web message from the main menu:

1. From the main menu, highlight **Messages** and press **Ok**.
2. Highlight **Page/Text** and press **Ok**.
3. Highlight the folder that contains your message and press **Ok**. An asterisk indicates an unread message and an exclamation point indicates an urgent unread message. Messages are stored in the Inbox folder unless they are filtered or moved to another folder. A copy of all unread messages are stored in the All Unread folder. (See “Creating Folders for Page and Sprint PCS Wireless Web Messages” on page 59.)
4. Messages are displayed in the order they are received. A checkmark before a message means you have read it, an asterisk signifies it is new. Highlight the message you want to display and press **Ok**. Press the Mouse Key down to display additional text.

Numeric Page Options

After you display a numeric page, press **Ok** to display numeric page message options. To select an option, highlight it and press **Ok**.

- ▶ **Call** to dial the phone number in the page message.
- ▶ **View PB Entry** to display the Internal Phone Book entry (if the sender’s phone number is in your Phone Book). If the phone number is not in your Internal Phone Book, the Save Phone # option is displayed.
- ▶ **Save Phone #** to save the phone number if it is not already in your Internal Phone Book (if applicable).
- ▶ **Prepend** to add numbers to the beginning of the the phone number. (See “Prepending a Phone Number from a Page or Sprint PCS Wireless Web Message” on page 64.)
- ▶ **Erase Message** to delete the message.
- ▶ **Read** to display the message again.
- ▶ **Move To** to transfer the message to another folder (if you have created additional folders). (See “Moving Page and Sprint PCS Wireless Web Messages between Folders” on page 62.)
- ▶ **Exit** to return to the main menu. (You can also press **End**.)

Sprint PCS Wireless Web Message Options

After you display a Sprint PCS Wireless Web message, press **Ok** to display Sprint PCS Wireless Web message options. To select an option, highlight it and press **Ok**.

- ▶ **Call** to dial the phone number of the sender (if applicable).
- ▶ **View PB Entry** to display the Internal Phone Book entry (if applicable).
- ▶ **Save Phone #** to save the sender's phone number if it is not already in your Internal Phone Book (if applicable).
- ▶ **Extract #s** to extract phone numbers (if there are numbers contained in the text message). (See "Extracting Phone Numbers from Sprint PCS Wireless Web Messages" on page 63.)
- ▶ **Prepend** to add numbers to the beginning of the the phone number (if applicable). ("Prepending a Phone Number from a Page or Sprint PCS Wireless Web Message" on page 64.)
- ▶ **Erase Message** to delete the message.
- ▶ **Read** to display the message.
- ▶ **Move To** to transfer the message to another folder (if you have created additional folders). (See "Moving Page and Sprint PCS Wireless Web Messages between Folders" on page 62.)
- ▶ **Exit** to return to the main menu. (You can also press **End**.)

Creating Folders for Page and Sprint PCS Wireless Web Messages

You can create up to ten folders to store your page and Sprint PCS Wireless Web messages.

To create a folder:

1. From the main menu, highlight **Messages** and press **Ok**.
 2. Highlight **Page/Text** and press **Ok**.
 3. Highlight **Add New Folder** and press **Ok**.
 4. Enter a name for the folder and press **Ok**.
 5. To select an option, highlight it and press **Ok**.
- ▶ **Done** to create the folder.
 - ▶ **Set Max# Msg** to set a limit for messages stored in the folder. Highlight the number of messages and press **Ok**.
 - ▶ **Filter** to automatically filter incoming messages, based on the text they contain, into the folder. Enter the text you want to filter messages by and press **Ok**.
 - ▶ **Rename Folder** to change the name of the folder. Enter a new name and press **Ok**.
 - ▶ **Delete Folder** to erase the folder. Press **Ok** again to delete the folder.

**Tip:**

You can set a maximum number of messages for a folder to zero to eliminate unwanted emails. Or set the number of messages to one and store only the most recent message (for example, a weather report or stock quote).

Setting or Changing the Maximum Number of Messages for Page and Sprint PCS Wireless Web Folders

Your phone can store up to a total of 100 page or Sprint PCS Wireless Web messages (in one or more folders).

To set or change the maximum number of messages stored in a folder:

1. From the main menu, highlight **Messages** and press **Ok**.
2. Highlight **Page/Text** and press **Ok**.
3. Highlight **Edit Folder** and press **Ok**.
4. Highlight the folder you want to set the maximum number of messages for and press **Ok**. (You cannot edit the Inbox or All Unread folder.)
5. Highlight **Set Max# Msgs** and press **Ok**.
6. Highlight the maximum number of messages you want the folder to contain and press **Ok**. When you receive additional messages, old messages are automatically deleted.

Adding or Changing Filters for Page and Sprint PCS Wireless Web Messages

You can automatically filter your incoming page and Sprint PCS Wireless Web messages into specific folders. Filters search incoming messages and transfer the message into the appropriate folder when the message's text matches a filter. For example, use a phone number to filter numeric pages from work or your last name to filter Sprint PCS Wireless Web messages from your family.

To add or change a filter:

1. From the main menu, highlight **Messages** and press **Ok**.
2. Highlight **Page/Text** and press **Ok**.
3. Highlight **Edit Folder** and press **Ok**.
4. Highlight the folder you want to add or change a filter for and press **Ok**. (You cannot edit the Inbox or All Unread folder.)
5. Highlight **Filter** and press **Ok**.
6. Highlight **Change** and press **Ok**.
7. Enter the text you want to filter messages by and press **Ok**.

Renaming Page and Sprint PCS Wireless Web Folders

To rename a folder:

1. From the main menu, highlight **Messages** and press **Ok**.
2. Highlight **Page/Text** and press **Ok**.
3. Highlight **Edit Folder** and press **Ok**.
4. Highlight the folder you want to rename and press **Ok**. (You cannot rename the Inbox or All Unread folder.)
5. Highlight **Rename Folder** and press **Ok**.
6. Enter a new name for the folder and press **Ok**.

Deleting Page and Sprint PCS Wireless Web Message Folders

To remove a folder, its filter and all its messages:

1. From the main menu, highlight **Messages** and press **Ok** .
2. Highlight **Page/Text** and press **Ok** .
3. Highlight **Edit Folder** and press **Ok** .
4. Highlight the folder you want to delete and press **Ok** .
(You cannot delete the Inbox or All Unread folder.)
5. Highlight **Delete Folder** and press **Ok** .
6. To delete the folder, its filter and all its messages, press **Ok** .

Moving Page and Sprint PCS Wireless Web Messages between Folders

After you display a numeric page or Sprint PCS Wireless Web message, press **Ok** to display message options.

To move the message into another folder:

1. Highlight **Move To** and press **Ok** .
2. Highlight the folder you want to move the message to and press **Ok** .

Extracting Phone Numbers from Sprint PCS Wireless Web Messages

After you display a Sprint PCS Wireless Web message, press **Ok** to display message options.

To extract a phone number contained in the message:

1. Highlight **Extract #s** and press **Ok** . All the phone numbers contained in the message are displayed. (If there are no phone numbers to extract from the message, the option does not display.)
2. Highlight the number you want to extract and press **Ok** .
3. To select an option, highlight it and press **Ok** .
 - ▶ **Call** to dial the phone number.
 - ▶ **Next** to display the next phone number contained in the message (if applicable).
 - ▶ **View PB Entry** to display the Internal Phone Book entry (if the sender's phone number is in your Phone Book). If the phone number is not in your Internal Phone Book, the Save Phone # option is displayed.
 - ▶ **Save Phone #** to save the sender's phone number if it is not already in your Internal Phone Book (if applicable).
 - ▶ **Prepend** to add numbers to the beginning of the the phone number. (See "Prepending a Phone Number from a Page or Sprint PCS Wireless Web Message" on page 64.)

Prepending a Phone Number from a Page or Sprint PCS Wireless Web Message

After you display a numeric page or Sprint PCS Wireless Web message, press **Ok** to display message options.

If you happen to be outside your local area code and need to add a prefix to a phone number:

1. Highlight **Prepend** and press **Ok**.
2. Enter the digits or pauses (see below) you want to add to the number. If you want to save the number, select the **Save Phone #** option. If not, the changes only apply to the current call.
3. To select an option, highlight it and press **Ok**.
 - ▶ **Call** to dial the phone number.
 - ▶ **Save Phone #** to store the phone number in your Internal Phone Book.
 - ▶ **Hard Pause** to insert a hard pause. (See “Dialing and Saving Phone Numbers with Pauses” on page 33.)
 - ▶ **2-Second Pause** to insert a 2-second pause. (See “Dialing and Saving Phone Numbers with Pauses” on page 33.)
 - ▶ **Exit** to return to the previous screen.

Erasing All Page or Sprint PCS Wireless Web Messages

To erase all page Sprint PCS Wireless Web messages:

1. From the main menu, highlight **Messages** and press **Ok**.
2. Highlight **Page/Text** and press **Ok**.
3. Highlight **Erase All Msgs** and press **Ok**.
4. Highlight **Yes** and press **Ok**.

9

Using Your Internal Phone Book

In This Section

- ▶ Adding New Internal Phone Book Entries
- ▶ Finding Internal Phone Book Entries
- ▶ Internal Phone Book Entry Options
- ▶ Adding Call Alarms from the Internal Phone Book
- ▶ Selecting Ringer Types
- ▶ Dialing Sprint PCS Services

Now you know the basics and you’ve learned the advanced features that can help make it easier to stay in touch with people and information. This section helps you make the most of your contacts and use your time more effectively when you’re trying to connect with the important people in your life.

Adding a New Internal Phone Book Entry

Your Sprint PCS Phone can store up to 120 Internal Phone Book entries. Phone Book entries can store up to a total of 300 phone numbers and the entry's first and last name can contain ten characters. Your phone automatically sorts the Internal Phone Book entries alphabetically.

To add a new entry:

1. From the main menu, highlight **Phone Book** and press **Ok**.
 2. Highlight **Add New Entry** and press **Ok**.
 3. Enter a first name for the entry or highlight **Save w/o Name** and press **Ok**. (See "Entering Characters by Tapping the Keypad" on page 142.)
 4. Enter a last name for the entry or highlight **Save w/o Name** and press **Ok**.
 5. Enter a phone number and press **Ok**.
 6. Select a label by highlighting **Home**, **Work**, **Mobile**, **Pager**, **Fax**, **Data** or **No Label** and press **Ok**.
 7. To select an option, highlight it and press **Ok**.
- ▶ **Done** to create the Phone Book entry.
 - ▶ **Add Speed Dial** to add the phone number to your Speed Dial entries. Press **Ok** again to save the phone number in the first available Speed Dial location. (You can also enter the number of an empty location or highlight it and press **Ok**.)

- ▶ **Add Voice Dial** to add a Voice Dial tag to the entry. Follow the voice prompts to record a Voice Dial tag for the entry. (See "Using Voice Dialing" on page 128.)
- ▶ **Add to Folder** to add the entry to an Internal Phone Book folder (if you have created an additional folder). Highlight the folder you want to add the entry to and press **Ok**. (See "Adding a New Phone Book Folder" on page 77.)

After you have saved the number, the new Internal Phone Book entry is displayed. (See "Internal Phone Book Entry Options" on page 69.)

Finding Internal Phone Book Entries

There are several ways to display your Internal Phone Book entries. Follow the steps outlined in the sections below to display entries from the Internal Phone Book menu.

Finding Names

You can review all the entries stored in your Internal Phone Book or find an entry quickly by following these simple steps:

1. Highlight **Phone Book** and press **Ok**.
2. Highlight **Find Name** and press **Ok**.
3. If you have more than one folder (see "Adding a New Phone Book Folder" on page 77), highlight the folder you want to search and press **Ok**. Internal Phone Book entries are listed in alphabetical order by the entry's first or last name. (See "Sorting Internal Phone Book Entries" on page 79).
4. Scroll through the folder's Internal Phone Book entries with the Mouse Key (up/down). To find a specific entry, enter the first letter of the name or part of a name (such as "ave" for "Dave"). The more letters you enter, the more the search narrows.



Tip:

In Standby mode, you can also access the Find Name feature for All Entries by pressing the Mouse Key right.

Note:

All Internal Phone Book entries can be accessed from the All Entries folder.

**Tip:**

When you highlight an Internal Phone Book entry in the Find Name menu, you can press the Mouse Key left or right to display the labels of additional phone numbers.

Note:

You can also find a Speed Dial entry using the Find feature (see “Finding a Phone Number” on page 33.)

5. To display an entry, highlight it and press **Ok**.
6. To dial the default number you selected for the entry, press and hold **Ok**. To display additional Internal Phone Book entries, press the Mouse Key left or right.

Finding Speed Dial Entries

To find a number by its Speed Dial memory location:

1. Highlight **Phone Book** and press **Ok**.
2. Highlight **Find Speed Dial** and press **Ok**.
3. Speed Dial entries are displayed in numerical order. Scroll through the Internal Phone Book entries that contain the Speed Dial numbers with the Mouse Key (up/down). You can also enter the number of a Speed Dial location.
4. To speed dial a number, highlight it and press and hold **Ok**.
5. To display the Internal Phone Book entry, highlight the entry and press **Ok**.

Internal Phone Book Entry Options

When you display an Internal Phone Book entry, the following options are displayed. To select an option, highlight it and press **Ok**.

- ▶ **Call** to dial the phone number. (If you are roaming and have the Call Guard feature activated, select **Roam Call**. See “Call Guard” on page 22.)
- ▶ **[Additional Phone Numbers]** to display alternate phone numbers (if the entry has more than one phone number). Press and hold **Ok** to dial the phone number.
- ▶ **Add Phone #** to add a phone number to the entry. (See “Adding a Phone Number to an Internal Phone Book Entry” on page 70.)
- ▶ **Edit Entry** to change the entry’s ringer type, default number, folder, details or Secret mode. (See “Editing an Internal Phone Book Entry” on page 73.)
- ▶ **Edit Number** to change the entry’s phone number, label, Speed Dial location and Voice Dial tag. (See “Editing an Internal Phone Book Entry Phone Number” on page 74.)
- ▶ **Call Alarm** to schedule a call alarm. (See “Adding a Call Alarm from the Internal Phone Book” on page 71.)
- ▶ **View Details** to display the entry’s street address and email address. (To enter details, see “Editing an Internal Phone Book Entry” on page 73.)
- ▶ **Erase Entry** to delete the entry. To delete the entry, press **Ok** again.
- ▶ **Next** to display the next entry.
- ▶ **Previous** to display the previous entry.

**Tip:**

You can also view the next entry by pressing the Mouse Key right or view the previous entry by pressing the Mouse Key left.

Note:

Phone numbers labeled Fax or Data can only be dialed through a personal computer.


Adding a Phone Number to an Internal Phone Book Entry

To add a phone number to an entry:

1. Display an Internal Phone Book entry.
2. Highlight **Add Phone #** and press **Ok**.
3. Enter the phone number and press **Ok**.
4. Select a label by highlighting **Home, Work, Mobile, Pager, Fax, Data** or **No Label** and press **Ok**.
5. To select an option, highlight it and press **Ok**.
 - ▶ **Done** to create the Phone Book entry.
 - ▶ **Add Speed Dial** to add the phone number to your Speed Dial entries. Press **Ok** again to save the phone number in the first available Speed Dial location. (You can also enter the number of an empty location or highlight it and press **Ok**.)
 - ▶ **Add Voice Dial** to add a Voice Dial tag to the entry. Follow the voice prompts to record a Voice Dial tag for the entry. (See “Using Voice Dialing” on page 128.)
 - ▶ **Add to Folder** to add the entry to an Internal Phone Book folder (if you have created an additional folder). Highlight the folder you want to add the entry to and press **Ok**. (See “Adding a New Phone Book Folder” on page 77.)

Adding a Call Alarm from the Internal Phone Book

To add a call alarm from the Internal Phone Book:

1. Display an Internal Phone Book entry.
2. Highlight **Call Alarm** and press **Ok**.
3. Enter the time and date using your keypad. (Fields must be two digits, for example “07:46a 04/01/00.”) To toggle between AM and PM, highlight **AM/PM** and press **Ok**.
4. To schedule the call alarm, highlight **Done** and press **Ok**. To repeat the alarm, highlight **Set Repeating** and press **Ok**.
 - ▶ **Set Repeating** To repeat the call alarm, highlight **Daily, Weekly, Monthly** or **Yearly** and press **Ok**. The  icon is displayed next to Time/Date to indicate that the alarm is repeating. To schedule the call alarm, highlight **Done** and press **Ok**.

After you have scheduled the call alarm, the day the alarm is scheduled for is displayed. (See “Viewing Events and Call Alarms” on page 100.)

Call Alarm Alerts

There are several ways your Sprint PCS Phone alerts you of call alarms:

- ▶ By playing the assigned ringer type.
- ▶ By illuminating the backlight.
- ▶ By flashing the LED red.
- ▶ By displaying the Internal Phone Book entry name or phone number, the time and date of the alarm and the call alarm menu.

Note:

You can also add a call alarm from the Scheduler menu (see “Adding a Call Alarm to the Scheduler” on page 99.)

Call Alarm Menu

When your phone is turned on and you have a call alarm scheduled, your phone alerts you and displays the following options. To select an option, highlight it and press **Ok**.

- ▶ **OK** to display the **Call** or **Roam Call** option. To dial the number, press **Ok** again.
- ▶ **Snooze** to repeat the alarm in ten minutes.
- ▶ **Erase** to delete the alarm. If it is a repeating alarm, press **Ok** again to erase the alarm and all repeating occurrences.
- ▶ **Edit** to reschedule the time, date and frequency of the alarm.
- ▶ **Exit** to erase the alarm and return to the main menu.

If you have the Alarm mode enabled (see "Setting the Alarm Mode" on page 87), your phone will alert you to call alarms even when it is turned off. When the call alarm is scheduled, the following options are displayed. To select an option, highlight it and press **Ok**.

- ▶ **OK** to acknowledge the alarm.
- ▶ **Snooze** to repeat the alarm in ten minutes.
- ▶ **Save & Pwr ON** to save the alarm and turn your phone on.
- ▶ **Save & Pwr OFF** to save the alarm and turn your phone off.
- ▶ **Erase & Pwr OFF** to erase the alarm (and all repeating instances) and turn your phone off.

Editing an Internal Phone Book Entry

To make changes to an entry:

1. Display an Internal Phone Book entry.
2. Highlight **Edit Entry** and press **Ok**.

To select an option, highlight it and press **Ok**.

- ▶ **Set Default #** to save a phone number as the default number. Highlight the number and press **Ok**.
- ▶ **Folder** to move the entry to another folder. Highlight the folder you want to move the entry to and press **Ok**. (See "Adding a New Phone Book Folder" on page 77.)
- ▶ **Ringer Type** to assign an individual ringer type to the entry. (See "Selecting a Ringer Type for an Entry" on page 76.)
- ▶ **First Name** to change the entry's first name. Enter the new name and press **Ok**. (See "Entering Characters by Tapping the Keypad" on page 142.)
- ▶ **Last Name** to change the entry's last name. Enter the new name and press **Ok**. (See "Entering Characters by Tapping the Keypad" on page 142.)
- ▶ **Address** to save a street address for the entry. Enter the appropriate information and press **Ok**.
- ▶ **Email** to save an email address for the entry. Highlight an email entry location and press **Ok**. Then, enter an email address and press **Ok**.
- ▶ **Secret Mode** to select the entry's Secret mode. (See "Secret Internal Phone Book Entries" on page 76.)

Note:

If you edit an Internal Phone Book entry's phone number, the Speed Dial location and Voice Dial tag are removed.

Internal Phone Book Entry Details

To view the street and email address for an entry:

1. Display an Internal Phone Book entry.
2. Highlight **View Details** and press **Ok**.

(To enter a street and email address for an entry, see “Editing an Internal Phone Book Entry” on page 73.)

Editing an Internal Phone Book Entry Phone Number

To make changes to a phone number:

1. Display an Internal Phone Book entry.
2. Highlight **Edit Number** and press **Ok**.
3. If you have more than one phone number, highlight the number you want to edit and press **Ok**.

To select an option, highlight it and press **Ok**.

- ▶ **Edit Number** to change a phone number or label. Enter a new number or save the current number and press **Ok**. Highlight a label and press **Ok**.
- ▶ **Add/Edit Speed Dial** to add or change a Speed Dial location. Press **Ok** again to save the phone number in the first available Speed Dial location. (You can also enter the number of an empty location or highlight it and press **Ok**.)

- ▶ **Add/Edit Voice Dial** to add or edit a Voice Dial entry. To add a new Voice Dial Tag, highlight **Add Voice Dial** and press **Ok**. Then, follow the voice prompts to record a Voice Dial. To hear an existing Voice Dial, highlight **Play Voice Dial** and press **Ok**. To replace an existing Voice Dial, highlight **Change** and press **Ok**. Then, follow the voice prompts to record a new Voice Dial. To delete an existing Voice Dial Tag, highlight **Erase** and press **Ok**.
- ▶ **Delete Speed Dial** to erase a phone number from a Speed Dial location (if you have a Speed Dial location assigned). Press **Ok** again to remove the number from your Speed Dial entries.
- ▶ **Delete Voice Dial** to erase a phone number from a Voice Dial location (if you have a Voice Dial location assigned). Press **Ok** again to remove the number from your Voice Dial.
- ▶ **Erase Number** to erase the number. Press **Ok** again to delete the number.

**Tip:**

If you can't recall your lock code, try using the last four digits of either your Social Security number or Sprint PCS Phone Number or try 0000. If none of these work, call Sprint PCS Customer Care at 1-888-211-4PCS (4727).

Selecting a Ringer Type for an Entry

You can assign a ringer type to an Internal Phone Book entry so you can identify the caller by the ringer type. (See “Ringer Types” on page 83.)

To select a ringer type for an entry:

1. Display an Internal Phone Book entry.
2. Highlight **Edit Entry** and press **Ok**.
3. Highlight **Ringer Type** and press **Ok**.
4. Highlight a ringer type and press **Ok**. (You will hear a preview of the ringer type when you highlight it.)

Secret Internal Phone Book Entries

You can hide an entry's phone number(s) and require your lock code to change it by making the entry secret. The entry name is still displayed, but the number is replaced by “(Secret).”

To make an entry secret:

1. Display an Internal Phone Book entry.
2. Highlight **Edit Entry** and press **Ok**.
3. Highlight **Secret Mode** and press **Ok**.
4. Highlight **Yes** and press **Ok**.

To make an entry not secret:

1. Display an Internal Phone Book entry.
2. Highlight **Edit Entry** and press **Ok**.
3. Enter your lock code.
4. Highlight **Secret Mode** and press **Ok**.
5. Highlight **No** and press **Ok**.

Adding a New Phone Book Folder

You can organize Internal Phone Book entries by storing them in separate folders. Your phone can store up to six customized folders. A copy of all entries are stored in and accessible from the All Entries folder.

To create a new folder:

1. From the main menu, highlight **Phone Book** and press **Ok**.
2. Highlight **Add New Folder** and press **Ok**.
3. Enter the name of the folder and press **Ok**.

Moving Internal Phone Book Entries into Folders

You can organize Internal Phone Book entries by storing them in separate folders. A copy of all entries are stored in and accessible from the All Entries folder.

To move an entry into a different folder:

1. Display an Internal Phone Book entry.
2. Highlight **Edit Entry** and press **Ok**.
3. Highlight **Folder** and press **Ok**.
4. Highlight the folder you want to move the entry to and press **Ok**.

Renaming Phone Book Folders

To rename a folder:

1. From the main menu, highlight **Phone Book** and press **Ok**.
2. Highlight **Edit Folder** and press **Ok**.
3. Highlight the folder you want to rename and press **Ok**. (You cannot edit the All Entries folder.)
4. Highlight **Rename Folder** and press **Ok**.
5. Edit the folder's name and press **Ok**.

**Tip:**

You can use a folder's Ringer Type to help screen calls. For example, when you're at home select None for your Work folder.

Selecting Ringer Types for Phone Book Folders from the Phone Book Menu

To select a ringer type for an incoming call from a folder's Internal Phone Book entry:

1. From the main menu, highlight **Phone Book** and press **Ok**.
2. Highlight **Edit Folder** and press **Ok**.
3. Highlight the folder you want to select a ringer type for and press **Ok**. (You cannot edit the All Entries folder.)
4. Highlight **Ringer Type** and press **Ok**.
5. Highlight a ringer type and press **Ok**.

You can also assign a ringer type to a Phone Book folder from the Settings menu (see "Selecting Ringer Types for Voice Calls" on page 84).

Deleting Folders

To delete a folder:

1. From the main menu, highlight **Phone Book** and press **Ok**.
2. Highlight **Edit Folder** and press **Ok**.
3. Highlight the folder you want to delete and press **Ok**. (You cannot edit the All Entries folder.)
4. Highlight **Delete Folder** and press **Ok**.
5. To delete the folder and move the folder's entries into the All Entries folder, highlight **Yes** and press **Ok**.

Sorting Internal Phone Book Entries

To display entries alphabetically by their first or last name:

1. From the main menu, highlight **Phone Book** and press **Ok**.
2. Highlight **Sort Name** and press **Ok**.
3. Select **First-Last** or **Last-First** and press **Ok**.

Dialing Sprint PCS Services

You must be in digital mode to access Sprint PCS Services.

To dial a service:

1. From the main menu, highlight **Phone Book** and press **Ok**.
2. Highlight **Services** and press **Ok**.
3. Highlight **Account Info**, **CustomerCare**, **Dir Assist**, **Prepaid** or **Road Assist** and press **Ok**.
4. Highlight **Call** and press **Ok**.

My Sprint PCS Phone Number

To display your phone number:

1. From the main menu, highlight **Phone Book** and press **Ok**.
2. Highlight **My Phone #** and press **Ok**.

Changing Your Phone's Settings

In This Section

- ▶ Changing the Greeting
 - ▶ Adjusting the Volume
 - ▶ Ringer Types
 - ▶ Selecting Ringer Types
 - ▶ Changing the Contrast and Backlight Setting
 - ▶ Data/Fax Mode
-

This section describes how you can change your phone's settings to best suit your requirements. Take a few moments to review these options and adjust or add settings that are right for you.

**Tip:**

You can use the volume control keys on the side of the phone to adjust the ringer volume in Standby mode or the voice or speakerphone volume during a call.

Note:

When the phone is in Vibrate Mode and attached to an accessory (Desktop Charger, Hands-Free Car Kit, etc.), it uses the Standard ringer type to alert you of incoming calls, alarms or messages.

Changing the Headline

Your headline is also the name for the Current Setup (see “Selecting the Current Setup” on page 89). The headline can be up to 12 characters and is displayed on the first line of your phone’s display screen in Standby mode.

To change your headline:

1. From the main menu, highlight **Settings** and press **Ok**.
2. Highlight **Headline** and press **Ok**.
3. Highlight **Change** and press **Ok**.
4. Edit the name of the headline and press **Ok**. The headline (and Current Setup) is displayed.

Adjusting the Ringer and Key Beep Volume

To adjust the ringer or key beep volume:

1. From the main menu, highlight **Settings** and press **Ok**.
2. Highlight **Sounds** and press **Ok**.
3. Highlight **Volume** and press **Ok**.
4. Highlight **Ringer** or **Key Beep** and press **Ok**.
5. Highlight **Lowest**, **Low**, **Medium**, **High**, **Highest**, **Highest & Vibr**, **Vibrate** or **Off** for Ringer or **High**, **Medium**, **Low** or **Off** for Key Beep and press **Ok**.

If you set the key beep volume to Off, some alerts, such as Service Alerts, low-battery warning and the start-up sound, do not sound.

Selecting Voice Prompt Volume

To play voice prompts through the speakerphone or your phone’s earpiece:

1. From the main menu, highlight **Settings** and press **Ok**.
2. Highlight **Sounds** and press **Ok**.
3. Highlight **Volume** and press **Ok**.
4. Highlight **Voice Prompt** and press **Ok**.
5. Highlight **Normal** (for speakerphone) or **Private** (for earpiece) and press **Ok**.

Ringer Types

Ringer types help you identify incoming calls and messages. You can assign ringer types to individual Internal Phone Book entries, folders, types of calls and types of messages.

- ▶ **Preprogrammed Ringers** include a variety of standard ringer types and familiar music.
- ▶ **Vibrating Ringer** alerts you to calls or messages without disturbing others.
- ▶ **Custom Ringers** can be downloaded from web sites.
- ▶ **Recordable Ringers** are composed of your voice or sounds you record. (See “Recording Ringers” on page 131.)
- ▶ **Voice Ringer** announces when you have a new call, message or alarm scheduled. The voice ringer also identifies callers with your Voice Dial tag if selected for Caller ID calls.

**Tip:**

You can also assign ringer types to Internal Phone Book entries to identify individual callers. (See "Selecting a Ringer Type for an Entry" on page 76.)

Note:

If you select Distinctive for the Roaming option, the ringer type is used for all incoming roaming calls and overrides ringer types assigned to Internal Phone Book entries and folders.

Selecting Ringer Types for Voice Calls

To select a ringer type for voice calls so you can tell what kind of call is coming in by the ringer:

1. From the main menu, highlight **Settings** and press **Ok**.
2. Highlight **Sounds** and press **Ok**.
3. Highlight **Ringer Type** and press **Ok**.
4. Highlight **Voice Calls** and press **Ok**.
5. Highlight **With Caller ID, Phonebook Fldr, No Caller ID or Roaming** and press **Ok**. If you select **Phonebook Fldr**, highlight the folder and press **Ok**.
6. Highlight a ringer type and press **Ok**. You will hear a preview of the ringer type when you highlight it.

Selecting Ringer Types for Messages

To select a ringer type for messages:

1. From the main menu, highlight **Settings** and press **Ok**.
2. Highlight **Sounds** and press **Ok**.
3. Highlight **Ringer Type** and press **Ok**.
4. Highlight **Messages** and press **Ok**.
5. Highlight **Voicemail, Page/Text or Wireless Web** and press **Ok**.
6. Highlight a ringer type and press **Ok**. You will hear a preview of the ringer type when you highlight it.

Selecting Ringer Types for Alarms, Data Calls and Fax Calls

To select a ringer type for alarms, data calls and fax calls:

1. From the main menu, highlight **Settings** and press **Ok**.
2. Highlight **Sounds** and press **Ok**.
3. Highlight **Ringer Type** and press **Ok**.
4. Highlight **Messages** and press **Ok**.
5. Highlight **Alarms, Data Calls or Fax Calls** and press **Ok**.
6. Highlight a ringer type and press **Ok**. You will hear a preview of the ringer type when you highlight it.

Alert Notification

To enable or disable alert sounds:

1. From the main menu, highlight **Settings** and press **Ok**.
2. Highlight **Sounds** and press **Ok**.
3. Highlight **Alerts** and press **Ok**.
4. Select a feature by highlighting it and pressing **Ok**.
 - ▶ **Service** to alert you when you exit or enter PCS CDMA or cellular coverage.
 - ▶ **Messages** to alert you when you receive a voicemail, page, Sprint PCS Wireless Web message or Web Alerts.
 - ▶ **Minute Minder** to hear a beep once a minute when you are on a call. (The beep is not audible to the other party.)
5. Highlight **On or Off** and press **Ok**.

Shortcut:

You can also set the Backlight time from the main menu by pressing the Mouse Key left and pressing **6**.

Note:

Long backlight settings affect the battery's talk and standby times.

Selecting a Tone Length

Longer tone lengths may be better for tone recognition when dialing voicemail or other automated systems.

To select a tone length:

1. From the main menu, highlight **Settings** and press **Ok**.
2. Highlight **Sounds** and press **Ok**.
3. Highlight **Tone Length** and press **Ok**.
4. Highlight **Short** or **Long** and press **Ok**.

Changing the Backlight Time Length

The backlight setting lets you select how long the display screen and keypad are backlit after any key press is made.

To change the backlight setting:

1. From the main menu, highlight **Settings** and press **Ok**.
2. Highlight **Display** and press **Ok**.
3. Highlight **Backlight** and press **Ok**.
4. Highlight **8 Seconds**, **15 Seconds**, **30 Seconds**, **Off** or **Always On** and press **Ok**.

Changing the Contrast

To adjust the contrast on the phone's display:

1. From the main menu, highlight **Settings** and press **Ok**.
2. Highlight **Display** and press **Ok**.
3. Highlight **Contrast** and press **Ok**.
4. Highlight **Lowest**, **Low**, **Medium**, **High** or **Highest** and press **Ok**. You will see a preview of the Contrast setting when you highlight it.

Setting the Alarm Mode

To enable or disable call alarms and scheduled event alarms when your phone is turned off:

1. From the main menu, highlight **Settings** and press **Ok**.
2. Highlight **Alarm Mode** and press **Ok**.
3. Highlight **Disable** or **Enable** and press **Ok**.

Data/Fax Mode

The Sprint PCS Wireless Web™ Connection Kit (purchased separately) lets you link your laptop PC to your Sprint PCS Phone so you can send and receive data and faxes.

Receiving a Fax

To receive a fax with your phone:

1. From the main menu, highlight **Settings** and press **Ok**.
2. Highlight **Data/Fax (In)** and press **Ok**. (The data cable must be connected to your phone to view Data/Fax menu options.)
3. Highlight **Incoming Fax** and press **Ok**.

Receiving Data

To receive data with your phone:

1. From the main menu, highlight **Settings** and press **Ok**.
2. Highlight **Data/Fax (In)** and press **Ok**. (The data cable must be connected to your phone to view Data/Fax menu options.)
3. Highlight **Incoming Data** and press **Ok**.

Note:

When your phone is in Data/Fax mode, you cannot make or receive voice calls.

Note:

The phone must be on a digital network to send or receive data and faxes.

Note:

The phone always powers up in Standby mode, even if it was powered down in Data/Fax mode. The phone also returns to Standby mode if the data cable is disconnected.

Returning to Voice Mode

To return to Standby mode at the end of a data or fax transmission, highlight **Exit Data Mode** or **Exit Fax Mode** and press **Ok**.

When you are in Data/Fax mode, you can also return to Standby mode from the main menu.

1. Highlight **Settings** and press **Ok**.
2. Highlight **Data/Fax (In)** and press **Ok**.
3. Highlight **Disable** and press **Ok**.

Answering Your Phone with a Hands-Free Car Kit

You can select different answering options when your phone is connected to the Installed or Portable Sprint PCS Hands-Free Car Kit.

To answer calls automatically or by pressing any key:

1. From the main menu, highlight **Settings** and press **Ok**.
2. Highlight **Car Use** and press **Ok**.
3. Select an option by highlighting it and pressing **Ok**.
 - ▶ **Any Key Answer** to answer calls by pressing any key (not including **End**, the Mouse Key, Voice Services key or volume control keys).
 - ▶ **Auto Answer** to automatically answer incoming calls after five seconds.
4. Highlight **On** and press **Ok**.

To disable an option, follow steps 1-3 and select **Off**.

Selecting the Current Setup

Your settings for headline, sounds, display, alarm mode and car use can be grouped together and saved as a Setup. (You can change the individual settings at any time.) That way you can use different settings for your phone when you're at home, work, on vacation or any place you prefer to use a customized group of settings. The name of a Setup is the headline. (See "Changing the Headline" on page 82.)

To select a Setup:

1. From the main menu, highlight **Settings** and press **Ok**.
2. Highlight **More...** and press **Ok**.
3. Highlight **Select Setup** and press **Ok**.
4. Highlight a Setup and press **Ok**.
 - ▶ **Sprint PCS** features Standard ringer types for voice calls and the Chirp ringer type for messages.
 - ▶ **Meeting** uses a vibrating ringer and mutes the key beep volume.
 - ▶ **Voice** uses the Voice ringer type for voice calls and messages.
 - ▶ **Fun** features prerecorded, custom and recordable ringers.
 - ▶ **Loud** uses the Level 5 + Vibrate ringer volume and enables service alerts.

Shortcut:

You can also select a Current Setup from the main menu by pressing the Mouse Key left and pressing **2**.

Note:

For more information on ringer types, see page 83.

Copying Your Settings

To copy your settings over to a new Setup:

1. From the main menu, highlight **Settings** and press **Ok**.
2. Highlight **More...** and press **Ok**.
3. Highlight **Copy Settings** and press **Ok**.
4. Highlight the Setup you want to copy the settings from and press **Ok**.
5. Highlight the Setup you want to copy the settings to and press **Ok**.
6. Press **Ok** again to copy the settings to the selected Setup.

11

Setting Your Phone's Security

In This Section

- ▶ Accessing the Security Menu
- ▶ Locking Your Phone
- ▶ Unlocking Your Phone
- ▶ Restricting Calls
- ▶ Using Special Numbers

By using the security setting on your Sprint PCS Phone™, you receive peace of mind without sacrificing flexibility. With several options available, you can customize your phone to meet your personal needs.

**Tip:**

If you can't recall your lock code, try using the last four digits of either your Social Security number or Sprint PCS Phone Number or try 0000. If none of these work, call Sprint PCS Customer Care at 1-888-211-4PCS (4727).

Accessing the Security Menu

You must enter your lock code to view the Security menu. If you forget your lock code, try using the last four digits of your Social Security number, the last four digits of your Sprint PCS Phone Number or 0000.

To access the Security menu:

1. From the main menu, highlight **Security** and press **Ok**.
2. Enter your lock code.

Locking Your Phone

When your phone is locked, you can only receive incoming calls or make calls to 911, Sprint PCS Customer Care or special numbers.

To lock your phone:

1. From the Security menu, highlight **Lock Phone** and press **Ok**.
2. Highlight **Lock Now** or **On Power Up** and press **Ok**.
If you select **On Power Up**, the phone will be locked each time it powers up.

Unlocking Your Phone

To unlock your phone:

1. Highlight **Unlock** and press **Ok**.
2. Enter your lock code.

Changing the Lock Code

To change your lock code:

1. From the **Security** menu, highlight **Change Lock** and press **Ok**.
2. Enter your new lock code.
3. Reenter your new lock code.

Restricting Calls

You can restrict which phone numbers you can receive calls from or dial. (The Restrict Calls setting does not apply to 911 or Sprint PCS Customer Care.)

To restrict calls:

1. From the **Security** menu, highlight **Restrict Calls** and press **Ok**.
2. Highlight **Outgoing** or **Incoming** and press **Ok**.
3. Select an option by highlighting it and pressing **Ok**.
 - ▶ **Allow All** to make all outgoing or receive all incoming calls.
 - ▶ **PhoneBook Only** to make or receive calls only from special numbers or phone numbers stored in your Internal Phone Book.
 - ▶ **Special # Only** to make or receive calls only from special numbers. (See "Using Special Numbers" on page 94.)

Unrestricting Calls

To unrestrict all calls:

1. From the **Security** menu, highlight **Restrict Calls** and press **Ok**.
2. Highlight **Off** and press **Ok**.

To unrestrict incoming or outgoing calls only:

1. From the **Security** menu, highlight **Restrict Calls** and press **Ok**.
2. Highlight **Outgoing** or **Incoming** and press **Ok**.
3. Highlight **Allow All** and press **Ok**.

Note:

There are no Speed Dial options associated with special numbers.

Using Special Numbers

You can save three special numbers in addition to your Internal Phone Book entries (they can be the same number). You can make and receive calls from special numbers even when your phone is locked. You can also restrict your phone to dial or receive calls from special numbers only. (See “Restricting Calls” on page 93.)

To add or replace a special number:

1. From the **Security** menu, highlight **Special #s** and press **Ok**.
2. Highlight an entry location and press **Ok**.
3. Enter or replace the phone number and press **Ok**.

Erasing the Internal Phone Book

To erase all the names and phone numbers in your Internal Phone Book:

1. From the **Security** menu, highlight **Erase PhoneBook** and press **Ok**.
2. If you are certain you want to erase the entire contents of the Internal Phone Book, highlight **Yes** and press **Ok**.

Resetting Your Phone

Resetting the phone restores all the factory defaults, including the ringer types and display settings. The Internal Phone Book, Call Logs, Scheduler, Messages and Call Alarms are not affected.

To reset you phone:

1. From the **Security** menu, highlight **Reset Phone** and press **Ok**.
2. If you are certain you want to reset your phone, highlight **Yes** and press **Ok**.

12

Personal Information Management

In This Section

- ▶ Adding an Event to the Scheduler
- ▶ Event Alerts
- ▶ Adding a Call Alarm to the Scheduler
- ▶ Adding To Do Items
- ▶ Viewing the Scheduler Calendar
- ▶ Using the Calculator
- ▶ Playing Games

Your Sprint PCS Phone™ has been equipped with several personal information management features to help you manage your busy lifestyle. These features turn your phone into a time management planner that helps you keep up with your contacts, schedules and commitments. It takes productivity to a whole new level.

**Tip:**

Use the volume control keys to scroll by month through the Scheduler calendar or press the Mouse Key up or down to scroll by week.

Note:

Default alarm times are 10 minutes for Meetings, Events and Dining Appointments, 24 hours for Special Occasions and zero minutes for Call Alarms.


Adding an Event to the Scheduler

Your Scheduler helps organize your time and reminds you of important events.

To add an event:

1. From the main menu, highlight **Scheduler** and press **Ok**.
2. Highlight the day you want to add an event to by pressing the Mouse Key left (previous day) or right (next day) and pressing **Ok**.
3. Highlight **Add Event** and press **Ok**.
4. Highlight **Meeting, Spcl Occasion, Event or Dining Appt.** and press **Ok**.
5. Enter a description and press **Ok**. (See "Entering Character Using T9 Text Input" on page 143.)
6. Enter the time, date and duration using your keypad. (Fields must be two digits, for example "05:07a 01/01/99.") To toggle between AM and PM, highlight **AM/PM** and press **Ok**.
7. To select an option, highlight it and press **Ok**.

- ▶ **Done** to schedule the event.
- ▶ **Edit Alarm** to edit the event's alarm. Enter the number of hours or minutes before the event you want be reminded and press **Ok**. If you do not want to be reminded, highlight **No Alarm** and press **Ok**.
- ▶ **Edit Repeat** to change the event's repeating frequency. Highlight **Daily, Weekly, Monthly or Yearly** and press **Ok**.

- ▶ **Add New Memo** to add a voice memo alert to the event. Record your memo and press **Ok**. When a voice memo is attached to a scheduled event, the  icon is displayed next to the event's description.
- ▶ **Set End Time** to change the event's end time (if it is longer than 99 hours 99 minutes). Enter the end time and date and press **Ok**.
- ▶ **Edit Descript.** to change the description of the event. Enter a new description and press **Ok**.

Scheduled Event Alerts

There are several ways your Sprint PCS Phone alerts you of scheduled events:

- ▶ By playing the assigned ringer type.
- ▶ By illuminating the backlight.
- ▶ By flashing the LED red.
- ▶ By displaying event's description, time and date.

Scheduled Event Alert Menu

When your phone is turned on and you have an event alarm scheduled, your phone alerts you and displays the following options. To select an option, highlight it and press **Ok**.

- ▶ **Play Speaker** to play a memo through the speaker (if you have a voice memo attached).
- ▶ **Play Private** to play a memo through the earpiece (if you have a voice memo attached).
- ▶ **View Details** to display the event's time, date, duration, description and minutes before a scheduled alarm.
- ▶ **Snooze** to repeat the alarm in ten minutes.
- ▶ **Erase** to delete the event (even if it is a repeating event).
- ▶ **Edit** to edit the time, date, alarm, repeating status, memo, end time or description of the event.
- ▶ **Exit** to save the event and return to the main menu (or press **End**).

If you have the Alarm mode enabled (see "Setting the Alarm Mode" on page 87), your phone will alert you to scheduled event alarms even when it is turned off. When the event alarm is scheduled, the following options are displayed. To select an option, highlight it and press **Ok**.

- ▶ **View Details** to display the event.
- ▶ **Snooze** to repeat the alarm in ten minutes.
- ▶ **Save & Pwr ON** to save the event and power your phone on.
- ▶ **Save & Pwr OFF** to save the event and power your phone off.

Adding a Call Alarm to the Scheduler

To add a call alarm from the Scheduler:

1. From the main menu, highlight **Scheduler** and press **Ok**.
2. Highlight the day you want to add a call alarm to by pressing the Mouse Key left (previous day) or right (next day) and pressing **Ok**.
3. Highlight **Add Event** and press **Ok**.
4. Highlight **Call Alarm** and press **Ok**.
5. Highlight the Internal Phone Book entry you want to be reminded to call or highlight **Number Only** and press **Ok**. If you select **Number Only**, enter the phone number and press **Ok**.
6. Enter the time, date and duration using your keypad. (Fields must be two digits, for example "05:07a 01/01/99.") To toggle between AM and PM, highlight **AM/PM** and press **Ok**. To repeat the alarm, highlight **Set Repeating** and press **Ok**.
 - ▶ **Set Repeating** to set the call alarm's repeating frequency. Highlight **Daily**, **Weekly**, **Monthly** or **Yearly** and press **Ok**.
7. Highlight **Done** and press **Ok**.

For call alarm alerts, see "Call Alarm Alerts" on page 71.



Tip:

You can also add a call alarm from the Phone Book menu. (See "Adding a Call Alarm from the Internal Phone Book" on page 71.)

Viewing Events and Call Alarms

To view your scheduled events and call alarms:

1. From the main menu, highlight **Scheduler** and press **Ok**.
2. If you view the Scheduler calendar by week (see “Viewing the Scheduler Calendar” on page 107), an asterisk is displayed under days with events or call alarms scheduled. When you highlight a day with an asterisk, Event Type icons are displayed at the bottom of the screen. Icons are displayed in chronological order. (See “Event Type Icons” on page 108.) If you view the Scheduler calendar by month, days with events or call alarms scheduled are underlined.
3. To display an individual day, highlight the day by pressing the Mouse Key left (previous day) or right (next day) and press **Ok**. If you have call alarms or events scheduled, they are displayed in chronological order.
4. To display a scheduled event or call alarm, highlight it and press **Ok**.

Shortcut:

You can display Today's events from the main menu by pressing the Mouse Key left and pressing

4.

Editing Events

To change an event:

1. Highlight an event in the Scheduler menu and press **Ok**. (See “Viewing Events and Call Alarms” on page 100.)
2. Press **Ok** again to display event options.
3. Highlight **Erase** and press **Ok** to delete the event. Highlight **Edit** and press **Ok** to display additional options.
4. To select an option, highlight it and press **Ok**.
 - ▶ **Done** to schedule the event.
 - ▶ **Edit Alarm** to change the event's alarm. Enter the number of hours or minutes before the event you want be reminded of the event and press **Ok**. If you do not want to be reminded, highlight **No Alarm** and press **Ok**.
 - ▶ **Edit Repeat** to change the event's repeating frequency. Highlight **Daily**, **Weekly**, **Monthly** or **Yearly** and press **Ok**.
 - ▶ **Add New Memo/Edit Memo** to add or edit a voice memo alert. If you select **Add New Memo**, record your memo and press **Ok**. If you select **Edit Memo**, highlight **Play Speaker**, **Play Private** or **Erase Memo** and press **Ok**.
 - ▶ **Set End Time** to change the event's end time (if it is longer than 99 hours 99 minutes). Enter the end time and date and press **Ok**.
 - ▶ **Edit Descript.** to change the title of the event. Enter a new description and press **Ok**.

**Tip:**

You can also view the next or previous event or call alarm by pressing the Mouse Key left (previous) or right (next).

Editing Call Alarms

To change a call alarm:

1. Highlight a call alarm in the Scheduler menu and press **Ok** . The time, date and phone number (or Internal Phone Book entry) are displayed.
2. Select an option by highlighting it and pressing **Ok** .
 - ▶ **Erase** to delete the call alarm. To delete the call alarm, press **Ok** again.
 - ▶ **Edit Time/Date** to edit the time, date and repeating frequency of the call alarm.
 - ▶ **Next** to display the next scheduled event or call alarm for the selected day.
 - ▶ **Previous** to display the previous scheduled event or call alarm for the selected day.
 - ▶ **Exit** to return to the Scheduler menu.

Adding To Do Items

Your phone can store and manage 20 To Do items.

To add an entry to your To Do List:

1. From the main menu, highlight **Scheduler** and press **Ok** .
2. Press **Ok** again to display the Scheduler menu.
3. Highlight **To Do List** and press **Ok** .
4. Highlight **Add Item** and press **Ok** .
5. Enter a description and press **Ok** . (See “Entering Characters Using T9 Text Input” on page 143.)

6. Highlight **Low** or **High** and press **Ok** . Low priority To Do items are indicated by an asterisk and high priority To Do items by an exclamation point. When you complete a To Do item, you can identify it as Done with a checkmark. (See “Editing To Do Items” on page 104).
7. Enter a due date using your keypad or highlight **No Due Date** and press **Ok** . (Due dates do not have alarms associated with them.)

Viewing To Do Items

To view your To Do List:

1. From the main menu, highlight **Scheduler** and press **Ok** .
2. Press **Ok** again to display the Scheduler menu.
3. Highlight **To Do List** and press **Ok** . Low priority To Do items are indicated by an asterisk, high priority To Do items by an exclamation point and completed To Do items by a checkmark. (See “Editing To Do Items” on page 104.)
4. To display a To Do item, highlight it and press **Ok** .

Shortcut:

You can also display the To Do List from the main menu by pressing the Mouse Key left and pressing **5** .

Editing To Do Items

To change a To Do item:

1. From the main menu, highlight **Scheduler** and press **Ok**.
2. Press **Ok** again to display the Scheduler menu.
3. Highlight **To Do List** and press **Ok**.
4. Highlight the To Do item and press **Ok**.
5. Select an option by highlighting it and pressing **Ok**.
 - ▶ **Erase Item** to delete the To Do item. To delete the item, press **Ok** again.
 - ▶ **Edit Priority** to change the item's priority. Highlight the a priority and press **Ok**. Low priority To Do items are indicated by an asterisk, high priority To Do items by an exclamation point and completed To Do items by a checkmark.
 - ▶ **Edit Due Date** to change the due date. Edit the due date or highlight **No Due Date** and press **Ok**.
 - ▶ **Edit Descript.** to change the item's description. (See "Entering Characters Using T9 Text Input" on page 143).
 - ▶ **Add to Schedule** to remove the item from the To Do List and make it a scheduled event. (See "Adding a To Do Item as an Event" on page 105).
 - ▶ **Next** to display the next To Do item.
 - ▶ **Previous** to display the previous To Do item.
 - ▶ **Exit** to return to the Scheduler menu.



Tip:

Labeling a To Do item as done still retains the To Do item in your memory. To delete the item, select Erase Item.



Tip:

Press the Mouse Key left or right to display the next or previous To Do item.

Adding a To Do Item as an Event

To remove an item from the To Do List and schedule it as an event:

1. From the main menu, highlight **Scheduler** and press **Ok**.
2. Press **Ok** again to display the Scheduler menu.
3. Highlight **To Do List** and press **Ok**.
4. Highlight the To Do item and press **Ok**.
5. Highlight **Add to Schedule** and press **Ok**.
6. Enter a time and date with your keypad.
7. To select an option, highlight it and press **Ok**.
 - ▶ **Done** to schedule the event.
 - ▶ **Edit Alarm** to edit the event's alarm. Enter the number of hours or minutes before the event you want be reminded and press **Ok**. If you do not want to be reminded, highlight **No Alarm** and press **Ok**.
 - ▶ **Edit Repeat** to change the event's repeating frequency. Highlight **Daily**, **Weekly**, **Monthly** or **Yearly** and press **Ok**.
 - ▶ **Add New Memo** to add a voice memo alert to the event. Record your memo and press **Ok**.
 - ▶ **Set End Time** to change the event's end time (if it is longer than 99 hours 99 minutes). Enter the end time and date and press **Ok**.
 - ▶ **Edit Descript.** to change the description of the event. Enter a new description and press **Ok**.

Deleting To Do Items

To erase individual To Do items, see “Editing To Do Items” on page 104.

To erase all To Do items:

1. From the main menu, highlight **Scheduler** and press **Ok**.
2. Press **Ok** again to display the Scheduler menu.
3. Highlight **To Do List** and press **Ok**.
4. Highlight **Erase Items** and press **Ok**.
5. Highlight **Yes** and press **Ok**.

Viewing and Clearing Scheduler, Call Alarm or To Do List Memory

To view available and used Scheduler, Call Alarm or To Do List memory space:

1. From the main menu, highlight **Scheduler** and press **Ok**.
2. Press **Ok** again to display the Scheduler menu.
3. Highlight **Memory** and press **Ok**.
4. Highlight **View Details** and press **Ok**.
5. Highlight **Schedule**, **Call Alarm** or **To Do List** and press **Ok**. Your used and available memory is displayed.
6. To erase old or all Scheduler events, highlight **Erase Old** or **Erase All** and press **Ok**. To erase all call alarms, highlight **Erase All** and press **Ok**. To erase done or all To Do items, highlight **Erase Done** or **Erase All** and press **Ok**.
7. Highlight **Yes** and press **Ok**.

Erasing Old Events or All Events, Call Alarms and To Do Items

To erase events, call alarms and To Do items:

1. From the main menu, highlight **Scheduler** and press **Ok**.
2. Press **Ok** again to display the Scheduler menu.
3. Highlight **Memory** and press **Ok**.
4. Highlight **Erase Old** to erase old Scheduler events (non-repeating events that have expired) or **Erase All** to erase all events, call alarms and To Do items and press **Ok**.
5. Highlight **Yes** and press **Ok**.

Going To Dates

To go directly to a day in the Scheduler calendar:

1. From the main menu, highlight **Scheduler** and press **Ok**.
2. Press **Ok** again to display the Scheduler menu.
3. Highlight **Go To Date** and press **Ok**.
4. Enter the date using your keypad. (Fields must be two digits, for example “02/17/00.”)
5. Highlight **Go** and press **Ok**. Press **Ok** again to view the day’s Scheduler menu.

Viewing the Scheduler Calendar

To view your Scheduler calendar:

1. From the main menu, highlight **Scheduler** and press **Ok**.
2. Press **Ok** again to display the Scheduler menu.
3. Highlight **Week View** or **Month View** and press **Ok**. The Scheduler calendar is displayed and the setting is saved the next time you display the calendar.



Tip:

You can also display the Go To menu by pressing any digit when the Scheduler’s month or week view is displayed.



Tip:



Use the volume control keys to scroll by month through the Scheduler calendar or press the Mouse Key up or down to scroll by week.

Event Type Icons

When you highlight a day in the Scheduler calendar, icons appear on the bottom of the display that indicate the type of event and the order in which the event is scheduled (Week View only).

- ▶  - Meeting
- ▶  - Dining Event
- ▶  - Call Alarm
- ▶  - Special Occasion
- ▶  - General Event

When you create or view events, icons are displayed that indicate event characteristics:

- ▶  - Repeating Event or Call Alarm
- ▶  - Alarm Scheduled (Events only)

Using the Calculator

Your phone comes with a built-in calculator function. To use this tool, follow these easy steps:

1. From the main menu, highlight **Calculator** and press **Ok**.
2. Enter numbers using your keypad. Press **#** to insert a decimal point.
3. To select an arithmetic option, press ***** (press ***** again to scroll through options) or highlight the option and press **Ok**.
4. Press **Ok** again to calculate the equation.

Playing Games

To start a game:

1. From the main menu, highlight **Games** and press **Ok**.
 2. To select a game, highlight it and press **Ok**.
- ▶ **Blackjack:** Press **Ok** to begin the game. You always wager \$10 and can **Double Down** with 10 or 11 points. Try and beat the Dealer's score (D:) by choosing **Hit** or **Stay** and pressing **Ok**. A running dollar total keeps track of your winnings (or losses).
 - ▶ **Football:** Press **Ok** to begin the game. Select Offensive and Defensive options by highlighting them and pressing **Ok**. The score, time remaining and field position are displayed.
 - ▶ **Dice:** Press **Ok** to begin the game. Try to remove all the digits (1-9) by highlighting combinations and pressing **Ok**. Your score is the total of the remaining digits.

Experiencing Sprint PCS Wireless WebSM

In this Section

- ▶ The Sprint PCS Wireless Web
 - ▶ The Sprint PCS Wireless Web Browser
 - ▶ Creating and Finding Bookmarks
 - ▶ Setting up a Sprint PCS Wireless Web Connection
 - ▶ Accessing Sprint PCS Wireless Web Updates
-

By now you've discovered the great features that come with your Sprint PCS Phone™. Now it's time to experience the Sprint PCS Wireless Web. Let the adventure begin.

Note:

Sprint PCS Wireless Web service will not work when roaming off the Sprint PCS Nationwide Network and may not be available in select affiliate areas.

The Sprint PCS Wireless Web

With the Sprint PCS Wireless Web and your wireless Internet-ready phone, you have access to the wireless Internet in three ways:

- ▶ **Sprint PCS Wireless Web MailSM** lets you send and receive e-mail quickly and easily and ensures you will never miss an important e-mail again.
- ▶ **The Sprint PCS Wireless Web Browser** allows you to view specially-design text versions of popular web sites.
- ▶ **Sprint PCS Wireless Web Connection** allows you to connect to the Internet or your company's network with a laptop PC or hand-held computing device and a Sprint PCS Wireless Web Connection Kit.
- ▶ **Sprint PCS Wireless Web UpdatesSM** let you receive daily information updates, including weather, stock quotes and sports scores at the time you choose.

Sprint PCS Wireless Web Mail

With Sprint PCS Wireless Web Mail, you can set up a Sprint PCS e-mail account at no additional charge and perform many of the typical e-mail functions from your Sprint PCS Phone that you can from your personal computer at www.sprintpcs.com. Or if you prefer, you can access other select e-mail providers, including America Online.[®]

To set up and use your Sprint PCS Wireless Web Mail:


1. Highlight **Wireless Web** and press **Ok**.
2. If the Sprint PCS Wireless Web Home Page is not displayed, highlight the **Home** softkey and press **Ok**.
3. Highlight **@Sprint PCS** (or **AOL**) and press **Ok**.

4. Highlight **Sprint PCS Mail** and press **Ok**. If you are a first-time user, follow the prompts to set up your Sprint PCS Wireless Web account. A user name and password must also be established.
5. To view your messages, select **Inbox** with Sprint PCS Wireless Web Mail (or **Mail** from the America Online home page).
6. Highlight the message you want to read and press **Ok**.
7. After you have read the message, you can select a quick action at the end of the message, **Erase**, **Reply**, **Reply All** or **Next Message**, or select **Menu** for a full list of options.

The Sprint PCS Wireless Web Browser

Your phone comes equipped with a MiniBrowser, which allows you to access up-to-the minute information through the Sprint PCS Wireless Web.

You can view specially-designed text versions of popular Internet sites. Browsing the Sprint PCS Wireless Web using your phone is different than using a home computer because the amount of information is reduced (sites usually display only their most critical aspects) and most of the graphics have been removed.

The MiniBrowser connects to the Internet by placing a call. Note that  appears on the display whenever a call is in progress, just as with a regular voice call. Service charges vary depending on your service option.

Launching a Sprint PCS Wireless Web Browser Session

To launch the Sprint PCS Wireless Web Browser:

1. From the main menu, highlight **Wireless Web** and press **Ok**. You'll see a few introductory messages as the browser launches.

Shortcut:

You can also launch the MiniBrowser from the main menu by pressing the **Mouse Key** left and pressing **1**.

Sprint PCS
Wireless Web
13

Note:
The Sprint PCS
Wireless Web Home
Page is subject to
change.

The first time you use the MiniBrowser, you'll be prompted to enable the security feature. This automatic process will take 3-6 minutes to complete and it occurs just once. When the process is complete, you're ready to start using the Sprint PCS Wireless Web.

Following the security setup, you'll see the Sprint PCS Wireless Web home page. This is the main page for the MiniBrowser and it gives you access to all the sites in the Sprint PCS Wireless Web. The next time you use the MiniBrowser, you may not see the home page at first because the MiniBrowser will display the page you were viewing when you last exited the MiniBrowser.

WIRELESS WEB	
1	@SprintPCS
2	Yahoo!
3	Amazon.com
4	eCompare
5	Bloomberg
6	FOX Sports
7	Go2online
8	CNN
9	Bookmarks
	More...
OK	MENU

The Sprint PCS Wireless Web Home Page

You may notice that sometimes the MiniBrowser will launch without placing a call. This is because the phone stores recently viewed pages in its memory cache. The MiniBrowser will connect automatically when you access a page that's not stored in the cache.

If the phone has been inactive for awhile and a new wireless Internet site has not been requested, the MiniBrowser will automatically disconnect. The MiniBrowser will remain active – only the connection will end. The MiniBrowser will automatically reconnect when you go to a wireless Internet site that's not stored in the phone's memory cache. For this reason, you may find that you are billed for several network connections within a single session. This is normal and is designed to minimize airtime charges.

When launching the MiniBrowser you will see a reminder that MiniBrowser calls will be charged.


Using the Sprint PCS Wireless Web Browser

Using the MiniBrowser is easy once you've learned a few basics. Here are some tips for navigating the Sprint PCS Wireless Web:

Softkeys

The bottom line of the MiniBrowser contains a row of softkeys. These are your main controls for getting around. To activate a softkey, press the Mouse Key left or right to highlight the desired softkey, then press **OK**.

Press the Mouse Key right a few times and you'll see more softkeys. Depending on the wireless Internet site you're using, the first two softkeys may change names and functions, but the other softkeys are always available and give you access to these special features:

- ▶  indicates a secure site.
- ▶ **Home** accesses the Sprint PCS Wireless Web home page.
- ▶ **Help** opens the MiniBrowser Menu, which is described later.
- ▶ **Mark** creates a bookmark for the current page.
- ▶ **BkMrks** accesses the list of Bookmarks.

**Tip:**

The tenth item in a numbered list may be selected by pressing the 0 (zero) key on your phone's keypad, even though the number 0 doesn't appear on screen.

Note:

Only specially-designed wireless Internet sites are available via the Go To function.

Scrolling

As with other parts of your phone's menu, you'll have to scroll up and down to see everything on some wireless Internet sites. Press the Mouse Key up or down to scroll line by line. You can also use the volume control keys on the side of your phone to quickly scroll one page at a time rather than one line at a time.

Selecting

Once you've learned how to activate softkeys, you can start navigating wireless Internet sites. Select on-screen items by using the Mouse Key to highlight the desired item, then activate the desired softkey by pressing **Ok**. You'll find that the left softkey is used primarily for selecting items. This softkey is often labeled "OK," but don't confuse it with **Ok** on your phone, which always activates the highlighted softkey.

If the items on a page are numbered, you can also use your keypad (number keys) to select an item.

Links, which appear [in brackets], allow you to jump to different wireless Internet sites, select special functions, or even place phone calls. Select links by highlighting the link and then activating the appropriate softkey, which is usually (but not always) the left softkey.

Going to a Wireless Internet Site

From the Sprint PCS Wireless Web home page, you can go to a wireless Internet site simply by highlighting the desired site name and activating the OK softkey. Note that the list of wireless Internet sites extends beyond one page. Select "More" to see additional site listings.

To access a site that does not appear on the home page, use the "GO TO" function. You'll be required to enter the URL (site address) for the site you want to visit.

To go back one page, press **Clr**.

Going Home

To return to the Sprint PCS Wireless Web home page, highlight the Home softkey and press **Ok**.

Entering Text

Some wireless Internet sites require that you enter text using your phone's keypad. See "Entering Characters Using T9 Text Input" on page 143 or "Entering Characters by Tapping the Keypad" on page 142.

Creating a Bookmark

Bookmarks allow you to store the address of favorite wireless Internet sites for easy access at a later time.

To create a bookmark:

1. Go to the page you want to mark.
 2. Highlight the **Mark** softkey and press **Ok**.
 3. When a page has a title, it is automatically used for the name of the bookmark. If you want, you can change the name.
 4. Highlight **Save** and press **Ok** to save the name and add the page to your list of bookmarks. A message appears confirming the bookmark was added to the list.
 5. Select **Ok** to return to the screen that you marked and resume navigation within the Sprint PCS Wireless Web Browser.
- The new bookmark is added to the bottom of your bookmark list.

Note:

Bookmarking a page does not store the page contents, just its address.

Note:

Some pages cannot be bookmarked. Bookmark availability is determined by web site developers.

Note:

When using the "Go to..." option, it is not necessary to enter "http://" before the site name. Only HDML and WML sites are accessible.

Finding a Bookmark

To access a bookmark from the Home page:

1. Highlight **Bookmarks** and press **Ok**.
2. Highlight the bookmark you want to display and press **Ok**.

To access a bookmark from the BookMrks softkey:

1. Highlight the **BkMrks** softkey and press **Ok**.
2. Highlight the bookmark you want to display and press **Ok**.

Deleting a Bookmark

1. From the bookmark list, highlight the bookmark you want to delete.
2. Press **Ok**.
3. Highlight **Erase** from the options and press **Ok**.
A message displays prompting you to confirm.
4. Press **Ok** to delete the bookmark.

Using Go To

To go directly to a wireless Internet site:

1. Highlight the **Menu** softkey and press **Ok**.
2. Highlight **Go to...** and press **Ok**.
3. Enter the name or URL of the wireless Internet site and press **Ok**.

The Browser Menu

The Browser Menu contains several special functions. To access the Browser Menu, use the Mouse Key to highlight the Help softkey, then press **Ok**.

- ▶ **Help** View help text for the current wireless Internet site (when available).
- ▶ **Home** Accesses the Sprint PCS Wireless Web home page.
- ▶ **Mark Site** Create a bookmark for the current wireless Internet site.
- ▶ **Show URL** Display the URL (address) for the current wireless Internet site.
- ▶ **Restart** Reset and restart the MiniBrowser.
- ▶ **Phone.com** Display information about the Phone.com browser.
- ▶ **T9 Help** Describes how to enter text using T9 Text entry (see "Entering Characters Using T9 Text Input" on page 143.)
- ▶ **Advanced** Displays advanced options for your Sprint PCS Wireless Web Browser. (You should only use when instructed by Sprint PCS Customer Care.)

Ending a Browser Session

To end a browser session and disconnect from the Sprint PCS Wireless Web, press **ⓂEnd**.

Troubleshooting

If you're having trouble using the Sprint PCS Wireless Web MiniBrowser, use the following troubleshooting guide:

Problem: You can't escape from a particular site.

Recommendation: Go to the Sprint PCS Wireless Web home page by using the Mouse Key to highlight the Home softkey, then press **Ok** .

Problem: You continue to receive errors when using a certain site.

Recommendation: Try again later. Sites are sometimes temporarily inaccessible due to high traffic. If the problem persists, there may be a problem with the site.

Problem: The MiniBrowser appears to be malfunctioning or stops responding.

Recommendation: Reset the MiniBrowser by going to the Browser Menu and selecting the "Restart" option. If that doesn't work, turn your phone off then on again. If that also fails, try removing the battery and then replacing it.

If none of these solutions work, please contact Sprint PCS Customer Care.

Problem: An error message says that my phone is not yet registered for Sprint PCS Wireless Web services.

Recommendation: Sprint PCS Wireless Web services can take longer to activate than voice services. Please try again later. If the problem persists for more than one day, please contact Sprint PCS Customer Care.

Problem: The message "Service Not Available" appears.

Recommendation: Your phone can't acquire a signal or you are in an area that does not yet support Sprint PCS Wireless Web services. If possible, move to an area that supports Sprint PCS Wireless Web services. If you continue to receive this message, please contact Sprint PCS Customer Care.

Problem: The message "Data Server Unavailable" appears.

Recommendation: Sprint PCS Wireless Web services are temporarily unavailable for some reason. Please try again later. If this problem persists, please contact Sprint PCS Customer Care.

Problem: The message "IP Address Missing" appears.

Recommendation: Your phone's factory settings have been altered. Please contact Sprint PCS Customer Care for assistance.

Note:

You will not need to install the Sprint PCS Dialer for Palm or HPC/Windows CE.

Setting up a Sprint PCS Wireless Web Connection

Getting Started

Your wireless Internet-ready Sprint PCS Phone allows you to connect to a laptop PC, hand-held or palm-sized computing device to send and receive email, access the Internet or your company's network and more, without searching for a wall-mounted telephone jack. In just three steps, you can use your connectivity:

1. First, you'll need a Sprint PCS Wireless Web™ Connection Kit (sold separately).
2. Connect your laptop PC to your Sprint PCS Phone by using the serial data cable. The cable adapter will connect to a hand-held or palm-sized computing device.
3. Finally, take a few minutes to install the Sprint PCS DialerSM software onto your computer using your CD.

For complete details on how to install and use this software, refer to the user guide in the Sprint PCS Wireless Web Connection Kit.

Placing a Call

To place a call while you're connected to the Sprint PCS Wireless Web:

1. First, make sure the cable is connected properly.
 2. Open the Sprint PCS Dialer software or application on your computer and place the call.
- ▶ The phone displays the number your computer is calling and a "connecting" message is displayed.
 - ▶ Once the call successfully connects, your phone's display shows you information on the status of the data call.

Receiving Sprint PCS Wireless Calls

Most users use the Sprint PCS Wireless Web Connection to place outgoing data/fax calls. But you can also set up your Sprint PCS Phone to receive (host) data and fax calls. Because each phone model is different, the Sprint PCS Wireless Web Connection Kit doesn't include instructions for how to set up your phone to receive data and fax calls. Here's the procedure to set up your Sprint PCS Phone to receive a (mobile-terminated) data or fax call:

1. From the main menu, highlight **Settings** and press **Ok**.
2. Highlight **Data/Fax (In)** and press **Ok**.
3. Once you've received the incoming data/fax call, you may want to return the phone to its normal state by disabling incoming data/fax calls. Highlight **Exit Data Mode** or **Exit Fax Mode** and press **Ok**.

Note:

Caller ID is not available on Sprint PCS Wireless Web Browser calls.

Using Special Features During a Sprint PCS Wireless Web Call

Your phone gives you the ability to use special features while you're on a Sprint PCS Wireless Web call. They are outlined below:

- ▶ **Caller ID:** Just like your phone stores regular Caller ID numbers, it also stores the numbers of incoming Sprint PCS Wireless Web Connection calls. To distinguish between the two types of calls, "Data" or "Fax" displays along with the number of the caller when you view your Caller ID records.
- ▶ **Call Waiting:** If someone tries to reach you while you're connected to the Sprint PCS Wireless Web, your phone behaves like it is turned OFF. Depending on your service, callers may get your voicemail. Call Waiting is automatically deactivated whenever you place or receive a Sprint PCS Wireless Web Connection call.
- ▶ **Accessing features:** You can still access most of your phone's features while you're connected to a Sprint PCS Wireless Web Connection Call. You can navigate the phone's menu system to change or view your phone's features or phone book entries. You can also read messages or view the Caller ID records that you received before placing the call.

Ending a Sprint PCS Wireless Web Call

It's important to note that some of the normal ways to end a call won't work with the Sprint PCS Wireless Web Connection calls. You should always close the connection through the application on your computer. Your phone will then return to Standby mode.

Although you can end a Sprint PCS Wireless Web Connection call by disconnecting the data cable or turning off your phone, this may disrupt your computer.

Accessing Sprint PCS Wireless Web Updates

With Sprint PCS Wireless Web Updates, you can have the Internet-based information sent directly to your Sprint PCS Phone at the times you choose. When you select the Sprint PCS Wireless Web option, up to 50 updates can be sent to your phone each month at no additional charge.

To select the Internet-based information you want sent to your Sprint PCS Phone:

1. From your computer, log on to the Internet.
2. Go to the site from which you want to receive information. A few of the sites you can visit are America Online, amazon.com, eCompare!, ebay, FoxSports.com and FTD.com. (The location where you request updates within each site will vary.)
3. Where indicated on the site, input your Sprint PCS 10-digit phone number followed by "@messaging.sprintpcs.com." For example: 5551234567@messaging.sprintpcs.com.

Upon completing the registration process, you should begin receiving your updates on your Sprint PCS Phone as requested.

Using the Voice Services of Your Sprint PCS Phone

In this Section

- ▶ Using Voice Dialing
 - ▶ Recording Memos
 - ▶ Using Commands
-

This section explains the features associated with your phone's Voice Services. The easy-to-follow instructions explain how to make calls or go to a menu by simply speaking a command. You'll also learn how to record memos and personal ringers.

Note:

Train Voice Dial tags in a quiet environment and without the aid of an accessory (for example, a headset or hands-free car kit).

**Tip:**

You can also begin recording memos by pressing and holding the Voice Services key.

Note:

Your phone can store up to a total of four minutes of memo recordings, scheduler voice attachments or recordable ringers.

Using Voice Dialing

You can use a Voice Dial tag to automatically dial a phone number in your Internal Phone Book. Your phone can store up to 25 Voice Dial tags. (To create a Voice Dial tag, see “Adding a New Internal Phone Book Entry” on page 66 or “Editing an Internal Phone Book Entry” on page 73.)

To use a Voice Dial tag to call a phone number:

1. Press the Voice Services key on the side of the phone.
2. Follow the voice prompts and recite the entry's Voice Dial tag into your phone's microphone.

Recording Memos

To record a memo:

1. Highlight **Voice Services** from the main menu and press **Ok** . (Or press the Voice Services key on the side of the phone and press **Ok** .)
2. Highlight **Record Memo** and press **Ok** .
3. Record your memo and press **Ok** or the Voice Services key when you are finished. The time and date you recorded your memo, the length of the memo and the memory size are displayed. The time and date is used as the default memo title. (For memo options, see “Memo Options” on page 129.)

Memo Options

To select a memo option:

1. Highlight **Voice Services** from the main menu and press **Ok** . (Or press the Voice Services key on the side of the phone and press **Ok** .)
2. Highlight **Memo List** and press **Ok** .
3. To display a memo, highlight it and press **Ok** .


To select an option, highlight it and press **Ok** .

- ▶ **Play Speaker** to play a memo through the speaker.
- ▶ **Play Private** to play a memo through the earpiece.
- ▶ **Erase Memo** to delete the memo.
- ▶ **Edit Title** to edit the memo title. (See “Entering Characters by Tapping the Keypad” on page 142 for options.)
- ▶ **Add To Schedule** to add the memo to your Scheduler. (See “Adding Memos to your Scheduler” on page 130.)
- ▶ **Next** to display the next memo.
- ▶ **Previous** to display the previous memo.
- ▶ **Exit** to return to the Voice Services menu.

**Tip:**

You can also view the next memo by pressing the Mouse Key right or view the previous memo by pressing the Mouse Key left.

Adding Memos to Your Scheduler

When a voice memo is attached to a scheduled event, the  icon is displayed next to the event's description.

To add a memo to your scheduler:

1. Display memo options.
2. Highlight **Add to Schedule** and press **Ok**.
3. Enter the time, date and duration of the event using your keypad. (Fields must be two digits, for example "05:07a 01/01/99.") To toggle between AM and PM, highlight **AM/PM** and press **Ok**.
4. To select an option, highlight it and press **Ok**.
 - ▶ **Done** to schedule the event.
 - ▶ **Edit Alarm** to change the event's alarm. Enter the number of hours or minutes before the event you want be reminded of the event and press **Ok**. If you do not want to be reminded, highlight **No Alarm** and press **Ok**.
 - ▶ **Edit Repeat** to change the event's repeating frequency. Highlight **Daily**, **Weekly**, **Monthly** or **Yearly** and press **Ok**.
 - ▶ **Edit Memo** to edit the memo alert. Record your memo and press **Ok**.
 - ▶ **Set End Time** to change the event's end time (if it is longer than 99 hours 99 minutes). Enter the end time and date and press **Ok**.
 - ▶ **Edit Descript.** to change the title of the event. Enter a new description and press **Ok**.

Recording Ringers

You can record ringers and use them as ringer types to identify callers or types of calls. (See "Selecting a Ringer Type for an Entry" on page 88 or "Selecting Ringer Types for Voice Calls" on page 98.)

To record a ringer:

1. Highlight **Voice Services** from the main menu and press **Ok**. (Or press the Voice Services key on the side of the phone and press **Ok**.)
2. Highlight **Record Ringers** and press **Ok**. Recorded ringer locations have a checkmark in front of them and empty ringer locations have an asterisk in front of them.
3. Highlight an entry and press **Ok**.
4. Highlight **Record** and press **Ok**.
5. Follow the voice prompts and record your ringer. When you are finished, press **Ok**.

Recordable Ringer Options

To edit a recordable ringer:

1. Highlight **Voice Services** from the main menu and press **Ok**. (Or press the Voice Services key on the side of the phone and press **Ok**.)
2. Highlight **Record Ringers** and press **Ok**.
3. Highlight the ringer you want to edit and press **Ok**.
4. To select an option, highlight it and press **Ok**.
 - ▶ **Record** to record a new ringer.
 - ▶ **Erase** to delete the ringer.

Note:

In analog mode, recordable ringers are replaced by the Multi-Chirp ringer type.

Note:

Train commands in a quiet environment and without the aid of an accessory (for example, a headset or hands-free car kit).

Using Commands

You can use commands to redial a phone number, display the Scheduler menu, turn the backlight on, select a Setup or access Sprint PCS Wireless Web bookmarks (see “Command Options” on page 133).

To use a command, you must first train the command (see “Training Commands” on page 132).

To use a command:

1. Press the Voice Services key on the side of the phone.
2. Follow the voice prompt and recite your voice command. If the phone is unsure of the command, it will ask you to confirm it. If the phone plays the wrong command, say no. The phone will continue through a list of possible options until you say yes.

Training Commands

To train your phone to react to your commands:

1. Highlight Voice Services from the main menu and press **Ok** . (Or press the Voice Services key on the side of the phone and press **Ok** .)
2. Highlight Voice Commands and press **Ok** . Trained commands have a checkmark in front of them and untrained commands have an asterisk in front of them.
3. Highlight a command and press **Ok** .
4. Highlight Train Command and press **Ok** . (Select Play Command to hear a recorded command or Description for a description of the command.)
5. Follow the voice prompts.

Command Options

To edit a command:

1. Highlight **Voice Services** from the main menu and press **Ok** . (Or press the Voice Services key on the side of the phone and press **Ok** .)
2. Highlight **Voice Commands** and press **Ok** . Trained commands have a checkmark in front of them and untrained commands have an asterisk in front of them.
3. To edit a command, highlight it and press **Ok** .
4. To select an option, highlight it and press **Ok** .
 - ▶ **Play Command** to play the command.
 - ▶ **Train Command** to train the command. (See “Training Commands” on page 132.)
 - ▶ **Description** to display a description of the command.

Voice Dial Options

To use a Voice Dial tag, see “Using Voice Dialing” on page 128.

To display Voice Dial tag options:

1. Press the Voice Services key on the side of the phone and press **Ok** or highlight **Voice Services** from the main menu and press **Ok** .
2. Highlight **Voice Dial List** and press **Ok** .
3. Highlight a Voice Dial tag and press **Ok** .
4. To select an option, highlight it and press **Ok** .
 - ▶ **Play Voice Dial** to play the Voice Dial tag.
 - ▶ **Erase** to delete the Voice Dial tag.
 - ▶ **Next** to display the next Voice Dial tag.
 - ▶ **Previous** to display the previous Voice Dial tag.
 - ▶ **Exit** to return to the main menu.

**Tip:**

You can scroll between commands by pressing the Mouse Key left or right.

**Tip:**

You can scroll between Voice Dial tags by pressing the Mouse Key left or right.

Navigating Through Menus and Entering Text


In this Section

- ▶ Menu Navigation
 - ▶ Shortcuts
 - ▶ Viewing the Menus
 - ▶ Entering Characters by Tapping the Keypad
 - ▶ Entering Characters Using T9 Text Input
 - ▶ Entering Symbols and Numbers
-

This section is a road map to using your phone and also shows how to enter characters in your phone. Every function and feature you've learned can be accessed through a menu. Take a few moments to know your way around and how to enter text. You'll find that it makes it easier to use and understand your phone.

Menu Navigation

The Mouse Key provides circular scrolling through menus quickly and easily. The scroll bar at the right of the menu keeps track of your position in the menu at all times.



As you navigate through a menu, the options are highlighted. Select an option by highlighting it and pressing **OK**.

Shortcuts

You can also go directly to menus or selected features by using shortcuts. For example, press the Mouse Key right to display the All Entries folder of your Internal Phone Book.

To access other shortcuts, press the Mouse Key left from the main menu and then press the appropriate number or highlight the option and press **OK**.

- ▶ **1** Launches the Sprint PCS Wireless Web Browser
- ▶ **2** Lets you select a Current Setup
- ▶ **3** Displays Unread Page or Sprint PCS Wireless Web messages
- ▶ **4** Displays the current day's Scheduler day view
- ▶ **5** Displays the To Do List
- ▶ **6** Lets you select the Backlight setting

Working within the Menu Structure

Selecting Menu Items

As you navigate through a menu, the options are highlighted. Select an option by highlighting it and pressing **OK**.

For example, if you want to view your last incoming call:

1. From the main menu, highlight **Call Logs** and press **OK**. (It may already be highlighted.)
2. Press the Mouse Key down to highlight **Incoming Log** and press **OK**. If you have received any calls, they are displayed on the screen.

Backing up within a Menu

To go to the previous menu:

- ▶ Press **Clr**.

To go to the main menu:

- ▶ Press **ⓂEnd**.

Viewing the Menus

Menu Diagram

Menus let you check or change your phone settings. The following outline shows the menu structure.

Call Logs

- Outgoing Log
- Incoming Log
- Missed Log
- Erase Logs> Outgoing Log
- Incoming Log
- Missed Log
- All Logs

Messages

- Voicemail> Call
- Clear Count
- Page/Text> Inbox
- All Unread
- Add New Folder
- Edit Folder> Set Max# Msgs
- Filter
- Rename Folder
- Delete Folder
- Erase All Msgs
- Web Messages

Phone Book

- Find Name
- Find Speed Dial
- Add New Entry
- Add New Folder
- Add New Entry
- Edit Folder> Rename Folder
- Ringer Type
- Delete Folder
- Sort Name> First-Last
- Last-First
- Services> Account Info
- CustomerCare
- Dir Assist
- Prepaid
- Roadside Assist
- My Phone #

Roaming

- Set Mode> Sprint PCS
- Automatic
- Analog Only
- Call Guard

Scheduler

- Calendar (Week View or Month View)
- [Scheduled Events or Call Alarms]>
- Event/Alarm Details> Play Speaker
- Play Private
- Erase
- Edit> AM/PM
- Edit Alarm
- Edit Repeat
- Add New Memo
- Set End Time
- Edit Descript.
- Exit
- Add Event> Meeting
- Call Alarm
- Spcl Occasion
- Event
- Dining Appt.
- To Do List
- To Do List> [Scheduled To Do Items]
- Add Item
- Erase Items
- Memory> Erase Old
- Erase All
- View Details> Schedule> Erase Old
- Erase All
- Call Alarm> Erase All
- To Do List> Erase Done
- Erase All
- Go To Date
- Week View
- Month View
- Exit

Wireless Web

[Softkeys]

OK

Home

Help

Mark

BkMrks

Settings

Headline

Sounds> Volume> Ringer

Key Beep

Voice Prompt

Ringer Type> Voice Calls>

With Caller ID

Phonebook Fldr

No Caller ID

Roaming

Messages>

Vicemail

Page/Text

Wireless Web

Alarms

Data Calls

Fax Calls

Alerts> Service

Messages

Minute Minder

Display> Backlight

Contrast

Alarm Mode

Data/Fax (In)

Car Use> Any Key Answer

Auto Answer

More...> Select Setup

Copy Settings

Security

Lock Phone

Change Lock

Restrict Calls> Outgoing> Allow All
PhoneBook Only
Special# Only
Incoming> Allow All
PhoneBook Only
Special# Only

Off

Special #s

Erase PhoneBook

Reset Phone

Calculator

equals

add

subtract

multiply

divide

decimal pt

Games

Blackjack

Football

Dice

Voice Services

Record Memo

Memo List> [Recorded Memos]>

Play Speaker

Play Private

Erase Memo

Edit Title

Add to

Schedule

Record Ringers> [Recorded Ringers]>

Record

Erase

Commands

Voice Dial List> [Voice Dial Tag]>

Play Voice Dial

Erase

KeyGuard

[Activates KeyGuard]

**Tip:**

To capitalize a letter, press the Mouse Key up before entering it.

Entering Characters by Tapping the Keypad

Your Sprint PCS Touchpoint Phone™ provides convenient ways to enter letters, punctuation or numbers. (See “Entering Characters Using T9 Text Input” on page 143 and “Entering Symbols and Numbers” on page 144.)

When you create Phone Book entries or enter titles for memos and folders, you enter characters by tapping the keypad. Press the corresponding key until the desired character appears. By default, the first letter of a word is capitalized and following letters are lowercase. Characters scroll in the following order:

- ▶ **1** 1.?, '&-@()~_
- ▶ **2** ABC2abc2
- ▶ **3** DEF3def3
- ▶ **4** GHI4ghi4
- ▶ **5** JKL5jkl5
- ▶ **6** MNO6mno6
- ▶ **7** PQRS7pqrs7
- ▶ **8** TUV8tuv8
- ▶ **9** WXYZ9wxyz9
- ▶ **0** Space 0
- ▶ **#** Forward
- ▶ ***** Backward

After a character is entered, the cursor () automatically advances to the next space after two seconds or when you enter a character not on the same key.

To enter characters by tapping the keyboard for Scheduler event descriptions or To Do items:

1. Highlight the character input softkey by pressing the Mouse Key once to the right.
2. Press **Ok** until **ALPHA** (for capital letters) or **alpha** (for lowercase letters) is displayed.
3. Enter characters by tapping the keypad.

If you make a mistake, press **Clr** to erase a single character, or press and hold **Clr** to delete the entire entry.

Entering Characters Using T9 Text Input

T9 Text Input enables you to quickly and conveniently enter text for Scheduler event descriptions, To Do items or Web Browser messages.

To use T9 Text Input when entering text:

1. Highlight the character input softkey by pressing the Mouse Key once to the right.
2. Press **Ok** until **T9WORD** (for capital letters) or **T9word** (for lowercase letters) is displayed. (The cursor changes to the down arrow symbol on the Mouse Key.)
3. Enter text by pressing the key your desired character appears on only once. (You can use **1** to enter Smart Punctuation.)

T9 Text Input analyzes the letters you enter using an intuitive word database and creates a suitable word. (The word may change as you type.) If the word you want does not display after you have entered all the letters, press the Mouse Key down to scroll through additional word selections. To accept a word and insert a space, press **0**.

**Tip:**

You can also scroll through the character input softkey options by pressing the Mouse Key up.

**Tip:**

You can also scroll through the character input softkey options by pressing the Mouse Key up.

**Tip:**

To capitalize a letter, press the Mouse Key up before entering it.

16

Selecting Your Accessories

In this Section

- Overview of Available Accessories for this Phone
- How to Order

We offer a variety of accessories for your new Sprint PCS Phone™. Choose from any of the following options which are all designed to give you more flexibility and convenience.

If the word you want does not display as an option, you can add it to the database.

To add a word to the T9 Text Input database:

1. Highlight the character input softkey by pressing the Mouse Key right.
2. Press **Ok** until **ALPHA** (for capital letters) or **alpha** (for lowercase letters) is displayed.
3. Enter the word using multi-tap text entry. (See “Entering Characters by Tapping the Keypad” on page 142.) The word will appear as an option the next time you scroll through options during T9 Text Entry.

If you make a mistake, press **Clr** to erase a single character, or press and hold **Clr** to delete the entire entry.

Press ***** to move the cursor left or **#** to move the cursor right.

Entering Symbols and Numbers

When you create Phone Book entries and To Do items or enter titles for memos and folders, you can enter symbols or numbers by tapping the keypad. (See “Entering Characters by Tapping the Keypad” on page 142.)

For Scheduler event descriptions, To Do items or Sprint PCS Wireless Web messages, you can select symbols or numbers for the character input mode.

1. Press the Mouse Key right and highlight the character input softkey.
2. Press **Ok** until **SYM1** (for symbols) or **NUM** (for numbers) is displayed. If you select **SYM1**, you can press the Mouse Key down to display additional symbols
3. Enter a symbol or number by pressing the appropriate key.



Tip:

You can also scroll through the character input softkey options by pressing the Mouse Key up.

Accessory Options

Standard Battery

The standard battery provides approximately 3.75 hours of continuous talk time in digital mode and 1 hour of continuous talk time in analog mode or approximately 200 hours of continuous standby time in digital mode and 25 hours continuous standby time in analog mode. The battery charges in about 2 hours using any of the charging accessories available with this phone.

Cigarette Lighter Adapter

You can charge your phone (even during a call) in your vehicle using the cigarette lighter adapter.

Portable Hands-Free Car Kit

Allows you to operate your phone hands-free so you can drive safely. This accessory connects to your car's cigarette lighter port and does not require installation. It also charges the phone's battery.

Desktop Charger

The Desktop Charger uses an AC adapter and is provided with your phone for convenient charging.

Travel Charger

Compact and lightweight, this is a convenient way to charge your phone while on the road.

Sprint PCS Wireless Web™ Connection Kit

Lets you link your phone to a laptop PC, hand-held or palm-sized computing device to send and receive email messages and browse the Internet. Includes serial data cable, cable adapter, CD-ROM (with software) and user guide. Designed for Microsoft® Windows 95, 98, NT, CE and Palm® operating systems.

How to Order

Most Sprint PCS Accessories found at local Sprint PCS Centers can also be purchased through the Sprint PCS Accessory HotlineSM by calling 1-800-974-ACC1 (2221). Next day delivery is offered in select areas. You can also visit our web site at www.sprintpcs.com.

Knowing Performance and Safety Guidelines

In this Section

- ▶ Getting the Most Out of Your Reception
 - ▶ Maintaining Safe Use and Access to Your Phone
 - ▶ Caring for the Battery
 - ▶ Acknowledging Special Precautions and the FCC Notice
-

Part of getting the most out of your Sprint PCS Phone™ is knowing where and how it works at optimum efficiency. This section outlines performance and safety guidelines that ensure you experience the full quality your Sprint PCS Phone was designed to give you.

Getting the Most Out of Your Reception

Keeping Tabs on Signal Strength

The quality of each call you make or receive depends on the signal strength in your area. Your phone informs you of the current strength by displaying a number of bars next to the signal strength icon. The more bars displayed, the stronger the signal.

If you're inside a building, being near a window may give you better reception.

Understanding Power Save Feature

If your phone is unable to find a signal after 15 minutes of searching, a Power Save feature is automatically activated. If your phone is on, it periodically rechecks service availability or you can check yourself by pressing any key. Anytime the Power Save feature is activated, a message displays on the screen. When a signal is found, your phone returns to Standby mode.

Understanding How Your Phone Operates

Your phone is basically a radio transmitter and receiver. When it's turned on, it receives and transmits radio frequency (RF) signals. When you use your phone, the system handling your call controls the power level. This power can range from 0.006 watts to 0.2 watts in digital mode.

Knowing Radio Frequency Safety

The design of your Sprint PCS Phone complies with updated NCRP standards described below. To further limit RF exposure, you can limit the duration of your calls and operate your phone in the most power-efficient manner.

In 1991-92, the Institute of Electrical and Electronics Engineers (IEEE) and the American National Standards Institute (ANSI) joined in updating ANSI's 1982 standard for safety levels with respect to human exposure to RF signals. More than 120 scientists, engineers and physicians from universities, government health agencies and industries developed this updated standard after reviewing the available body of research. In 1993, the Federal Communications Commission (FCC) adopted this updated standard in a regulation. In August 1996, the FCC adopted hybrid standard consisting of the existing ANSI/IEEE standard and the guidelines published by the National Council of Radiation Protection and Measurements (NCRP).

Emergency Calls

IMPORTANT!

This phone, like any wireless phone, operates using radio signals, wireless and landline networks as well as user-programmed functions, which cannot guarantee connection in all conditions. Therefore, you should never rely solely upon any wireless phone for essential communications (e.g. medical emergencies).

You may wish to dial a number other than 911 including "0" or a pre-programmed local number to a particular emergency response department. To save or edit customized emergency numbers, see "Using One-Touch/Two-Touch Speed Dialing" on page 35 or "Using Special Numbers" on page 94.

Remember, to make or receive any calls the phone must be switched on and in a service area with adequate signal strength. Emergency calls may not be possible on all wireless phone networks. Check with local service providers.

Note:

For the best care of your phone, only Sprint PCS authorized personnel should service your phone and its accessories. Faulty service may void the warranty.

**Tip:**

If you really need to use your phone while you're driving, use a headset, Speed Dialing or Voice Dialing.

Maintaining Your Phone's Peak Performance

There are several simple guidelines to operating your phone properly and maintaining safe, satisfactory service.

- ▶ Hold the phone with the antenna up and over your shoulder.
- ▶ Try not to ever hold, bend or twist the phone antenna.
- ▶ Don't use the phone if the antenna is damaged.
- ▶ Speak directly into the mouthpiece.
- ▶ Avoid exposing your phone and accessories to rain or liquid spills. If your phone does get wet, immediately turn the power off and remove the battery. If it's inoperable, return it to a Sprint PCS Center or call Sprint PCS Customer Care for service.
- ▶ Avoid exposing your phone and accessories to rain or liquid spills. If your phone does get wet, immediately turn the power off and remove the battery. If it's inoperable, return it to a Sprint PCS Center or call Sprint PCS Customer Care for service.

Maintaining Safe Use of and Access to Your Phone

FAILURE TO FOLLOW THE INSTRUCTIONS OUTLINED IN THIS SECTION MAY LEAD TO SERIOUS PERSONAL INJURY AND POSSIBLE PROPERTY DAMAGE

Using Your Phone While Driving

Talking on your phone while driving is illegal in some states. Even where it's not, it can divert your attention from driving. Remember that safety always comes first.

When using your phone in the car:

- ▶ Get to know your phone and its features, such as speed dial and redial.
- ▶ When available, use a hands-free device.
- ▶ Position your phone within easy reach.
- ▶ Let the person you are speaking to know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions.
- ▶ Do not take notes or look up phone numbers while driving.
- ▶ Dial sensibly and assess the traffic; if possible, place calls when you are not moving or before pulling into traffic.
- ▶ Do not engage in stressful or emotional conversations that may divert your attention from the road.
- ▶ Dial **9 1 1** to report serious emergencies. It's free from your wireless phone.
- ▶ Use your phone to help others in emergencies.
- ▶ Call roadside assistance or a special non-emergency wireless number when necessary.

Following Safety Guidelines

To operate your phone safely and efficiently, always follow any special regulations in a given area. Turn your phone off in areas where use is forbidden or when it may cause interference or danger.

**Tip:**

Purchase an optional Hands-Free Car Kit.

Performance
and Safety
17

Note:

Always turn off the phone in healthcare facilities and request permission before using the phone near medical equipment.

Using Your Phone Near Other Electronic Devices

Most modern electronic equipment is shielded from radio frequency (RF) signals. However, RF signals from wireless phones may affect inadequately shielded electronic equipment.

RF signals may affect improperly installed or inadequately shielded electronic operating and entertainment systems in motor vehicles. Check with the manufacturer or its representative to determine if these systems are adequately shielded from external RF signals. Also check with the manufacturer regarding any equipment that has been added to your vehicle.

Consult the manufacturer of any personal medical devices, such as pacemakers and hearing aids, to determine if they are adequately shielded from external RF signals.

Turning Off Your Phone Before Flying

Turn off your phone before boarding any aircraft. To prevent possible interference with aircraft systems, the U.S. Federal Aviation Administration (FAA) regulations require you to have permission from a crew member to use your phone while the plane is on the ground. To prevent any risk of interference, FCC regulations prohibit using your phone while the plane is in the air.

Turning Off Your Phone in Dangerous Areas

To avoid interfering with blasting operations, turn off your phone when in a blasting area or in other areas with signs indicating that two-way radios should be turned off. Construction crews often use remote-control RF devices to set off explosives.

Turn off your phone when you're in any area that has a potentially explosive atmosphere. Although it's rare, your phone or its accessories could generate sparks. Sparks could cause an explosion or a fire resulting in bodily injury or even death. These areas are often, but not always, clearly marked. They include:

- ▶ Fueling areas such as gas stations
- ▶ Below deck on boats
- ▶ Fuel or chemical transfer or storage facilities
- ▶ Areas where the air contains chemicals or particles such as grain, dust or metal powders
- ▶ Any other area where you would normally be advised to turn off your vehicle engine

Restricting Children's Access to Your Phone

Your Sprint PCS Phone is not a toy. Children should not be allowed to play with it because they could hurt themselves and others, damage the phone or make calls that increase your phone bill.

Note:

Never transport or store flammable gas, liquid or explosives in the compartment of your vehicle that contains your phone or accessories.

Caring for the Battery

Protecting Your Battery

The guidelines listed below help you get the most out of your battery's performance.

- ▶ Use only Sprint PCS-approved batteries and desktop chargers. These chargers are designed to maximize battery life. Using other batteries or chargers voids your warranty and may cause damage.
- ▶ In order to avoid damage, charge the battery only in temperatures that range from 32° F to 113° F (0° C to 45° C).
- ▶ Don't use the battery charger in direct sunlight or in high humidity areas, such as the bathroom.
- ▶ Never dispose of the battery by incineration.
- ▶ Keep the metal contacts on top of the battery clean.
- ▶ Don't attempt to disassemble or short-circuit the battery.
- ▶ The battery may need recharging if it has not been used for a long period of time.
- ▶ It's best to replace the battery when it no longer provides acceptable performance. It can be recharged hundreds of times before it needs replacing.
- ▶ Don't store the battery in high temperature areas for long periods of time. It's best to follow these storage rules:

Less than one month:

-4° F to 140° F (-20° C to 60° C)

More than one month:

-4° F to 113° F (-20° C to 45° C)

Disposal of Lithium Ion (Lilon) Batteries

For safe disposal options of your Lilon batteries, contact your nearest Sprint PCS-authorized service center.

Special note: Be sure to dispose of your battery properly. In some areas, the disposal of batteries in household or business trash may be prohibited.

Acknowledging Special Precautions and the FCC Notice

FCC Notice

The phone may cause TV or radio interference if used in close proximity to receiving equipment. The FCC can require you to stop using the phone if such interference cannot be eliminated.

Vehicles using liquefied petroleum gas (such as propane or butane) must comply with the National Fire Protection Standard (NFPA-58). For a copy of this standard, contact the National Fire Protection Association, One Batterymarch Park, Quincy, MA 02269, Attn: Publication Sales Division.

Cautions

Any changes or modifications to your phone not expressly approved in this document could void your warranty for this equipment and void your authority to operate this equipment. Only use approved batteries, antennas and chargers. The use of any unauthorized accessories may be dangerous and voids the phone warranty if said accessories cause damage or a defect to the phone.

Although your phone is quite sturdy, it is a complex piece of equipment and can be broken. Avoid dropping, hitting, bending or sitting on it.



Tip:

For safety, do not handle a damaged or leaking Lilon battery.

Body-Worn Operation

To maintain compliance with FCC RF exposure guidelines, if you wear a handset on your body, use a holster or other body-worn accessory. Use of non-Sprint PCS approved accessories may violate FCC RF exposure guidelines. The phone has not been tested for body-worn operation with the phone placed in a pants, shirt or other similar pocket.

For body worn operation, this phone has been tested and meets FCC RF exposure guidelines when used with an accessory that contains no metal and that positions the handset a minimum of 1.5 centimeters from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines.

For more information about RF exposure, please visit the FCC website at www.fcc.gov/oet/rfsafety.

Specific Absorption Rate (SAR) for Wireless Phones

The SAR is a value that corresponds to the relative amount of RF energy absorbed in the head and body of a user of a wireless handset.

The SAR value of a phone is the result of an extensive testing, measuring and calculation process. It does not represent how much RF the phone emits. All phone models are tested at their highest value in strict laboratory settings. But when in operation, the SAR of a phone can be substantially less than the level reported to the FCC. This is because of a variety of factors including its proximity to a base station antenna, phone design and other factors. What is important to remember is that each phone meets strict federal guidelines.

All phones must meet the federal standard, which incorporates a substantial margin of safety.

FCC Radio Frequency Emission

This phone meets the FCC Radio Frequency Emission Guidelines. FCC ID number: LXC-E330. More information on the phone's SAR can be found from the following FCC website: <http://www.fcc.gov/oet/fccid>

Owner's Record

The model number, regulatory number and serial number are located on a nameplate inside the battery compartment. Record the serial number in the space provided below. This will be helpful if you need to contact us about your phone in the future.

Model: Sprint PCS Touchpoint Phone™ (TP3300)

Serial No.:

User Guide Proprietary Notice

CDMA Technology is licensed by QUALCOMM Incorporated under one or more of the following Patents:

4,901,307 5,109,390 5,267,262 5,416,797

5,506,865 5,544,196 5,657,420 5,101,501

5,267,261 5,414,796 5,504,773 5,535,239

5,600,754 5,778,338 5,228,054 5,337,338

5,710,784 5,056,109 5,568,483 5,659,569

5,490,165 5,511,073

T9 Text Input is licensed by Tegic Communications and is covered by U.S. Pat. 5,818,437, U.S. Pat. 5,953,541, U.S. Pat. 6,011,554 and other patents pending.

Index

A

Accessories 145
 Activating Your Phone 4
 Answering Calls 27

B

Backlight 86
 Battery
 Capacity 16
 Charging 17
 Installing 16
 Removing 16

C

Calculator 108
 Call Alarm
 Alerts 71
 Editing 102
 Internal Phone Book 71
 Menu 72
 Scheduler 99
 Viewing 100
 Call Guard 22
 Call Logs
 Erasing 46
 Making a Call 43
 Options 43
 Saving a Phone Number 45
 Viewing 42
 Call Waiting 48
 Caller ID 48
 Commands
 Options 133
 Training 132
 Using 132
 Contrast 86

D

Data/Fax Mode 87
 Desktop Charger 17
 Dialing Options 28
 Display Screen 14



E

End-of-Call Options 31

Entering Characters

Symbols and Numbers 144

Tapping the Keypad 142

Using T9 Text Input 143

F

4-Digit Dialing 34

Filters 60

Finding a Phone Number 33

Forwarding Calls 50

G

Games 109

I

In-Call Options 29

Incoming Call Notification 30

Internal Phone Book

Adding a Folder 77

Adding a New Entry 66

Adding a Phone Number 70

Editing a Phone Number 74

Editing an Entry 73

Entry Details 74

Entry Options 69

Finding Entries 67

Moving Entries 77

Secret Entries 76

Sorting Entries 79

K

KeyGuard 15

L

Locking Your Phone 92

M

Making Calls 26

Memos

Adding to Your Scheduler 130

Options 129

Recording 128

Menu Tree 138

Missed Call Notification 27

Muting 39

N

Numeric Paging

Creating Folders 59

Displaying 56

Filters 60

Moving Messages 62

New Messages 55

Options 57

Prepending 64

Storage 56

P

Pauses 33

R

Recordable Ringers

Options 131

Recording 131

Ringer Type

Examples 83

for Alarms, Data Calls and Fax Calls 85

for an Entry 76

for Messages 84

for Phone Book Folders 78

for Voice Calls 84

Roaming

Analog Cellular Networks 20

Call Guard 22

Other PCS CDMA Networks 20

Roam Mode 21

S

Safety Guidelines 149

Saving a Phone Number 32

Scheduler

Adding an Event 96

Editing Events 101

Event Alert Menu 98

Event Alerts 97

Viewing Events and Call Alarms 100

Viewing the Calendar 107

Security

Accessing the Menu 92

Changing the Lock Code 92

Resetting Your Phone 94

Restricting Calls 93

Unrestricting Calls 93

Settings

Alarm Mode 87

Alert Notification 85

Copying Settings 90

Current Setup 89

Headline 82

Speakerphone 26

Special Numbers 94

Speed Dialing 35

Sprint PCS Services

- Billing Information 7
- Customer Care 6
- Dialing 79
- Directory Assistance 7
- Operator Services 7

Sprint PCS Wireless Web Alerts

- Displaying 55
- New Alerts 55

Sprint PCS Wireless Web Browser

- Browser Menu 119
- Ending a Session 119
- Launching a Session 113
- Troubleshooting 120
- Using 115

Sprint PCS Wireless Web Connection

- Ending a Call 124
- Placing a Call 123
- Receiving Calls 123
- Setting up 122

Sprint PCS Wireless Web Messaging

- Creating Folders 59
- Displaying 56
- Extracting Phone Numbers 63
- Filters 60
- Moving Messages 62
- Options 58
- Prepending 64
- Sending 53
- Storage 56

Sprint PCS Wireless Web Updates 125

T

Three-Way Calling 49

To Do Items

- Adding as an Event 105
- Deleting 106
- Editing 104
- Viewing 103

Tone Length 86

Turning Your Phone On and Off 15

U

Unlocking Your Phone 4, 92

V

Voice Services

- Voice Dial Options 133
- Voice Dialing 128

Voice mail

- Clearing the Icon 54
- New Alerts 53
- Retrieving Messages 54
- Setting Up 5

Volume

- Conversation 38
- Ringer 38
- Ringer and Key Beep 82
- Voice Prompt 83