


HeNA



**USER MANUAL
MID-80Q8**

Features

Browse the Web.
Visit your favorite websites

Check your e-mail
Keep in touch with friends and family

Watch YouTube™ videos
Browse the world's most popular
video-sharing community

Read your favorite books
Download thousands of books .

Discover many Windows app

Connect to the Internet wirelessly
High-speed Wi-Fi 802.11 b/g/n networking


Enjoy your media library anywhere
Portable powerhouse plays popular music,
video, and photo formats

TF card increases your storage capacity
(up to 32 GB supported)

Built-in camera
Convenient front-facing and rear camera

Automatic orientation detection
Read any way you want; the display adjusts
automatically!

Unit at a Glance



1. POWER

Press to turn the unit on, or to turn the screen on or off.

Press and hold to access the Power Off menu. Keep pressing power button for 3 seconds and device will reset automatically.

2. Volume+/Volume-

3. USB

Connect to a USB device.

4. Headphone

Audio output connection for headphones.

5. TF CARD 6. HOME

7. FRONT CAMERA

8. REAR CAMERA

9. MIC

Safety Information

Read the safety information before using the tablet.



witch off in restricted areas

Switch the device off when mobile PC use is not allowed or when it may cause interference or danger, for example, in aircraft, in hospitals or near medical equipment, fuel, chemicals, or blasting areas. Obey all instructions in restricted areas.



road safety comes first

Obey all local laws. Always keep your hands free to operate the vehicle while driving. Your first consideration while driving should be road safety.



interference

All wireless devices may be susceptible to interference, which could affect performance



qualified service

Only qualified personnel may install or repair this product.



batteries, chargers, and other accessories

Use only batteries, chargers, and other accessories approved by S805Gfor use with this device. Third-party chargers that comply with the IEC/EN 62684 standard, and that can connect to your device micro USB connector, may be compatible. Do not connect incompatible products.



keep your device dry

Your device is not water-resistant. Keep it dry.



glass parts

The device screen is made of glass. This glass can break if the device is dropped on a hard surface or receives a substantial impact. If the glass breaks, do not touch the glass parts of the device or attempt to remove the broken glass from the device. Stop using the device until the glass is replaced by qualified service personnel.

Charging the Battery

Charging the Battery

The tablet has a built-in battery and the battery comes partially charged. You must fully charge the battery before using your device for the first time. After the first charge, you can use the device while charging. Always charge the battery using the 5V/2A power adapter provided.

Charging via power adapter


Connect the standard USB end of the USB cable to the power adapter. Connect the Micro-USB end of the USB cable to your tablet. Then plug the power adapter into the mains socket.

OR

Charging via the USB cable

Connect the standard USB end of the USB cable to your PC. Then connect the Micro-USB end of the USB cable to the  port of the tablet.

An indicator light above the power button will illuminate, indicating charging is in progress.



If the battery is completely discharged, you cannot turn on the device, even with the USB power adapter connected. Allow a depleted battery to charge for a few minutes before you try to turn on the device.


Note: You cannot sufficiently charge the battery using the USB cable and your PC due to incorrect current.

To check the battery status, tap the battery icon on the bottom of the screen.

Turning the Tablet On or Off

The following screen drawings are only for reference and please refer to actual screen drawings.

To turn on your tablet


1. Press  and hold for about 2 seconds to turn on your tablet.
2. If the lock screen image displays, swipe your finger from the bottom of the display to switch to the login screen, and then enter password to log in to Windows.



- Please first create a Microsoft account.

The tablet is ready for use after the Windows Start screen displays.





To turn off the screen

- When the tablet is turned on, press  to turn off the screen to save battery power.
- Or you can swipe from the right edge of the display to access the menu. Tap All Settings to display the settings. Tap System → Power & Sleep to set the screen to be turned off after a set time period.

NOTE: If your tablet is in a sleep state, press  or tap home button  to turn on the screen.

To turn off the tablet

- Press  and hold until you see “Slide to shut down your PC” on the screen. Slide to shut down your tablet.



- You can also turn off the tablet in desktop and tablet modes:


In desktop mode, tap  on the bottom of the screen to access the menu.

Tap Power→Shut down to turn off the tablet.




To turn off the tablet in tablet mode, first enable the tablet mode by swiping the screen from the right to access the menu. In addition to the action center, it also allows access to general settings like airplane mode, rotation lock, and Wi-Fi.

Tap Table mode to enable the tablet mode. Tap Power→Shut down to turn off the tablet.



Built-in Applications

Windows 10 comes with built-in apps like Map, Photos, Mail & Calendar, Music and Video. And these apps use OneDrive to back up your information and sync seamlessly across your Windows 10 devices, so you're never far from what you need.



Touch-Screen Navigation

Your tablet has a multi-touch display. You can touch the screen to operate the tablet.



Swipe right

Swiping-in from the right edge of the display reveals the menu. This menu provides access to the action center and general setting options.



Swipe left

Swiping slowly from the left edge to the right edge of the display reveals thumbnails of the applications.



Swipe down

Swiping-in from the top to the bottom of an application docks or closes the application.

Connecting Your Tablet to a Wi-Fi Network

1. Tap the Wi-Fi symbol on the bottom of the screen. Tap Wi-Fi to enable the Wi-Fi function.
 - A list of available wireless networks will appear.
2. Tap a network to connect to it.
3. If you want your tablet to automatically connect to the network when it's available, tap Connect automatically.
4. Tap Connect.
5. If prompted, type your network security key (network password), and then tap Next.
6. Choose whether or not you want to share with other computers and devices on the network.
 - Choose No if you're connecting to a network in a public place like a Café.To disconnect from a wireless network
 1. Tap the Wi-Fi symbol and then tap the network with a connected status.
 2. Tap Disconnect.

Troubleshooting

1.1 Device can not connect to Wi-Fi

- Ensure the wireless network is working by testing it using another wireless device.
- Ensure the device and the wireless router is within the range of the wireless network to be connected too. Walls or other obstructions will reduce the possible distances between wireless devices.
- Ensure the security password being used is correct.
- 1.2 Device doesn't turn on
 - You can not turn on the device when the battery charge is below the critical level, please charge the battery.
 - Press the Power button for 10s times on the device and check if it is restarting is normally or not.
 - Check if the charger is connected correctly.

1.3 Heat Issues

- When running multiple applications, using the screen on its brightest setting, or when being charged, this device can get quite hot. This is normal and should not cause any inconvenience when in use.

1.4 System has anomalies and doesn't work correctly

- Installing some third-party applications may cause the system not to operate correctly. Press the Power button for 10s times device will Re-boot.

1.5 Cannot set E-mail or registration application

- Ensure that the MID is connected to a Wi-Fi network and can connect to the Internet.
- Ensure you E-mail settings have been entered correctly for the account being accessed.
- Make sure your system time and local time are correct.

1.6 Can not record

- Press the Power button for 10s times, then check if the record function works correctly.

1.7 The stand-by time of the device is too short

- The duration of the lithium battery varies with environmental temperature changes and the service conditions. If the environment temperature is too low or too high, the duration of the battery will be affected. It is recommended to use this device at normal temperature.

- Battery life is dependent on usage. High volume, WIFI, and the frequent use may cause the battery to be drained at a higher rate.

1.8 No sound via earphone

- Please check if the volume setting is 0
- Please check if audio file is broken, and try to play another audio file to confirm. If the audio file is broken, it may cause severe noise or static.

1.9 The color distortion of video or picture display

Troubleshooting

– Press the Power button for 10s times on the device to resolve this issue.

1.10 Can not copy files

-- Please check if the device is connected to the computer correctly.

– Please check if the memory space is full

-- Please check if the USB cable is broken.

1.11 Other troubles

Please follow up the next step to fix the other troubles before you return the MID/Tablet PC to us:

-- Step 1: Press the Power button for 10s times, then check if the function works correctly;

-- Step 2: Upgrade the firmware from the CD and restart the MID/Tablet PC, then check if the function works correctly.

Specifications

Processor	INTEL Z3735G WINDOWS	
Storage	RAM	1G
	ROM	16 GB
Display	8" IPS (1280X800), Capacitive touch screen	
Wi-Fi Networking	IEEE 802.11 b/g/n	
Audio Output	3.5mm headphone	
PC Interface	USB 2.0 high speed	
Camera	Front	0.3 M
	Rear	2 M
Operating System	WINDOWS 10	
Power	Rechargeable Li-poly battery power Adapter(DC IN 5V,2A)	
Speakers	1x0.8W speaker	

FCC Warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.