


SUNON®

S-RF1
Remote Control

Operating Instructions



	Button	Function
	1-6	Press each button to turn on the fan then you can set up the air volume. The number stands for air volume from low to high in numerical order (1 lowest to 6 highest volume).
	0	Press the button to turn off the fan
	↻	Press the button to switch the fan direction, when the fan : Ventilation: airflow move upwards. Reverse: airflow move downwards.
	0 + ⚙️	Press this two button at same time to enter pairing process. After pairing process is completed, direction of the fan will be initialized to ventilation (Downward airflow).
Remote Control Pairing - Only needed for first time setup - After turn on the power, it must enter the pairing process in one minute - If you fail to pairing, please turn off the power and restart above process 5 minutes later		

Battery installation

- Remove the battery cover and install 2 AAA batteries.
- Remove the batteries when not used for a long time. Please recycle the used batteries.

Operating Instructions

1. Make sure the fan blades are standstill before you turn on the fan every time.
2. Press 0 to turn off the fan, DO NOT touch the fan and fan blade once its standstill.
3. Once you press any buttons, the fan will receive the final order and spin direction. DO NOT touch the fan and blades during the procedure.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

EU Compliance Statement

Hereby Sunonwealth Electric Machine Industry Co.,Ltd. declares that the radio equipment type[S-RF1/S-RF1-R designation of type of RE] is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:www.sunon.com/tw/

This Equipment is required to have a CE Mark on the Label which means that the equipment has been tested to the following Directives and Standards:This equipment has been tested to the requirements for the CE Mark as required by Radio Equipment Directive 2014/30/EU as indicated in European Standard EN 300 and EN 301 and the EMC Directive 2014/30/EU as indicated in European Standard EN 55014.

The operating frequencies and maximum transmission power levels for wireless devices operated in the EU are listed below:

433.92MHz:-18.45dBm.

Model:S-RF1/S-RF1-R

SUNON®

Sunonwealth Electric Machine Industry Co., Ltd.

80673 No. 30, Ln. 296, Xinya Rd., Qianzhen Dist., Kaohsiung City 806, Taiwan (R.O.C.)

www.sunon.com

E-mail : sunon@sunon.com