

LXT110

ALIGNMENT PROCEDURE

1. REFERENCE TEST EQUIPMENT

- A. HP8921A Cell site test set or HP8920A, B Communication Test Set with Spectrum Analyzer option.
- B. Fluke 187 Digital Voltmeter
- C. HP E3615A Power supply

2. TEST POINT

| | |
|--------------------------|---|
| A. ANTENNA | : Test point is not prepared. Use antenna contact with ANTENNA_GND_T(antenna ground). |
| B. VCO reference voltage | : Test point TP1 is prepared. |
| C. RX audio output | : Test point SPKOUT is prepared or use ear-jack(3.5mm). |
| D. TX Mic. Input | : Test point MICIN is prepared or use ear-jack(2.5mm) with 10uF coupling capacitor. |
| E. Battery Vcc | : Test point TP2 is prepared. |
| F. Up Key | : Test point UP is prepared. |
| G. Down Key | : Test point DW is prepared. |
| H. Function Key | : Test point Menu is prepared. |
| I. Monitor Key | : Test point SCAN is prepared. |
| J. PTT Key | : Test point PTT is prepared. |

Note. : All key can be activated when connect with ground.

3. VCO ALIGNMENT

- A. Set unit to Channel 1 and connect a voltmeter to TP1 (VCO PD).
- B. Press & hold PTT.
- C. Extend L303 until the voltmeter reads 1.2V.
- D. ***Cover shield-plate on VCO can and monitor the voltage on TP1.*** The voltage should be 1.2Vdc +/-0.2Vdc. If the voltage is not 1.2Vdc +/-0.2Vdc, realign L303 until meet to requirement.
- E. Release PTT button so units is in receiving mode and monitor the voltage on TP1. The voltage should be in the range 1.0Vds +/-0.3V
- F. Set unit to channel 14.
- 6. Press & hold the PTT switch and observe the voltage on TP4. The voltage should be 1.5 – 2.5 Vdc.
- 7. Release PTT and observe the voltage on TP4. The voltage should read between 1.5 - 2.5 Vdc.

Note : VCO shield-can should be soldered after VCO alignment is finished.

4. TRANSMITTER FREQUENCY ALIGNMENT

- A. Press & hold the PTT button.
- B. Align CT201 trimmer capacitor such that the output frequency is equal to the channel frequency with a maximum error of +/- 200 Hz. CT201 is located on the left side of 20.95MHz X-tal.

LXT110 ALIGNMENT PROCEDURE

5. TRANSMITTER OUTPUT POWER CONFIRMATION

- A. Set unit to channel 1 and power Hi mode.
- B. Press & hold the PTT button.
- C. Transmit power should normally be between 0.35W to 0.8W.
- D. Set unit to channel 14.
- E. Press & hold the PTT button. Ensure that Tx Power should be between 0.35-0.8W.

6. TRANSMITTER DEVIATION ALIGNMENT

- A. Connect an audio generator (600 ohms) to the ear jack. The audio frequency should be set at 1KHz with a level of 200mV RMS.
- B. Connect an FM deviation meter (communications test set) to Antenna contact. Set the monitor to read peak to peak divided by two [(pk-pk)/2] deviation. Set filter of equipment from 25Hz to 15KHz.
- C. Press & hold the PTT button.
- D. Align RV2 for +/- 2.0 kHz deviation (+/-0.1KHz). RV2 is located on the bottom of the VCO shield can.
- E. Decrease audio generator level until deviation reads +/- 1.5 kHz (approximately 7mV) and record generator level. Level should be between 4 mV and 10 mV.
- F. Confirm that transmit audio distortion is less than 5%.

7. RECEIVER ALIGNMENT

- A. Set the output level of the RF signal generator for -47dBm. The generator should be set for 1.5 kHz deviation at 1 kHz audio.
- B. Set volume level 4 (It is initial.).
- C. Connect Audio analyzer to SPKOUT.
- D. Set equipment filter 25Hz to 15KHz.
- E. Confirm that Rx Sensitivity is less than -119dBm (nominally -121dBm) by reducing the output level of the RF signal generator until a 12 dB SINAD reading is achieved.
- F. Set signal generator level to -47dBm.
- G. With 1.5KHz deviation at 1KHz modulation, set volume for maximum audio. Audio level should be on over than 1.4Vrms.

8. BATTERY INDICATOR CONFIRMATION

- A. Set unit to receiving mode. Don't set transmitter mode..
- B. Set power supply voltage to 4.5V.
- C. Decrease power supply voltage until low battery icon blinks.

9. POWER OFF CURRENT CONSUMPTION

- A. Set power supply voltage to 6V and connect to unit.
- B. Confirm current. It must be less than 300uA.

10. FREQUENCIES TABLE

| Channel | Freq. MHz | Channel | Freq. MHz |
|---------|-----------|---------|-----------|
|---------|-----------|---------|-----------|

LXT110
ALIGNMENT PROCEDURE

| | | | |
|----|----------|----|----------|
| 1 | 462.5625 | 12 | 467.6625 |
| 2 | 462.5875 | 13 | 467.6875 |
| 3 | 462.6125 | 14 | 467.7125 |
| 4 | 462.6375 | 15 | 462.5500 |
| 5 | 462.6625 | 16 | 462.5750 |
| 6 | 462.6875 | 17 | 462.6000 |
| 7 | 462.7125 | 18 | 462.6250 |
| 8 | 467.5625 | 19 | 462.6500 |
| 9 | 467.5875 | 20 | 462.6750 |
| 10 | 467.6125 | 21 | 462.7000 |
| 11 | 467.6375 | 22 | 462.7250 |

LXT110

LABORATORY TESTING PROCEDURES

UNIT TEST - (UNIT ASSEMBLED)

TEST PREPARATION

- 1) Install 3 "AAA" alkaline batteries (observe polarity markings).
 - Right middle terminal is the system plus polarity
 - Left bottom terminal is the system minus polarity.
- 2) Press the power button.

SYSTEM TEST

- 1) Radiated Transmit and Receive performance may be observed.
- 2) Audio out & Audio in are available at the Headset jack.

LABORATORY TEST - (UNIT UN-ASSEMBLED)

TEST PREPARATION

- 1) Disassemble unit (6 screws – 2 behind batteries). Remove the PCB from the cabinet.
- 2) Remove the antenna and install a 50 ohm coax cable in its place.
- 3) Either clip alligator leads or solder test leads to the power supply connections. The positive terminal is the lower left PCB mounting hole. The negative terminal is the lower right PCB mounting hole top of the 20.95MHz X-tal. (battery side view)
- 4) Connect 4.5VDC power source to the terminals, observing correct polarity.
- 5) Connect an 12-ohm load through the Headset jack (3.5mm mono-phone plug).
- 6) Connect a audio generator with 10uF coupling capacitor through the Headset jack (2.5mm mono-phone plug).
- 7) Select desired channel 1- 22 using CH up/down keypad switch. The rubber keypad may be removed from the front cabinet and used directly on the PCB.

LXT110

LABORATORY TESTING PROCEDURES

SPECIFIC TEST METHODS AND GUIDANCE

Modulation Characteristics – (*paragraph 2.1047(a) of the Rules*)

FOR TX AUDIO FILTER RESPONSE

1. Connect audio generator with 10uF coupling capacitor to microphone input jack. Press PTT button.
2. Connect RF output with modulation meter. (Filters of modulation meter should be set to a 50Hz to 15KHz.)
3. Adjust audio generator about 3-5mVrms for 0.75KHz modulation.
4. While transmitting, sweep generator and note measurement.
5. Please compensate the back-ground noise level.

Modulation Characteristics – (*paragraph 2.1047(b) of the Rules*)

FOR TX AUDIO LOW PASS FILTER RESPONSE.

1. Connect audio generator with 10uF coupling capacitor to microphone input jack. Press PTT button.
2. Connect AC voltmeter or other test equipment via jumper wire to TP9.
3. Adjust audio generator for 200mV.
4. While transmitting, sweep generator and note measurement.

Occupied Bandwidth – (*paragraph 2.1049(c) of the Rules*)

1. Connect an audio frequency sweep generator with 10uF coupling capacitor to microphone input jack.
2. Adjust audio generator to a frequency of 2500Hz and a level of 100mV rms (+16dB above 10-12mV per FCC).
3. With a spectrum analyzer, transmit the radio and monitor the transmitter though an antenna.
4. Note required measuements per FCC.

LXT110

PRODUCTION SPECIFICATION

1. GENERAL SPECIFICATION

| | Items | Specifications |
|----|---|---|
| 1 | Tx Frequency range | 462.550MHz ~ 467.7125MHz |
| 2 | Tx VCO Frequency range | Same as item 1 |
| 3 | RX Frequency range | Same as item1 |
| 4 | RX VCO Frequency range | 441.150MHz ~ 446.3125MHz (Lower Heterodyne) |
| 5 | Channel Number Channel Spacing | 22CH 12.5KHz |
| 6 | Frequency Control | PLL Synthesizer with Temperature Compensated Crystal Reference |
| 7 | IF frequencies | 21.4 MHz for 1'st IF 450KHz for 2'nd IF |
| 8 | Modulation | FM (F3E emissions) |
| 9 | Standard Test Modulation signal | Modulated audio Frequency : 1KHz Test modulation : +/-1.5KHz |
| 10 | TX Frequency stability | Max. +/-2.5ppm (-20°C to +50°C) |
| 11 | Nominal test temperature Range | 25°C +/- 5°C |
| | Extreme operating temperature Range | -20°C to +50°C |
| 12 | Antenna Impedance | 50 ohm +/- 25 ohm |
| 13 | Power source | 3 AAA Alkaline batteries or 3 AAA Ni-HM rechargeable batteries |
| 14 | Test Power Supply Voltage | 4.5Vdc. +/-0.1Vdc |
| | Extreme Supply Voltage Range | 3.0Vdc to 5.0Vdc |
| 15 | Battery life time (Typ. 5/5/90 duty) | Min. 35 Hours |
| 16 | Microphone | Self contained Electret |
| 17 | Speaker | Self contained 8 ohm |

LXT110

PRODUCTION SPECIFICATION

2. DETAILED SPECIFICATION

A. RECEIVER SECTIONS

* Normal test condition *

| | TYP. | LIMIT |
|--|------------------------|----------------------------|
| 1. MAXIMUM USABLE SENSITIVITY * 1KHz +/-1.5KHz DEV. * REF. CHANNEL 1 & 8 | -122dBm | <-119dBm |
| 2. 20dB QUIETING SENSITIVITY * 1KHz +/-1.5KHz DEV. * REF. CHANNEL 1 & 8, 12dB SINADDER | -116dBm | <-114dBm |
| 3. ADJACENT CHANNEL TWO SIGNAL SELECTIVITY & SENSITIZATION * +/- 1 CHANNEL SPACING | | >50dB |
| 4. INTER-MODULATION SPURIOUS RESPONSE ATTENUATION | | >50dB |
| 5. SPURIOUS EMISSIONS * CONDUCTIVE CONNECTION | | <-53dBm |
| 6. RECEIVE FREQUENCY RESPONSE * REF. 1KHz +/-1.5KHz DEV. 300Hz 3KHz | -4.0dB -17.0dB | +/-2.0dB +/-3.0dB |
| 7. AUDIO OUTPUT LEVEL * REF. 1KHz +/-1.5KHz DEV. * (No LOAD) * Volume Max. | 1.5V | >1.4V |
| 8. AUDIO OUTPUT DISTORTION * REF. 1KHz +/-1.5KHz DEV. * (No LOAD) | 3% | <5% |
| 9. MAX. S/N RATIO * REF. 1KHz +/-1.5KHz DEV. * (No LOAD) | 36 dB | >30dB |
| 10. RX VCO REF. VOLTAGE * REF. CHANNEL 1 * REF. CHANNEL 8 | 1.0V 2.0V | +/-0.3V +/-0.3V |
| 11. SQUELCH THRESHOLD * REF. 1KHz +/-1.5KHz DEV.* | 9dBsinadder | -3dB - +3dB |
| 16. CURRENT CONSUMPTION * Un-squelched Volume Max. * Squelched * Power Off | 200mA 35mA 200uA | +/-40mA <40mA <300uA |

LXT110

PRODUCTION SPECIFICATION

B. TRANSMITTER SECTIONS

| | TYP | LIMIT |
|---|------------------------------|----------------------------------|
| 1. TRANSMITTER FREQUENCY TOL. * REF. CHANNEL 1 | | <+/-200Hz |
| 2. TRANSMITTER RF POWER * REQUIRED CONDUCTIVE CONNECTION * REF. CHANNEL 1 Hi Power (DC4.5V) | 0.6W | +0.2W / -0.3W |
| 3. TRANSMITTER OCCUPIED BANDWIDTH * REQUIRED CONDUCTIVE CONNECTION * REF. CHANNEL 1 @12.5KHz | | <-50dBc |
| 4. TRANSMITTER SPURIOUS * REQUIRED CONDUCTIVE CONNECTION * REF. CHANNEL 8 | | <-50dBc |
| 5. MODULATION SENSITIVITY * REF. 1KHz AUDIO * CHANNEL 1 , @+/-1.5KHz | 7mV | +/-3mV |
| 6. MODULATION LIMITING * REF. 1KHz AUDIO, CHANNEL 1 * (INPUT AUDIO ; 200mVrms) | +/-2.0KHz | +/-0.2KHz |
| 7. MODULATION AUDIO DISTORTION * REF. 1KHz AUDIO +/-1.5KHz | 3% | <5% |
| 8. TX AUDIO FREQUENCY RESPONSE * REF. 1KHz AUDIO, CHANNEL 1 * (INPUT AUDIO ; 3mVrms) 300Hz 3KHz 6KHz | -15.0dB +6.0dB -16.0dB | +/-3.0dB +/-3.0dB +/-3.0dB |
| 9. TX MODUALTION S/N * REF. 1KHz AUDIO, CHANNEL 1 * (REF. INPUT AUDIO ; 12mVrms) | 35dB | >30dB |
| 10. TX VCO REF. VOLTAGE * CHANNEL 1 * CHANNEL 14 | 1.5V 2.5V | +/-0.3V +/-0.3V |
| 11. CURRENT CONSUMPTION * DC 4.5V | 400mA | +/-150mA |

LXT110
TX AUDIO TEST RESULT

Frequency Response of Audio Low Pass Filter (150mV input)

| | 3K | 4K | 5K | 6K | 7K | 8K | 9K | 10K | 15K | 20K |
|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|------------|------------|------------|
| #1 | 0 | -8.15 | -15.8 | -21.1 | -25.4 | -28.7 | -32.4 | -34.9 | -46.5 | -51.5 |
| #2 | 0 | -8.20 | -16.2 | -21.3 | -25.7 | -29.2 | -32.5 | -35.3 | -46.7 | -52.1 |

Frequency Response of the Audio Low Pass Filter

LXT110 #1
LXT110 #2

