
 <p><b>Hella GmbH &amp; Co. KGaA</b> 59552 Lippstadt</p>	<p>Date: 2022-04-04</p> <p>No.:</p> <p>Page 1</p>
<h1>User's Guide</h1>	
<p>Subject: RS 6.0 – Advanced driver assistance system – User's Guide</p> <p>Ref.:</p>	

## RS 6.0 – User's Guide




This document is confidential. Its contents are not to be exploited, passed on or disclosed to third parties without our express permission. All rights are reserved.

The RS 6.0 is an advanced driver assistant system, to warn the driver of the ego vehicle against potential collisions with other road users to the side, to the rear and to the front of the ego vehicle.

This system is not meant to encourage aggressive driving. The absence of a warning will not guarantee the absence of other road users. Responsibility for the safe operation of the vehicle remains with the driver.

Hella 3399EN (2000-05)


signed by:	checked by:
------------	-------------

 Hella GmbH & Co. KGaA 59552 Lippstadt	Subject:	Date: 2022-04-04
	RS 6.0 – Advanced driver assistance system – User’s Guide	No.:
		Page 2 of 6

# 1 Functions


The sensor is capable to detect other objects. With this recognition capability it can cover the following functionalities:

## 1.1 Blind-spot detection and lane-change warning




These functions monitor the neighboring lanes and warn the driver of the ego vehicle when an intended lane change could cause a collision with other traffic participants.

## 1.2 Rear traffic alert




This function monitors the difficult to see zone at the rear side of the ego vehicle and warns the driver against possible collisions with other moving road users when reversing out of a parking space.

## 1.3 Pre-crash rear



This document is confidential. Its contents are not to be exploited, passed on or disclosed to third parties without our express permission. All rights are reserved.


 <b>Hella GmbH &amp; Co. KGaA</b> 59552 Lippstadt	Subject:	Date: 2022-04-04
	RS 6.0 – Advanced driver assistance system – User's Guide	No.:
		Page 3 of 6

This function monitors the lane behind the ego vehicle and initiates safety measures when a crash from behind is unavoidable.

#### 1.4 Safe exit




This function monitors the area next to the car doors on the passenger's and on the driver's side to the back and to the front and warns the driver if the car door cannot be opened safely.

 <b>Hella GmbH &amp; Co. KGaA</b> 59552 Lippstadt	Subject:	Date: 2022-04-04
	RS 6.0 – Advanced driver assistance system – User's Guide	No.:
		Page 4 of 6

## 2 System Architecture

The system consists of two or more radar sensor units which are mounted hidden behind plastic surfaces in the corners and/or the sides of a vehicle.

Each unit communicates with a vehicle central processing unit via ethernet.




**Block diagram of system architecture.**

### Technical Data

Supply voltage	+9 V ... +18 V
Power consumption	Typ. 4.3 W
Operating temperature range	-40°C ... +85°C
Operating frequency range	76000 MHz ... 79000 MHz
Modulation bandwidth	900 MHz resp. 1700 MHz
Modulation	FMCW (fast chirps) plus phase-coding
Antenna feed power	10 dBm (peak), 1.23 dBm (average)
Antenna type	Waveguide slot array
Transmit antenna Tx1 gain	11 dBi
Transmit antenna Tx2 gain	11 dBi
Transmit antenna Tx3 gain	11 dBi

Because of the simultaneous operation of all three transmitters with identical frequency, from outside of the radar sensor a single effective transmitter can be assumed with an effective gain of  $11 \text{ dBi} + 10 \log(3) = 15.77 \text{ dBi}$ .

 Hella GmbH & Co. KGaA 59552 Lippstadt	Subject:	Date: 2022-04-04
	RS 6.0 – Advanced driver assistance system – User's Guide	No.:
		Page 5 of 6

### 3 Vehicle Integration

Since RADAR waves can penetrate plastics, the sensor integration is possible behind the bumper fascia and thus invisible from the exterior. However, the plastic and other materials which surround the sensor may cause bending, refraction and reflection of the RADAR waves. Distances, clearances, selected radii and other constructive elements in their arrangement can lead to constructive or destructive interference of the RADAR waves. That must be avoided by choosing a suitable integration position.

The sensors should be positioned in the vehicle at a height of 400 to 700 mm above the road surface. If that cannot be fulfilled, then the deviating installation height must be agreed upon with Hella GmbH. & Co. KGaA.

#### 3.1 Spatial orientation of the sensors

The RS6.0 sensors can be mounted in the front and/or rear area of a vehicle under defined angles:


**Rear side integration:** approx. 45 deg



**Front side integration:** approx. 45 deg



This document is confidential. Its contents are not to be exploited, passed on or disclosed to third parties without our express permission. All rights are reserved.

 Hella GmbH & Co. KGaA 59552 Lippstadt	Subject:	Date: 2022-04-04
	RS 6.0 – Advanced driver assistance system – User's Guide	No.:
		Page 6 of 6

**Note:** This User's Guide is not intended for the end user. The RS6.0 Advanced Driver Assistance System is not sold separately from the vehicle and the end user instructions of the radar will be provided by the OEM.

#### USA:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radio frequency radiation exposure Information: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

#### Canada (both English and French language required):

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.;

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Cet équipement est conforme aux limites d'exposition aux rayonnements ISED établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps. Ce transmetteur ne doit pas être placé au même endroit ou utilisé simultanément avec un autre transmetteur ou antenne.

This document is confidential. Its contents are not to be exploited, passed on or disclosed to third parties without our express permission. All rights are reserved.