

Attachment

User's Manual

WARNING

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Notice:

- (1) Use only shielded cables to connect I/O devices to this equipment.*
- (2) Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.*

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


SERIAL&PS/2 MOUSE USERS MANUAL

MODEL NO : SR2000 、 SP2000 、 SR3000 、 SP3000

CABLE, ADAPTER&CONNECTORS:

The serial mouse cable is 5 ft long coiler cable. Ther mouse cable is comected to computer host unit through a 9-pin D-subminiature corector. If you have a ps/2 port, you can connect an adapter on the 9-pin D-subminiature connector to change the serial mouse as a ps/2 mouse. The following figure lists the connector pins and their signals.

SP2000/SP3000
6 Pin MINI-DIN Connector



SR2000/SR3000
9 Pin D-subminiature Connector



Description (PS/2)	MINI-DIN CONNECTOR	D-SUB CONNECTOR	Description (SERIAL)
	PIN		
—		1	Reserved
—		2	RXD
Vcc	4	3	TXD
—		4	Reserved
GROUND	3	5	GROUND
DATA	1	6	DSR
Vcc	4	7	RTS
CLOCK	5	8	CTS
—		9	reserved