

INSTRUCTION MANUAL

PAIRING AND SENSOR ACTIVATION

Pairing: Consult your Ant + or Bluetooth Smart device's instructions for pairing. Sensor will need to be activated directly before pairing process.

Sensor Activation: To verify proper position install as below, spin wheel or turn crank more than two revolutions. Initial sensor activation will be indicated by the LEDs flashing up to 10 times.

Please Note: The sensor will stay active for at least 20 minutes although the LEDs no longer flash.


Bluetooth Smart Connection: Install and activate sensor. Turn on your phone's (or other compatible device) Bluetooth Smart capability. Open the desired cycling app and follow instructions for Bluetooth Smart sensor connection.

Please note, Bluetooth Smart devices do not always appear in your phone's listing, even when connected.


All apps collect, share, and display speed and cadence information differently.

INSTALLATION

INSTALLATION FOR SPEED SENSOR



INSTALLATION FOR CADENCE SENSOR



SPECIFICATION

- 1 Electrical:**
 - 1.1 Supply power: 3.0Vdc (CR2032)
 - 1.2 Battery Life: 1 years
 - 1.3 Communication protocol: ANT+ / Bluetooth Smart
- 2 Mechanical:**
 - 2.1 Water resistance: IPX7
 - 2.2 Dimension: 42mm x 36mm x 16.5mm (main body)
- 3 Environmental:**
 - 3.1 Operating temperature: 0°C ~ +60°C
 - 3.2 Storage temperature: -20°C ~ +70°C
- 4 Function:**
 - 4.1 Range: 0.1km/h ~ 99.9km/h(SPEED), 30rpm ~ 240rpm (CADENCE)
 - 4.2 Indication light: White (SPEED), Green (CADENCE)
 - 4.3 Accuracy: +/-0.1Km/h or 1% whichever is larger
 - 4.4 Transmission range: 3 meter (min.)
 - 4.5 Auto power down: 20 minutes

FCC ID: O4GBKM5AB

FCC STATEMENT

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

The grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The RF Exposure Compliance distance is 20mm.

IC:7666A-BKM5AB

IC Statement

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

CAN ICES-3(B)/NMB-3(B)

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) il ne doit pas produire de brouillage et

(2) l'utilisateur du dispositif doit être prêt à accepter tout brouillage radioélectrique reçu, même si ce brouillage est susceptible de compromettre le fonctionnement du dispositif.

CAN ICES-3(B)/NMB-3(B)

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la section 2.5 de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 millimeters between the radiator and your body.

Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ou émetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 20 millimètres entre le radiateur et votre corps.