



INSTRUCTIONS

REMOTE CONTROL SHARK




Requires 3 x 1.5V "AAA" R03 batteries.

CONTROLLER



Requires 2 x 1.5V "AAA" R03 batteries.

WATER ACTIVATED




INSTALLING THE BATTERIES:

- Unscrew and open battery compartment cover to insert batteries in the toy as shown in diagram. Close the cover and tighten the screw.
- Use 2 "1.5V" batteries on controller, type "AAA/R03" or equivalent (not included).
- Use 3 "1.5V" batteries on remote control shark, type "AAA/R03" or equivalent (not included).
- Use only the batteries recommended.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Do not mix old and new batteries.
- Remove batteries when toy is not in use.
- Remove used batteries from toy and dispose of in accordance with the maker's recommendation.
- Do not attempt to recharge non-rechargeable batteries.
- Do not use rechargeable batteries.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Batteries are to be inserted with the correct polarity.
- The supply terminals are not to be short-circuited.
- Non-rechargeable batteries are not to be recharged.

WARNING: Dispose of used batteries immediately. Keep new and used batteries away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

If the shark swims slower, it is an indication of weak batteries. Please replace with new batteries to resume normal speed.



HOW TO PLAY:

- Put the batteries into the remote controller and press the ON/OFF button.
- To switch off the remote, simply press the on & off button for 2 seconds and the LED light will turn "off".
- Put the batteries into the RC Shark.
- Place RC Shark into the water for activation.
- The LED on the remote control will remain "on" once it is connected with the shark. If connection is disrupted, the LED will start flashing on and off. If this happens, make sure the shark is placed in water so the remote control can remain connected with it.

CAUTION:

- This product is a children's toy that will swim in water through the 2.4GHz wireless remote control.
- The RC Shark & remote control possesses the waterproof function.
- Operate only in calm, clear water for the RC Shark. Pools and shallow are recommended.
- After each use, wipe with towel and allow to dry completely.
- Do not operate near concrete walls which may disturb transmission.
- The RC Shark is designed for operation in fresh water. Avoid in salt water operation. Do not submerge the RC Shark in water for a long time.
- The remote control will not power off by itself, so make sure to switch off the remote after play.

WARNING: Never allow young children to play in or around water without adult supervision.

FCC ID: O9L-CT01-76155-1
O9L-CT01-76155-2

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.