GM-302 Mini Wireless Optical Mouse

Hardware Installation

- 1. Insert batteries, ensuring they are in the right direction.
- Plug receiver into computer's port. The "Lock LED" light turns on.

ID Code Configuration

- Press the button on the receiver to unlock the receiver , the "Lock LED" light turns off.
- Press the ID button on the bottom of the mouse. When the Lock light on the receiver is lit, the mouse is set up with a random ID and the receiver is locked.

To avoid potential interference, the receiver is automatically locked after configuration. Ensure the receiver is unlocked before configuration or the product will not function.

Program Resolution

The Agilent ADNS-2030 optical sensor is used in this device. The default resolution is 800 cpi, however, it can be programmed to 400 cpi by re-inserting the batteries while pressing the wheel button of the mouse. If go back to default 800 cpi, just re-insert the batteries again without pressing the wheel button of the mouse

Re-install or re-insert the batteries

Please configure ID code again every time you re-insert the batteries.

When to use extension USB to USB cable

For Desktop PC use, plug USB extension cable to receiver. Place the receiver to where the best transmission performance is achieved. This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions.

- 1) This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

Per FCC 15.21, you are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

