# A3 size (Black & White) - English - FRONT

# US\_F17\_FL\_5F62D85\_IM





### Contents Battery Requirement 1. Vehicle: 5 x 1.5V 'AA" batteries RC Vehicle (Vehicle) x 1

2. Transmitter: 1 x 9V battery





For Vehicle

1 x 9V For Transmitter ( Not Included )

**EN** 

5=62D85

# Antenna for RC Transmitter x 1 **Battery Precaution**

RC Transmitter (Transmitter) x

- Alkaline batteries are recommended to be used
- Only batteries of the same or equivalent type as recommended are to be used
   Do not mix alkaline, standard or rechargeable batteries
   Do not mix old and new batteries or different type of batteries
- Non-rechargeable batteries are not to be charged

- Non-rechargeable batteries are into to be charged.
   If rechargeable batteries are to be used, they are only to be charged under adult supervision.
   Rechargeable batteries are to be removed from the product before they are charged.
   Be sure to insert batteries with correct polarities and always follow the battery manufacturer's instructions.
- 9. Remove all batteries from the Vehicle and Transmitter when not in use
- 10. Exhausted batteries are to be removed from the product
   11. The supply terminals are not to be short-circuited
- 12. Dispose of batteries property. Do not dispose the batteries in fire it may cause them to explode or leak causing injury or damage 13. Battery installation and removal must only be done by adult


# **Battery and Antenna Installation**


- For Vehicle (Fig. 1 and Fig. 2)

  1. Switch OFF the power.

  2. Unscrew the screw on the battery cover.


  3. Open the battery cover.
- 4. Install 5 new 1.5V "AA" batteries with correct polarities (+/-) as shown inside the battery compartment.





# For Transmitter (Fig. 3 and Fig. 4)

- 1. Switch OFF the power
- 2. Unscrew the screw on the battery cover
- 3. Open the battery cover
- 4. Install 1 new 9V battery with correct polarities (+/-) as shown inside the battery compartment
- 6. Tighten the screw or the battery cover
- 7. Insert the antenna into the top of Transmitter, tighten it by rotating clockwise
- (viewing from top of Tranmitter)



# **BACK**

- How to Play

  1. Switch the vehicle ON

  2. Use the Forward / Backward joystick (Fig.3) to drive the Vehicle forward and backward
- 3. Use the Left / Right joystick (Fig.3) to control the Vehicle turning left or right
- 3. Use the Lett / Agin ( physick ( rig. 3) to bothlor the vehicle turning lain to right
   4. If the vehicle does not run in a straight line, adjust the Direction Adjustment on the vehicle chassis (Fig. 1)
   5. Play on a smooth surface for optimum performance
   6. After playing, remember to switch the power OFF, on the Vehicle and Transmitter

- 7. The cotimum control range is up to 33 feet (10m) outdoors

### **Performance Tips**

- Do not drive on grass, dirt, sand, dusts, carpet or go through water
- Do not drive in windy or rainy weather
   Avoid direct impact with obstacles
- Switch the power OFF when not in use to prevent damage due to battery leakage
   Remove all batteries from the Vehicle and Tramsmitter when not in use for long period
- 6. Keep fingers, hair and loose clothing away from wheels
- The operating range can be affected by a variety of factors
   a) Low Voltage of batteries in Transmitter or Vehicle
   b) Interference from other items that emit radio frequency signals

- 8. Outdoor usage is recommended in order to get optimum control range
- Play with the vehicle on a clean smooth surface
   Clean the battery compartment to make sure it is free from dust to prevent poor battery contact

- 1. Do not attempt to disassemble the Vehicle or Transmitter
- 7. Do not accompt to bias-before the Vehicle with same frequency with other player(s) in the same location. This can cause the vehicle to lose control 3. Make sur his battery are at last and utility correct polarities (+/-) as shown inside the battery compartment 4. Remove the packages are tasked util accessories before giving the Vehicle and Transmitter to child

## FCC label compliance statement:

- This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

  1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These imits are designed to provide reasonable protection against harmful interference in a residential insaliation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. Newwey, there is no guarantee that inferierence will not occur in a particular installation. If this equipment flose scause harmful interierence to radio communicate Howevey, there is no guarantee that inferierence will not occur in a particular installation. If this equipment does cause harmful interierence by radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

  Recrient or relocate the receiving antenna

  Increase the separation between the equipment and receiver

  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

  Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This radiocommulication device complies with all the requirements of Industry Canada Standard RSS-310. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

**Declaration of Conformity**The product is in conformity with the requirement of EU Directive 1999/5/EC

### Environmental notes:

The whole product also does not belong to household waste at the end of the product life.

You can return it at collection points for the recycling of electronic and electronical instruments

The symbol on the Item, instruction manual, hangtag or packing is showing this clearly.

Materials should be recycled according to their respective markings.

Recycling of old devices or other re-use of materials contained therein represents an important contribution to environmental protection.

Please ask at your local community for the correct collection point.

Batteries should not be disposed of in the household waste. As the consumer you are legally obliged to return batteries containing harmful substances and all other used batteries You can hand in your old batteries at public collection points in your area or wherever batteries are sold.

You will find these chemical abbreviations along with a crossed-out refuse bin on batteries containing harmful substances



Cd=Battery contains cadmium







The packaging and instruction manual comain important immuniation. Please keep them for future reference. Warning Choking Hazard. Not suitable for children under the age of 3 years due to small parts. We reserve the first to improve/emend specifications and colors without notice. Warning! The Antenna of vehicle is not to be inserted into socket outlets.

The packaging and instruction manual contain important information.

EN LOS ESTADOS UNIDOS PONT TOTS: "FL'US, NIC., WAYNE, NJ 0'7470 MPRIETE DEI VINDORIET PARIMOPITADO POR! TOTS: "R'US (CÀMADA) LTD. (ITÉE), 2777 LANGSTAFF RIAD, CONCORD, ON LAK AMS DIGITBILITED A NASTRALL RY (DISTRIBLE EN AUSTRALLE PRAPINSTRIBUIDO EN AUST TOYS: "R'US (AUSTRALIA (AUSTRALIE) PTY LTD. (IDÉE), REGENTS PAPK NSW 2143