



RC T-REX

87415

3+
age

Instruction Manual

2.4G RADIO CONTROL T-REX

Contents

- RC T-Rex x 1
- RC Transmitter x 1
- Water Pump x 1
- Instruction Manual x 1

15M / 49FT
Range



RC Transmitter x 1





RC T-Rex x 1



Water Pump x 1

BATTERY REQUIREMENTS:

 **3 x AA**
For T-Rex
(Included for try-me)

 **2 x AA**
For Transmitter
(Not Included)

Battery Precaution

1. Alkaline batteries are recommend
2. Only batteries of the same or equivalent type as recommended are to be used
3. Do not mix alkaline, standard, or rechargeable batteries
4. Do not mix old and new batteries or different types of batteries
5. Non-rechargeable batteries are not to be charged
6. If rechargeable batteries are to be used, they are only to be charged under adult supervision
7. Rechargeable batteries are to be removed from the product before they are charged
8. Be sure to insert batteries with correct polarities and always follow the battery manufacturer's instructions
9. Remove all batteries from the T-Rex and Transmitter when not in use
10. Exhausted batteries are to be removed from the product
11. The supply terminals are not to be short-circuited
12. Dispose of batteries properly / do not dispose the batteries in fire - it may cause them to explode or leak causing injury or damage
13. Battery installation and removal must only be done by an adult





Battery installation

For T-Rex (Fig. 1 and Fig. 2)


1. Switch the power button to OFF position
2. Unscrew the battery cover
3. Open the battery cover
4. Install 3 new 1.5V "AA" batteries with correct polarities (+/-)
5. Close the battery cover
6. Tighten the screw on the battery cover

For Transmitter (Fig. 3 and Fig. 4)

1. Unscrew the battery cover
2. Open the battery cover
3. Install 2 new 1.5V "AA" batteries with correct polarities (+/-) as shown inside the battery compartment
4. Close the battery cover
5. Tighten the screw on the battery cover



How to fill with water for smoking effect



1. Please prepare a cup of clear tap water. Keep squeezing and releasing the provided water pump to fill with the water. (Fig.5)



2. Open the water tank cap on the T-Rex. (Fig.6)



3. Squeeze the provided water pump to fill the water tank into the T-Rex. (Fig.7)




4. Close the water tank cap firmly. (Fig.8)

Trouble shooting for 2.4GHz pairing in case of no signal


1. Switch OFF the T-Rex and Switch ON to re-start.
2. Re-install batteries to the transmitter.
3. The transmitter signal light will flash for 7-8 seconds.
4. After the LED light of the transmitter stops flashing, the pairing process is complete for playing.
5. If pairing cannot be completed within 8 seconds, please turn off the T-Rex and re-start the pairing process.
6. When the pairing process is done, whenever switching the T-Rex on and off, it searches for the code that is memorized and will only lock on to the transmitter signal contained that code.
7. If the pairing signal disconnected, please turn off the T-Rex and re-install the batteries in the transmitter. The pairing process will be completed after turning on the T-Rex again.

How to play


1. Plug the T-Rex tail in the body. Switch ON the T-Rex



2. Press the left button of the transmitter to control the T-Rex moving forward



3. Press the right button of the transmitter for light, sound and smoking effect



4. Play on a smooth surface for optimal performance
5. Remember to switch OFF the power of the T-Rex after playing
6. The optimal control range is up to 15M / 49FT

Performance Tips

1. Do not operate T-Rex on grass, dirt, sand, dusts, carpet or go through water.
2. Do not operate T-Rex in windy or rainy weather.
3. Avoid direct impact with obstacles.
4. Switch OFF the power when not in use to prevent damage of T-Rex due to leakage of electrolyte from batteries.
5. Remove all batteries from the T-Rex and Transmitter when not in use for long period.
6. Keep fingers, hair and loose clothing away from wheels.
7. The operating range can be affected by a variety of factors
 - a) Low Voltage of batteries in Transmitter or T-Rex
 - b) Interference from other items that emit radio frequency signals.
8. Outdoor usage is recommended in order to get optimal control range.
9. Play with the T-Rex on a clean and smooth surface.
10. Clean the battery compartment to make sure it is free from dust to prevent poor contact of batteries

Cautions

1. Do not attempt to disassemble the T-Rex or Transmitter
2. Make sure the batteries are installed with correct polarities (+/-) as shown inside the battery compartment
3. Remove the package and take out all accessories before giving the T-Rex and Transmitter to child to play

The packaging and instruction manual contain important information. Please keep them for future reference.

We reserve the right to improve/amend specifications and colors without notice.

FCC Label Compliance Statement:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna
 - Increase the separation between the equipment and receiver
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
 - Consult the dealer or an experienced radio/TV technician for help

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RSS-210 Compliance Statement:

This device complies with Industry Canada Licence-exempt RSS-210. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Declaration of Conformity

The product is in conformity with the requirement of EU Directive 2014/53/EU.

Environmental Notes:

The whole product also does not belong to household waste at the end of the product life.

You can return it at collection points for the recycling of electronic and electrical instruments

The symbol on the item, instruction manual, hangtag or packing is showing this clearly.

Materials should be recycled according to their respective markings.

Recycling of old devices or other re-use of materials contained therein represents an important contribution to environmental protection.

Please ask at your local community for the correct collection point.



Disposal of Batteries

Batteries should not be disposed of in the household waste. As the consumer you are legally obliged to return batteries containing harmful substances and all other used batteries. You can hand in your old batteries at public collection points in your area or wherever batteries are sold.



You will find these chemical abbreviations along with a crossed-out refuse bin on batteries containing harmful substances:

Pb=Battery contains lead

Cd=Battery contains cadmium

Hg=Battery contains mercury



www.kidztech.net



Conforms to the safety requirements of ASTM F963



KIDZTECH TOYS MANUFACTURING LTD.
Room 802, 8/F, Inter-Continental Plaza,
94 Granville Road, TST East, Hong Kong.
Tel: (852) 27218868 info@kidztech.net
Made in China http://www.kidztech.net

US OFFICE:

1540 Forest Avenue,
River Forest, IL 60305, USA

Tel: 708-689-0085 Fax: 708-689-8172

Frequency band: 2408-2475 MHz
Maximum radio frequency
power transmitted: <0dBm