

**Replace gaskets when installing new meter** 2.3

**Important! Be aware of maximum torque** 2.4

Maximum torque for 3/4": 11 ft-lb ✓

3/4" 11 ft-lb

Maximum torque for 1": 22 ft-lb ✓

1" 22 ft-lb

**Install meter in the correct direction of flow** 2.5

Correct direction

Wrong direction

**Info codes and display** 3

Info code	Meaning
	Possible leak
	Possible broken pipe
	Attempt of fraud
	Meter is missing water
	The water flows in reverse direction
	Flashes. The meter is still in transport mode
	Lights permanently. The radio is switched off
	Low battery

**Check the installation** 4.1

Installation is complete

Make sure the meter displays **DRY** and the desired unit of measurement

Open the water supply

**Check the installation** 4.2

Check that the display switches to **FLOW** and that the counter is in movement

Current display status... 287 GPM

...4 sec. later 053 ft³

The first 8 hours the meter operates in Installation Mode. The display will update every 4 seconds during Installation Mode, permitting the installer to confirm that the meter is properly operating. Every time the meter becomes dry and subsequently rewetted, Installation Mode will re-initiate

**Antenna mounting** 5

**Note:** For pit antennas use clamps 30-26-1211 and for top mounted antennas use clamps 30-26-1214.

**FCC Cautions** 6.1

**Caution:** Changes or modifications not expressly approved by the party responsible for compliance could void the users authority to operate the equipment.

**RF Exposure compliance statement:** This device may be used with no restrictions, since the source-based time-averaged output power is  $\leq 60/f(\text{GHz})$  mW.

**This device complies with Part 15 of the FCC Rules.**

**Operation is subject to the following two conditions:**

- 1 This device may not cause harmful interference, and
- 2 This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

**FCC Cautions** 6.2

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

www.kamstrup.com