

Operation and Installation Instructions:

Description:


The FM- stereo Wireless Transmitter is an electronic device, which receives stereo signals from any one of a multitude of sound producing equipment and then transmits these signals at the 89.8mHz band.

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determine by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment has been verified to comply with the limits for a class B computing device, pursuant to FCC Rules. In order to maintain compliance with FCC regulations, shielded cables is likely to result in interference to radio and TV reception. The user is cautioned that changes and modifications made to the equipment without the approval of manufacturer could void the user's authority to operate this equipment.

Connection Points:



Operation and Installation Instructions:

INSTALLATION:

1. Prepare the sound generating equipment with proper cabling and power.
2. Insert the correct stereo cabling into the sound generating equipment, stereo output.
3. Insert the stereo cable into the CDRF unit's 3.5mm stereo input.
4. Connect 12VDC power to the CDRF.
5. Turn on the stereo generating equipment.
6. If the stereo signal is being sensed by the CDRF it will turn on the LED. This will also signify that the stereo signal is being transmitted on 49.8mHz.
7. Listen to the stereo signal being transmitted by using a matching headset receiver.

OPERATION:

Normal operation is a matter of routine tasks-

1. Applying power to the sound generating equipment.
2. Placing the headset on your head and switching its power switch on.
3. Then adjusting the volume and left and right ear controls to your satisfaction.