



4. Configuration/Adjustments


- Set the gear lever to select driving speed. Select 'Hi' for high speed mode and 'Lo' for normal speed mode for easier control.




- Turn the steering axle adjuster at the bottom towards left when the vehicle drives to the right involuntarily. If it turns left involuntarily, turn the adjuster towards right.




- Some times the throttle signal between the racer and transmitter may need adjustment so the racer stays still in the idle mode. Adjust the throttle trimming dial to establish an idle setting for the vehicle. If the vehicle rolls forward by itself, turn the dial clockwise until it stops moving. Turn it anticlockwise to compensate for reverse idle.




- Rear Tires Replacement
Rear tires with larger diameter are available as replacement. Change to the spare rear tires to obtain top speed performance. It is recommended to get familiar with the control before using them.



- Set up the backflip ramp
 - Fold the flaps down to form a ramp. Place four pieces of cellular tape on the four corner edges to secure the ramp.



- Affix the paper ramp on the floor by two pieces of cellular tape.



Driving Tips:

- The turning speed and radius may vary at different control combination.
- Operate only on flat, smooth (but not slippery), dry surfaces and low pile carpet, as hair, carpet or dirt can affect the operation of the vehicle.
- Don't drive your vehicle in sand or through water or snow, if your vehicle gets wet, wipe with a towel and allow to dry completely.

5. Trouble Shooting

Symptom	Cause	Correction
Vehicle does not react, or react poorly to operation by transmitter.	- PAIRING / SYNC Procedure is not yet completed or done. - Out of the control range of distance. - Enter into power save mode.	- Pair the vehicle and the transmitter by press and hold both pairing buttons. - Vehicle runs distance up to 15 meters (or 50 feet) indoor. - Switch off the vehicle and turn on again.
The vehicle is not driving straight	- The vehicle is not adjusted properly. - The front and rear tires are misplace.	- Adjust the steering axle adjust. - Check the tires. If issue persists, try swapping left and right tires or insert them in different orientation.
Components are loose or detached.	- Bumpers or wheels are out of place.	- Insert the bumper to the slot in the front of the vehicle. - Place the tires evenly on the rims. The front tires are thinner and the rear tires are thicker.
Vehicle runs slowly or does not run.	- ON/OFF switch is not in "ON". - Low battery. - Hair, carpet or dirt might be trapped between wheels.	- Switch on the power. - Recharge the vehicle. - Carefully remove such foreign materials.

Like us on
facebook.com/SilverlitToys

Awesome videos of 3D Twister at
www.3DTwister.com



This product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

For ages 5+
Ab 5 Jahre
A partir de 5 ans
Leeftijd vanaf 5 jaar
A partir de 5 años
Dai 5 anni in su

Delivery Contents

- Vehicle
- Transmitter
- Instruction manual
- 2 x Spare Rear Tire
- 8 x adhesive tape
- Paper ramp

FCC Statements

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
1) This device may not cause harmful interference, and
2) This device must accept any interference received, including interference that may cause undesired operation.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Safety Precautions

- Parents, this toy is recommended for children. To ensure that your child's play is both safe and fun, please review the operating instructions with your children.
 - **DO NOT** pick up moving vehicle.
 - Keep hands, hair and loose clothing away from the tires and the wheel hubs when power switch is turned ON.
 - Remove battery from the toy when not in use.
 - **DO NOT** operate your vehicle on street. Avoid hitting people, pets or home furnishings.
- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The crossed-out dustbin symbol indicates that batteries, rechargeable batteries, button cells, battery packs, etc. must not be put in the household waste. Batteries are harmful to health and the environment. Please help to protect the environment from health risks. Tell your children to dispose of batteries properly by taking them to the local collecting points. This way batteries are recycled safely.

Waste Electrical and Electronic Equipment (WEEE)
When this appliance is out of use, please remove all batteries and dispose of them separately. Bring electrical appliances to the local collecting points for waste electrical and electronic equipment. Other components can be disposed of in domestic refuse.

Cautions:

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable battery are only to be charged by an adult.
- Different types of batteries or new and used batteries are not to be mixed. (Transmitter only)
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- Do not mix old and new batteries. (Transmitter only)
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries. (Transmitter only)

Care and Maintenance:

- Always remove batteries from the toy when it is not being used for a long period of time.
- Wipe the toy gently with a clean damp cloth.
- Keep the toy away from direct sunlight and/or direct heat.
- Do not submerge the toy into water that can damage the electronic assemblies.

Note:

- Parental guidance is recommended when installing or replacing batteries.
- Users should keep and retain this information for future reference.
- Users should keep strict accordance with the instruction manual while operation the toy.

Battery requirement for Transmitter:


- Power Supply : ---
- Rating : DC 6 V , 2.7 W
- Batteries : 4 x 1.5 V *AA/LR6/AM3(not included)

Battery requirement for Vehicle:

- Power Supply : ---
- Battery ratings : DC 3.7 V , 2 W
- Batteries : 1 x 3.7 V LiPo Rechargeable Battery Pack (included)
- Capacity : 75 mAh

Silverlit® Silverlit SAS, Espace Green Parc, Route de Villepele, 91280 Saint Pierre du Perray / France.
©2011 Silverlit. All rights reserved.




1. Part Identification



2. Battery Installation and Charging




Transmitter battery installation

- Switch off the transmitter
- Open the battery compartment by loosening the screw (fig. 1).
- Put 4 Type AA battery in the battery compartment as per the polarity shown inside (fig. 2).
- Place back the battery compartment cover (fig. 3).



Charging the vehicle

- Pull out the charging plug from the bottom of the transmitter (fig. 4).
- Switch off the vehicle. Insert the charging plug into the charging socket on the vehicle. Switch on the transmitter. The charging process will begin automatically and the charging indicator will light up (fig. 5).
- Unplug the charging plug after the charging indicator turns off. Charging is completed (fig. 6).



Note: 1. The vehicle can operate for about 4 - 5 minutes per every 12 - 20 minutes charging.
2. Before recharging the battery, wait 10 - 15 minutes for it to cool down.




The transmitter receives a signal from the car when the battery is low.
When the vehicle battery indicator on the transmitter starts blinking, recharge the vehicle..

3. Operation

3.1 Procedure for PAIRING / SYNCING the Vehicle and Transmitter

2.4 GHz technology allows for many racers to run without signal interference. A connection, or pairing, must be made between the car and the transmitter to function. Sometimes, the pairing will happen automatically. If it does not, or if the connection is lost then follow these steps to sync the racer and the transmitter.

- Turn the Power Switch button to 'ON' position both on the Vehicle and Transmitter, Red LED will then flash (fig. 7).
- Press the PAIR/SYNC button both on the Vehicle and Transmitter. The Synchronize/Pairing procedure is COMPLETED when you can see the Red LED light up solid (not blinking) on both Vehicle and Transmitter (fig. 8).
- Hold the transmitter with your left hand like holding a pistol (fig. 9). For better driving experience, crash feedback is integrated to the transmitter. The transmitter will vibrate when the vehicle hits an object.




3.2 Control

- Forward & Backward**
Pull throttle control (trigger) to drive the vehicle forward and push the throttle control away from you to drive in reverse.

TIPS!


To achieve maximum speed, operate the vehicle indoor on dust-free floor. Avoid driving it in thick /soft carpet. The vehicle may be damaged as a result.



- Turning Left & Right**
Rotate the steering wheel clockwise to steer the vehicle right and rotate the steering wheel counter clockwise to steer the vehicle left.

TIPS!

The car runs at very high speed. It will take practice to steer it precisely. Try it in low gear to start.



- Flipping System Switch**

The car is designed to know which side is on top, and it will send a signal back to the transmitter allowing the transmitter to steer right or left no matter which is on top. When the Flipping System switch is turned to OFF, the transmitter will not sense the flipping motion of the car, which will affect the steering. To have the best steering performance, keep the Flipping System Switch in the ON position.

