


Steering:

operate transmitter	engine position	submarine action
		parallel run forward
		vertical submerge
		parallel turn backward right
		vertical raise up




WARNING: Never allow young children to play in or around water without adult supervision.

Driving Tips:

- Operate only in calm, clear water for the submarine. Pools and shallow ponds are recommended.
- After each use, wipe with a towel and allow to dry completely.
- When your R/C Submarine runs erratically, the problem is usually the result of interference caused by high tension wires, radios, or other R/C toy running close by on the same frequency as yours. You may have to choose on alternate place to race.
- Do not operate near concrete walls which may disturb transmission.
- Your Submarine is designed for operation in fresh water. Avoid in salty water operation. Do not submerge the submarine & remote controller in water for a long time.

Trouble Shooting:

Symptom	Cause	Correction
Submarine does not react, or react poorly to operation by transmitter.	- High-frequency interference occurred near to high-voltage lines, transformers and some types of building.	- Avoid these if possible, or choose another place to operate the vehicle.
Loss of control	- Another radio control vehicle using the same frequency is operated near your vehicle. - Out of the control range of distance.	- Race against other vehicles using different frequencies. - Move to another place where without radio frequency interference from another device.
Submarine runs slowly or does not run.	- Loose battery connection - Main power switch is not in "ON" position. - Batteries are not placed in compartment correctly. - Batteries are exhausted.	- Check battery connection. - Switch on the power. - Check the battery polarity. - Replace all old batteries with new ones.




WARNING:
CHOKING HAZARD – Small parts.
Not for Children under 3 years.

FCC Statements

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
1) This device may not cause harmful interference, and
2) This device must accept any interference received, including interference that may cause undesired operation.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Operation:



THE AMAZING SPIDER-MAN
R/C Lizard chaser sub

Delivery contents:

- Submarine
- Remote controller
- Instruction manual



This product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Safety Precautions:

- Parents, this toy is recommended for children 5 years and older. To ensure that your child's play is both safe and fun, please review the operating instructions with your children. If toy in the presence of children under 5 years of age, adult supervision is recommended.
 - **DO NOT** pick up moving submarine
 - Keep hands, hair and loose clothing away from the engines when power switch is turned ON.
 - Remove battery from submarine and transmitter when not in use.
 - **DO NOT** operate your submarine near swimmers, stay behind the water's edge when operating.
- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RSS-310 OF INDUSTRY CANADA STANDARD

VALID FOR CANADA ONLY – This device complies with RSS-310 of Industry Canada Standard. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation of the device. This Category II radiocommunication device complies with Industry Canada Standard RSS-310. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that permitted for successful communication. Carrier frequency: 27.145 MHz Field strength: 56.25 dBuV/m@3m

The crossed-out dustbin symbol indicates that batteries, rechargeable batteries, button cells, battery packs, etc. must not be put in the household waste. Batteries are harmful to health and the environment. Please help to protect the environment from health risks. Tell your children to dispose of batteries properly by taking them to the local collecting points. This way batteries are recycled safely.

WEEE
When this appliance is out of use, please remove all batteries and dispose of them separately. Bring electrical appliances to the local collecting points for waste electrical and electronic equipment. Other components can be disposed of in domestic refuse.

Cautions:

- Non-rechargeable batteries are not to be recharged.
- Do not use rechargeable batteries.
- Different types of batteries or new and used batteries are not to be mixed.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.

Care and Maintenance:

- Always remove batteries from the toy when it is not being used for a long period of time.
- Wipe the toy gently with a clean damp cloth.
- Keep the toy away from direct sunlight and/or direct heat.
- Do not submerge the submarine and transmitter into water unless the battery compartment is properly closed and locked.

TIPS

Optimum performance can be only obtained by using new 24g alkaline batteries.

Note:

- Parental guidance is recommended when installing or replacing batteries.
- New and alkaline batteries are recommended to use in this toy to obtain best and maximum performance.
- You are advised to replace with new batteries as soon as the function becomes impaired.
- Interference will cause loss of control or uncontrolled running of vehicle if used in vicinity of cordless telephones, baby monitors, electronic devices or other radio controlled devices.
- To race 2 submarines at the same time, each must have a separate frequency. One with 27MHz, and the other with 49MHz. If both have the same frequency, their signals will interfere with each other.
- Users should keep and retain this information for future reference.
- Users should keep strict accordance with the manufacturer's instructions while operating the product.

Battery requirement for submarine:

- Power Supply : ---
- Rating : DC 3 V ; 0.36 W
- Batteries : 2 X 1.5V "AA"/LR6/AM3 (not included)

Battery requirement for Transmitter:

- Power Supply : ---
- Rating : DC 3 V ; 0.06 W
- Batteries : 2 X 1.5V "AA"/LR6/AM3 (not included)

Silverlit® (SLT USA) Inc. Suite# 220, 21660 East Copley Drive Diamond Bar, CA, 91765, U.S.A. Tel: (877) 502-8697
© 2012 Silverlit. All rights reserved. Visit us at : www.silverlit.com


Spider-Man, the Character TM & © 2012 Marvel Characters, Inc. The Amazing Spider-Man, the Movie © 2012 Columbia Pictures Industries, Inc. All Rights Reserved. **MARVEL** **SPIDER-MAN** **COLUMBIA PICTURES**

Getting Started

Both your submarine and controller require.
2 x 1.5V "AA" size alkaline batteries.


Battery Installation: Submarine

- Make sure the power switch is on "OFF" position.
1. Twist submarine tail clockwise (about 30 degrees), then pull it out to remove the battery cover (fig. 1)
 2. Put 2xAA size alkaline batteries inside submarine as per the "+" and "-" signs shown in battery compartment (fig. 2)
 3. Set the locker on battery cover in the slot on submarine body, the battery polarity shall be in response to that on battery cover, then twist it in counter clockwise to lock battery cover (fig.3)



Battery Installation: Transmitter

1. Use a phillips head screwdriver to loosen screw. (turn counter clockwise) (fig. 4)
2. Insert new 1.5V "AA" size batteries with "+" & "-" signs as shown below. (fig. 5)
3. Close the battery cover use a phillips head screwdriver. (fig. 6)



Driving your R/C Submarine:

- Twist the dummy pump on tail clockwise to power on.
- Set the left and right engine parallel to submarine body axis, then put it in water, submarine can float on water. Operate your remote controller to drive submarine go forward or turn on water surface.
- Set the left and right engine vertical to submarine body axis, then put it in water to submarine's water line (fig. 7), operate the "Forward key" on your remote controller to let submarine dive in water (you can operate the "back turn key" on your remote controller to let submarine go up to water surface.)
- After use, switch off the R/C Submarine.
- If the R/C Submarine is to be "parked" for a relatively long time, remove all batteries from the submarine and the transmitter.

