



<b>For Your Safety</b>	<b>3</b>
Safety Tips	3
Network Service	6
Usage Warnings	7
<b>Getting Started</b>	<b>9</b>
Inserting the SIM card	10
Charging the Battery	12
Battery Care	13
Phone Elements	14
Keypad Illustration	16
<b>Basic Operations</b>	<b>17</b>
Message	18
Phonebook	23



## CONTENTS

02

MOBICOM 2189

26	Call History
28	Network Service
32	Phone Settings
36	Organizer
38	Extra Features
<b>39</b>	<b>FCC Notice and SAR Statement</b>
<b>41</b>	<b>Warranty Statement and Card</b>



# FOR YOUR SAFETY

- 1. Safety Tips**
- 2. Network Service**
- 3. Usage Warnings**



## 1. Safety Tips

Read these simple guidelines. Not following them may be dangerous or illegal. Read the complete user guide for further information.



### SWITCH ON SAFELY

Do not switch the phone on when wireless phone use is prohibited or when it may cause interference or danger.



### ROAD SAFETY COMES FIRST

Obey all local laws. Always keep your hands free to operate the vehicle while driving. Your first consideration while driving should be road safety.



### INTERFERENCE

Obey all local laws. Always keep your hands free to operate. All wireless phones may be susceptible to interference, which could affect performance.



### SWITCH OFF IN HOSPITALS

Follow any restrictions. Switch the phone off near medical equipment.



### SWITCH OFF IN AIRCRAFT

Follow any restrictions. Wireless devices can cause interference in aircraft.



### SWITCH OFF WHEN REFUELING

Turn off your phone prior to entering fueling areas.



## SWITCH OFF NEAR BLASTING

Obey all sign, and instructions. Turn off your phone when you are in a blasting area.



## USE SENSIBLY

Use only in the normal position as explained in the product documentation. Don't touch the antenna unnecessarily.



## QUALIFIED SERVICE

Only qualified personnel may install or repair this product.



## ENHANCEMENTS AND BATTERIES

Use only approved enhancements and batteries. Do not connect incompatible products.



## WATER-RESISTANCE

Your phone is not water-resistant. Keep it dry.



## BACK-UP COPIES

Remember to make back-up copies or keep a written record of all important information stored in your phone.



## EMERGENCY CALLS

Ensure the phone is switched on and in service. Press the End key as many times as needed to clear the display and return to the main screen. Enter the emergency number, then press the Talk key. Give your location. Do not end the call until given permission to do so.





## 2. Network Service

To use the phone you must have service from a wireless network operator. Many of the features in this device depend on features in the wireless network to function. These Network Services may not be available on all networks or you may have to make specific arrangements with your network operators before you can utilize Network Services.

Your service provider may need to give you additional instructions for their use and explain what charges will apply. Some networks may have limitations that effect how you can use Network Services. For instance, some networks may not support all language-dependent characters and services.

Your network operators may have requested that certain features be disabled or not activated in your device. If so, they will not appear on your device menu. Contact your network operators for more information.



## MOBICOM 2189

- Keep the phone and all its parts and accessories out of the reach of small children.
- Keep the phone clean. Do not use or store the phone in dusty, dirty areas, as its moving parts may be damaged.
- Keep the phone dry. Precipitation, moisture and liquids contain minerals that will corrode electronic circuits.
- Do not store the phone in hot areas. High temperature can shorten the life of electronic devices, damage batteries, warp or melt certain plastic parts.
- Do not store the phone in cold areas. When the phone warms up to its normal operating temperature, humidity can form inside the phone, which may damage electronic circuit boards.
- Phone should only be disassembled by an authorized service center. Unauthorized disassembly may void the warranty.
- Do not drop, knock or shake the phone. Rough handling can break internal electronic boards.
- Do not use harsh chemicals, cleaning solvents or strong detergents to clean the phone. Wipe it with a soft cloth slightly dampened in a mild soap-and-water solution.

**3. Usage Warnings**



## FOR YOUR SAFETY

08

MOBICOM 2189

- Do not paint the phone. Paint can clog the device's moving parts and prevent proper operation.
- If the phone, battery, charger or any other accessory is not working properly, take it to the nearest service facility.




# GETTING STARTED

- 1. Inserting the SIM card**
- 2. Charging the Battery**
- 3. Battery Care**
- 4. Phone Elements**
- 5. Keypad Illustration**




### 1. Inserting the SIM card

Note: Before installing the SIM card, make sure that the phone is switched off, and disconnected from the charger or any other device.




Remove the back cover:

- (1) press the top and the bottom of the battery cover;
- (2) slide to open




Remove the battery.

- (3) pull up the right side of the battery to take it out



Insert the SIM card


- (4) place the SIM card into the slot, with the gold side down and the beveled edge to the right.



- (5) push the SIM card to the left




(6) the SIM card stops at the left end of the slot




#### Replace battery

(7) put the battery back in, left side first, to make sure it goes into the right spot.




#### Replace the back cover

(8) align the two side clip on the cover with the housing




(9) slide the cover up and snap it into place





### 2. Charging the Battery



Note:

The Charger Connector is the left one of the two connectors on the bottom of the phone. Please find a small charger icon next to the charger connector to avoid plugging the charger into the audio connector by mistake.

#### (1). Charging the battery with the travel charger

- Plug the travel charger into the bottom outlet.
- The indication bar of battery scrolls when battery charging is in process; In this process the mobile phone can be used but this will increase the charging time.
- When the indication bar of battery stops scrolling, it means charging is complete; Please switch off the power before disconnecting the charger. The charging time may vary with the residual battery level.

#### (2). Low Battery Indicator

- When the battery is weak and only a few minutes of talk time remain, you will hear a warning tone and a message of low battery will be repeated at regular intervals on the display;
- When the battery is too weak for the phone to operate, it switches off automatically.

#### (3). Battery Usage

- The battery will consume more power when the phone is in talk mode. Therefore, the longer the talk time, the shorter the standby time;
- The lifetime of battery may vary with the external environment (i.e., number of charging cycles, ambient temperature, method of usage, signal strength and duration of keypad lighting).

Note: Use only the supplied charger because other chargers may damage the phone.



## MOBICOM 2189


- Do not charge the battery at improper temperatures because it can affect the battery capability.
- Do not charge the battery in sunny or damp environment.
- Keep the battery away from open flames. It is prohibited to disassemble the battery or put it together with explosive substances.
- Please do not knock the battery with a sharp object or place it under weight, otherwise the electronic circuits and internal parts and components can be damaged, shortening the lifetime of battery.
- The battery is designed to be charged and discharged many times, but will eventually wear out. You should replace the battery when talk time and standby time is noticeably shorter than normal.
- Please use the supplied accessories, in order to avoid damaging the phone and battery.
- Please keep the battery pins and metal parts clean.. Charging may not be performed if the battery is too dirty.
- Please place the battery in dry and cool environment. Extreme high or low temperature may damage the battery capability and reduce the lifetime of battery.

## 3. Battery Care



### 4. Phone Elements

Lanyard (back)





See Illustration on the left:

- **Lanyard Holes** (on the top of the back housing)

Allows the lanyard to go through to carry the phone.

- **Earpiece**

Allows sound to be heard through the phone.

- **LCD (Liquid Crystal Display)**

Mono 96x64, displays messages and icons.

- **Soft Keys**

Used to display the function.

- **Navigation Keys**

Help scrolling up and down **Menu**.

Shortcuts to Call History, Keypad and Ring Tone Setting, Messages, and Phone Book.

- **Numeric Keys**

Enter numbers, letters and characters. Quickly scroll through the menu options.

- **Charging Connector**


Charge the phone by plugging the charger in the connector.

- **Headset Connector**

Allows the headset to be connected to the phone.



## 5. Keypad Illustration



- **Send Key:** Makes or answers a call.
- **End Key:** Stops prompt, ends a call or exits from the current menu. Used to switch phone on/off when pressing and holding down for longer.
- **Left Soft Key:** Performs the functions shown in the left bottom area of display. Scroll through menu options in idle mode.
- **Right Soft Key:** Performs the functions shown in the right bottom area of display.
- **Navigation Keys:** Scroll through the menu; shortcuts:
  - Up Arrow Key: Keypad Tone setting and Ring tone setting.
  - Down Arrow Key: Phone Book
  - Left Arrow Key: Messages
  - Right Arrow Key: Call History



# **BASIC OPERATIONS**

- 1. Messages**
- 2. Phonebook**
- 3. Call History**
- 4. Network Service**
- 5. Phone Settings**
- 6. Organizer**
- 7. Extra Features**



### 1. Messages

- (1). Read
- (2). Write
- (3). Delete All
- (4). Settings
- (5). Broadcast
- (6). Voice Mail

The shortcut to Messages is the Left arrow key in idle mode.

#### (1). **Read** (read a message)

When a message is received, new messages will be displayed on the screen, and your phone will sound a tone in accordance with the settings you choose. Press **Read** to view the message.

I. To view the message immediately, select **Read**

II. To view a saved message, From **Menu**, select **Messages > Read > Inbox** or **Draft**. Unread messages are indicated with **\*** .

III. While viewing the message, select **Options** and one of the following:

- **Delete** — Delete the message you are viewing.
- **Reply** — While viewing a message, select **Options > Reply**. Compose your reply and send the message as described in “*Write and send a message*”.
- **Edit** — Edit the message.
- **Forward** — Forwards a received message to another recipient.
  - i. While viewing a message, select **Options > Forward**
  - ii. Edit the message, and select **Send**.
  - iii. Enter the recipient's phone number or retrieve it from contacts, and select **Send**.
- **Extr. Number** — Automatically captures the numbers within the message. You can press **Next** to cycle through them and press **Options** to
  - i. Save the number
  - ii. Call the number



## MOBICOM 2189

iii. Send a message to the number.

You can also press the **Send** key directly to call this number.

- **Call Number** — Call the number that sent you this message.

(2). **Write** (Write and send a message)

I. From **Menu**, select **Messages > Write**

II. Compose a message using the keypad.

Entering text:

Press # to switch modes: Abc - first letter is capitalized

ABC - upper case

abc - lower case

123 - numeric entry

Press \* to select function marks.

Press 1 to enter a space (except in numeric entry mode).

III. For other options while composing the message, select **Options** and one of the following:

- **Send** — Send the message to more than one recipient.
- **Save** — Select Save to save the message in the Draft.
- **Discard** — Erase the text clipboard.

IV. To send the message, select **Send**, enter the recipient's phone number or select **Names** to retrieve a number from contacts, and select **Send**.

Note: When sending messages, your device may display the line **Sending Message**. This is not an indication that the message has been received at the intended destination. For more details about messaging services, check with your network



operators.

### (3). *Delete All*

- I. From **Menu**, select **Messages > Delete All**
- II. Select **OK** to delete all or **Back** to exit.

### (4). *Settings*

- I. From **Menu**, select **Messages > Settings**

II. If more than one message profile set is supported by your SIM card, select the set desired to change; then select one of the following:

- **Service Cent.** — To save the phone number of the message center which is necessary for sending text messages; obtain this number from your network operators.

Save your message center number:

Messages sent by your phone are routed through your network operator message center. Normally, this number is saved to your phone by your network operator. To save the number manually, do the following:

- I. From **Menu**, select **Messages > Settings > Service center**

- II. If the box in the display is empty or contains an incorrect number, enter the number given by your network operator, and select **OK**.

OR

If the box in the display contains the correct number, select **OK**. A message appears in the display confirming your number is saved.

- **Validity** — To define how long the network attempts to send your messages before it gives up.

- **Status Reports** — To request the network to send delivery reports on your messages.



- **Storage** — Screen will display total space and free space.

#### (5). *Broadcast*

Broadcast messages are public messages delivered to all the end users, if the service is available from your network operator. The messages are categorized by different topics, such as weather forecast, bonus stock, flight lines and so on. Please contact your network operator for the category details.

From **Menu**, select **Messages>Broadcast**

The function options include the following:

- I. **Activate**—Activate the message station: to receive messages. Shut down the message station: stop to receive the messages.
- II. **Read**—Read the messages send by the station.
- III. **New Broadcast**—check the programs categories, and add or delete programs in your cell phone. Please inquiry the network operator for the corresponding codes of programs.
- IV. **List**  
List of cell broadcast filter names and parameters set.

#### (6). *Voice Mail*

This option enables you to answer the voice mail. You should apply for this service from your network operator first, then you can use this function.

From **Menu**, select **Messages > Voice Mail**

There are two sub options of this option:



**I. Voice Mail:** When this option is selected, your phone will directly access to the set Voice Mail Box, then you can listen to the voice messages. If the Voice Mailbox is not yet set, a prompt will appear on the screen, requesting you to enter the Voice Mailbox Number first.

Note: You can quickly access your voice mail by pressing and holding down the "1" key.

**II. Set Voice Mail:** Input the voice mail number provided by your network operators and press **OK**. This number will be saved.



You can save the phone numbers and corresponding names into the phone memory or SIM Card of your phone. Your phone memory allows you to store 100 names and phone numbers in total. The length and quantity of names and phone numbers to be stored into the SIM Card depends on the type of SIM Card provided.

The shortcut to Phone Book is:

1. Press the **Down** arrow key at the idle screen
2. Select **Names** at the idle screen

(1). **List** — Find a name or select from a list.

From **Menu**, select **PhoneBook > list**

Press **Up/Down** keys to scroll through the list of names. The names stored in the phone memory is indicated with the phone icon and the names stored in SIM card is indicated by the SIM icon.

Press **Send** key to call the name or select **Options** by pressing the soft key to edit, as one of the following options:

- **Send Message** — Send a message to the number (See “Write and send a message”)
- **Change** — Edit the original information
- **Details** — From **Menu**, select **Phonebook > List**, and then check the details of the name you selected.
- **Call Number** — From **Menu**, select **Phonebook > List**, choose the desired number and select **Call Number**
- **Copy** — Copy entries from phone memory to SIM and vice versa.
- **Move** — Move entries from phone memory to SIM and vice versa without keeping them in the original locations.

## 2. Phone Book

- (1). List
- (2). Add new entry
- (3). My number
- (4). Copy All
- (5). Delete All
- (6). Memory Stat.
- (7). Select Book
- (8). 1 Touch Dial



- **Delete** — Delete a name and its associated numbers.

### (2). *Add New Entry*

From **Menu**, select **PhoneBook > Add New Entry**.

or, you can also enter new numbers at idle screen and then press **Save** to add it to Phone Book.

### (3). *My Number*

From **Menu**, select **PhoneBook > My Number**

Screen will suggest **Edit** or **Back**. Select **Edit** to edit the number.

### (4). *Copy All*

From **Menu**, select **PhoneBook > Copy All**

Select **SIM to Phone** to copy all entries from SIM card to the phone; or select **Phone to SIM** to copy all entries from the phone to the SIM card.

### (5). *Delete All*

From **Menu**, select **PhoneBook > Delete All**

Select **SIM** or **Phone** to delete all the entries in the SIM card or in the phone.

### (6). *Memory Stat.*

From **Menu**, select **PhoneBook > Memory Stat.**

The screen displays the content and available spaces of SIM card and the phone.

**(7). *Select Book***

From **Menu**, select **PhoneBook > Select Book**

Use **Up/Down** arrow keys to select SIM card or cell phone. Phone book entries are stored in the selected phone book (SIM or phone's memory)

**(8). *1 Touch Dial***

From **Menu**, select **PB > 1 Touch Dial**. Pick one from number keys 2 through 9, and then enter a phone number and press **OK**. For locations 2 through 9, you can use one touch dialing by pressing and holding the appropriate number key.



### 3. Call History

- (1). Missed calls
- (2). Answered calls
- (3). Outgoing Calls
- (4). View calls options
- (5). Call timer

Call History stores information about the last 10 missed, 10 received, and 10 dialed calls. It also adds the total duration of all calls. When the number of calls exceeds the maximum, the most recent call replaces the oldest. For Call History to work properly:

- Your network operators must support caller ID, and it must be enabled.
- Your calls cannot be blocked.
- Your phone must be on and within the service area.

The shortcut to Call History is the Right arrow key in idle mode.

#### (1). *Missed Calls*

From **Menu**, select **Call History > Missed Calls**

**Missed Calls**- Shows the phone numbers of unanswered calls.

#### (2). *Answered Calls* -Answered calls are calls that have been answered.

I. From **Menu**, select **Call History > Answered calls**.

II. Scroll to a name or number, and select Options and the desired option from the list.

#### (3). *Outgoing Calls*

You can view dialed numbers in one of two ways:

I. At the start screen, press the **Talk** key.

OR

From **Menu**, select **Call History > Outgoing Calls**.

II. Scroll to a name or number, and select Options and the desired option from the list.



#### (4). ***View calls options***

Whether you are viewing missed, answered, or outgoing calls, the menu options are as follows:

**Store Number** — Enter a name for the number and save it to contacts.

**Send message** — Send a message to the number.

**Details** — Display the date\ number and time of the call.

**Delete** — Clear the number from memory.

To clear any missed, outgoing, or answer calls from phone memory,

select **Call History > missed/outgoing** or **Answer > Delete**

**Delete All**- To clear any missed, outgoing, or answer calls from phone memory, select **Call History > Missed / Outgoing** or **Answer > Delete all**

#### (5). ***Call Timers***

**Call timers**—View the duration of recent calls and clear the call timers.

From Menu, select **Call History > Call timers**



### 4. Network Service

- (1). Divert
- (2). Network Sel.
- (3). Call barring
- (4). Call waiting
- (5). Hide ID

#### (1). *Divert*

##### I. Not Reachable

This allows you to forward incoming calls when your phone is power off or in an area where the network is unreachable.

- From **Menu**, select **Network service > Divert**
- Scroll to operate these options: **Status, Set, Cancel**

##### II. If busy

Forward all calls when you are on a call.

This allows you to forward the incoming calls when your phone is busy. When this function is activated, Your phone will forward the incoming call even when you refuse to answer it.

- From **Menu**, select **Network service > Divert > If Busy**
- Scroll to operate these options: **Status, Set, Cancel**

##### III. If No Answer

Forward all calls to another number if you do not answer. You can also set a delay before forwarding takes place.

- From **Menu**, select **Network Service > Divert > If No Answer**
- Scroll to operate these options: **Status, Set, Cancel**

##### IV. All Calls

This network service allows you to forward the incoming call to another phone number, enabling you to correctly handle the incoming call when you are unable to answer. This function allows forwarding all the incoming calls in any instance.



- From **Menu**, select **Network service** > **Divert** > **All Calls**
- Scroll to operate these options: **Status**, **Set**, **Cancel**

#### V. Cancel All

Cancel any call forwarding options you may have set.

From **Menu**, select **Network service** > **Divert** > **Cancel All** to cancel all settings.

#### (2). **Network Sel.**

This option enables you to select or search your service network.

- From **Menu**, select **Network service** > **Network Sel** > **Automatic** or **Manual**

You can choose **Manual Net Sel** or **Auto Net Sel** to search network

#### (3). **Call Barring**

This service allows you to restrict your phone to make or answer any or some calls. You need to enter the network password if you want to use this function. You need to apply for the password from your network operator.

From **Menu**, select **Network service** > **Call Barring**, the menu options are as the following:

I. **Outgoing** — When this option is activated, you are unable to dial any number

II. **Intern. Calls** — When this option is activated, you are unable to dial



any international number.

**III. Intern. But Home** — It allows you to make a call only to your country and dial the domestic numbers when you are roaming.

**IV. Incoming Call** — When this option is activated, you are unable to answer any incoming call.

**V. When Roaming** — When this option is activated, and you are abroad, you are unable to answer any call except it comes domestically.

**VI. Cancel All** — When this option is activated, all the calling restrictions set before will be canceled. You need network password for this function.

**VII. Change Password** — enter original Phone Lock code, after it's confirmed correct, enter new code for twice.

Except **Cancel All**, other options include the same following items: **Status** ,**Set** ,**Cancel**. When the functions are activated, you need to enter network password.

### **(4). *Call Waiting***

If supported by your network operators, call waiting notifies you of an incoming call even while you are in a call. You can accept, reject, or ignore the incoming call.



## I. Check Status

You can see whether call waiting is active, and for which type of calls.

From **Menu**, select **Network service > Call Waiting > Check Status**

## II. Activate or Deactivate

From **Menu**, select **Network service > Call Waiting > Activate or Deactivate**.

(5). *Hide ID*

From **Menu**, select **Network service > Hide ID**, and one of the following:

I. Check Status

II. Activate

III. Deactivate

This function can control whether receiver is able to see your number or not, please consult your network operator for this service.



## 5. Phone Settings

- (1). Languages
- (2). Tones
- (3). Clock
- (4). Security
- (5). AutoRedial
- (6). Any-key Answer
- (7). Screen Saver
- (8). Auto Keylock
- (9). Factory Reset

### (1). *Languages*

From **Menu**, select **Phone Settings > Languages** and one of the following:

- English
- Spanish

### (2). *Tones*

#### I. Ringer

From **Menu**, select **Phone Settings > Tones > Ringer**, and one of the following:

- **Melody** — Enables you to set how the phone informs you of an incoming call.
- **Volume** — Enables you to set tone volume level of incoming call

#### II. SMS tone

From **Menu**, select **Phone Settings > Tones > SMS tone**

- **Melody** — Enables you to set different SMS tones.
- **Volume** — Enables you to set tone volume level of SMS tone

#### III. Alarm

From **Menu**, select **Phone Settings > Tones > Alarm**

- **Melody** — Select an alarm tone from list.
- **Volume** — Enables you to set tone volume level.

#### IV. Keypad Tone

From **Menu**, select **Phone Settings > Tones > Keypad Tone**

There are 2 choices:



- **Tones**--you can select Silent, Click, or DTMF
- **Volume**--you can adjust the volume by pressing up and down arrow keys on the navigation key.

The shortcut of the Keypad Tone control is the Up arrow key in idle mode.

#### (3). *Clock*

From **Menu**, select **Phone Settings > Clock**. This menu enables you to set date and time.

To set Time and Date, use navigation key to scroll through menu, and press **Select** to make your selection.

#### (4). *Security*

##### I. FDN (Fixed Dialing Number) PhoneBook

Once you set up and activate the FDN, this secondary phone book turns on to take the place of the regular Phone Book. Your phone can make calls only to those numbers that you have defined in this fixed dialing list. This option allows you to restrict your outgoing calls to a limited set of phone numbers.

From **Menu**, select **Phone Settings > Security > FDN PhoneBook**, and one of the following:

- **Activate** — to turn FDN on in order to use the restricted list only.
- **Deactivate** — to turn FDN off in order to use the regular Phone Book.

You need to enter PIN2 code to activate or deactivate this function. When it is activated, you can go to **Menu > Phone Book** to add, revise or delete numbers in this list.



### II. PIN

From **Menu**, select **Phone Settings > Security > PIN**. The menu options are as follow:

**Status, Activate, Deactivate, Change** — You will need to input your PIN code before you can perform any of PIN options. When this function is activated, you need to input your PIN code every time the phone is switch on.

**PIN change:**

- (I). At the prompt, enter the original PIN code, and select **OK**.
- (II). At the prompt, enter the new PIN code, and select **OK**.
- (III). At the prompt, enter the new PIN code again, and select **OK**.

### III. PIN2

The PIN2 code is required for features such as fixed dialing. If you enter an incorrect PIN2 code three times in succession, the PIN2 code is blocked and you will have to enter the PUK2 code.

The original PIN2 code must be obtained from your network operators.

Use this procedure to change your PIN2 code:

From **Menu**, select **Phone Settings > Security > PIN2**

**Change PIN2**

- At the prompt, enter the original PIN2 code, and select **OK**.
- At the prompt, enter the new PIN2 code, and select **OK**.
- At the prompt, enter the new PIN2 code again, and select **OK**.

### (5). *Auto Redial*

From **Menu**, select **Phone Settings > Security > Auto Redial**



You can select **On** or **Off**. When this function is activated, your phone will automatically redial the number up to 10 times after 10 attempts the function will be terminated. (This function must be supported by your network operator). Press **END** key to stop auto redial.

#### (6). *Any-key Answer*

Any-key answer allows you to answer an incoming call by briefly pressing any key except the End key.

From **Menu**, select **Phone settings > Any-key answer > On or Off**.

#### (7). *Screen Saver*

From **Menu**, select **Phone settings>Screen Saver**

Select **On** to activate or **Off** to deactivate.

#### (8). *Auto Keylock*

From **Menu**, select **Phone settings > Auto Keylock**

Select **On** to activate or **Off** to deactivate.

#### (9). *Factory Reset*

You can reset some of **Menu** settings to their original values. However, data that you have entered or downloaded are not affected. For example, names and numbers in contacts are not affected.

I. From **Menu**, select **Phone settings > Restore factory**

II. press **OK** to enter. Press again to reset some functions to factory settings.

Note: The stored phonebook information and messages will not be affected by restoring the factory settings.



### 6. Organizer

- (1). Alarm
- (2). Power On
- (3). Power Off
- (4). Calculator
- (5). Calendar
- (6). Global Time
- (7). Game

#### (1). *Alarm*

##### I. Alarm

From **Menu**, select **Organizer > Alarm > Alarm**  
Enter alarm time and choose frequency, **Once**, or **Daily**.

##### II. Tones

From **Menu**, select **Organizer > Alarm > Tones** and one of the following:  
• **Melody** — Enables you to set how the phone informs you of an alarm.  
• **Volume** — Enables you to set tone volume level of alarm.

##### III. Clear Alarm

From **Menu**, select **Organizer > Alarm > Clear Alarm**

#### (2). *Power On*

##### I. From **Menu**, select **Organizer > Power On**

Choose **ON** and set put **ON** time , and press **OK** key.

##### II. From **Menu**, select **Organizer > Power on > Tones** and one of the following:

- **Melody** — Enables you to set how the phone informs you of ON music.  
• **Volume** — Enables you to set tone volume level of ON music.

#### (3). *Power Off*

##### I. From **Menu**, select **Organizer > Power Off**

Choose **Power Off** and set off time , and press **OK** key.

##### II. From **Menu**, select **Organizer > Power Off > Clr Pwr off** to clear power off setting

#### (4). *Calculator*

The calculator adds, subtracts, multiplies, divides digits.



Note: This calculator has limited accuracy and is designed for simple calculations.

I. From **Menu**, select **Organizer > Calculator**

II. In the calculator screen, enter the first number in the calculation.

Press the # key for a decimal point if necessary.

III. To perform an arithmetic calculation, select **Options** to cycle through Equals, Plus, Minus, Divide By, Multiple By.

IV. For an arithmetic calculation, enter the second number in your calculation and select **Equals**. The completed calculation appears in the display.

#### **(5). *Calendar***

The Calendar function allows the user to view a calendar through December 2049.

From **Menu**, select **Organizer > Calendar**

Current date, week, and month are displayed

Note: Date checking ranges from 31st. Jan. 1900 to 31st. Dec. 2049

#### **(6). *Global Time***

This function provides you conveniences to consult the local time of major cities in the world, in order to better control the time during business trip and travel.

From **Menu**, select **Organizer > Global Time**

you can select the city you want to view.

#### **(7). *Games***

Two games, **Four In A Row** and **Tetris**, are available in this model.

From **Menu**, select **Organizer > Games > Four In A Row or Tetris**.



### 7. Extra Features

#### (1). *Shortcuts*

In idle Mode:

**Up** Arrow Key: Keypad Tone Setting and Ring Tone Setting. You can set them **Normal** or **Silent**.

**Down** Arrow Key: **Phone Book** menu

**Left** Arrow Key: **Messages** menu

**Right** Arrow Key: **Call History** menu

#### (2). *Key Lock and Unlock*

To lock the keypad: Select Menu and then press **\*** key

To unlock the keypad: Select Unlock and then press **\*** key.



## **FCC NOTICE AND SAR STATEMENT**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by Mobicom will void the user's authority to operate the equipment. Use only Mobicom approved chargers.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



## FCC NOTICE AND SAR STATEMENT

40

MOBICOM 2189

THIS PHONE MODEL HAS BEEN CERTIFIED TO BE IN COMPLIANCE WITH THE GOVERNMENT'S REQUIREMENTS FOR EXPOSURE TO RADIO WAVES.

Before a phone model is available to sale to the public, it must be tested and certified that it does not exceed government limits for exposure to radio frequency (RF) energy. Specific Absorption Rate (SAR) is a value that corresponds to the relative amount of RF energy absorbed by the user of a wireless phone. The Federal Communications Commission of the United States government and Health Canada set SAR limits. The limits include a safety margin designed to assure the safety of all persons, regardless of age and health. The maximum allowed SAR value set by the FCC is 1.6 W/kg. Tests for SAR values are conducted using FCC approved operating positions at the highest possible power levels. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating is likely well below the maximum value.

The highest SAR values as reported to the FCC for this model phone are in full compliance with FCC limits.

For more information about RF exposure, visit the FCC website at [www.fcc.gov](http://www.fcc.gov). Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications & Internet Association (CTIA) website:

[http://www.ctia.org/wireless\\_consumers/health\\_and\\_safety/index.cfm](http://www.ctia.org/wireless_consumers/health_and_safety/index.cfm)

or the Canadian Wireless Telecommunications Association (CWTA) website: <http://www.cwta.ca>



# **WARRANTY STATEMENT**

Please read the warranty statement and send the completed warranty card back to Mobicom.



### Mobicom ONE-YEAR LIMITED WARRANTY Statement

Mobicom warrants to the original purchaser ("Purchaser") that Mobicom's Phones and accessories ("Products") are free from defects in material and workmanship under normal use and service for the period commencing upon the date of purchase and continuing for the following specified period of time after that date:

Phone: 1 year

Battery, Charger, and other accessories: 6 months

1. The limited warranty extends only to the Purchaser of the Product and may not be assigned or transferred to any subsequent purchaser or user. The limited warranty extends only to Product purchased in the country for its intended sale.
2. Upon request from Mobicom, Purchaser must prove the date of the original purchase of the Product by a dated bill of sale or dated itemized receipt showing the serial number of the product and the seller's name and address.
3. During the limited warranty period, Mobicom will repair or replace the Product, as Mobicom determines, if its limited warranty applies. Mobicom will be responsible for parts and labor to repair or replace the Product or defective parts of the Product.
4. The limited warranty does NOT cover defects in appearance or any parts that do not affect the Product functions.
5. The Purchaser shall bear the cost of shipping the Product to Mobicom or to Mobicom's authorized return center. Mobicom shall bear the cost of shipping the Product back to the Purchaser after completion of service, provided that repairs were required to be performed under this limited warranty.
6. Mobicom's limited warranty does NOT apply if any of the following circumstances occurs:
  - The Product has been subjected to abnormal use or conditions, improper storage, exposure to moisture or dampness, unauthorized modifications, unauthorized connections, unauthorized repairs, misuse, neglect, abuse, accident, alteration, improper installation, or other acts that are not the fault of Mobicom. This includes damage caused by shipping.
  - The Product has been damaged by external causes such as liquid, water, collision with an object, or from fire, flooding, sand, dirt, windstorm, lightning, or exposure to weather conditions; theft; blown fuse or improper use of any electrical source; computer or Internet viruses, bugs, worms, Trojan Horses, cancelbots; or connection to products not recommended for interconnection by Mobicom.
  - Defects or damages are caused by physical damage to the surface of the Product, including scratches or cracks in or to the outside housing or the LCD display.

## MOBICOM 2189

- This Limited Warranty covers batteries only if battery capacity falls below 80% of rated capacity or the battery leaks, and this Limited Warranty does not cover any battery if (i) the battery has been charged by a battery charger not specified or approved by Mobicom for charging the battery, (ii) any of the seals on the battery are broken or show evidence of tampering, or (iii) the battery has been used in equipment other than the Mobicom phone for which it is specified.
- You did not advise Mobicom in writing of the alleged defects or malfunction of the Product within fourteen (14) days after the expiration of the warranty period.
- The Product serial number plate or the accessory data code has been removed, defaced, or altered.

7. If damage or a defect develops during the limited warranty period, the Purchaser must take the following step-by-step procedure:

- Return the Product to the place of purchase for repair or replacement. The Purchaser must copy to another device and delete from the Product any sensitive data that the Purchaser has stored in the Product prior to sending the Product for repair or replacement.
- If return to the place of purchase is not convenient due to distance (more than 50 miles), the Purchaser may contact us:  
*Mobicom USA Warranty Support Center*  
630 Margate Drive  
Lincolnshire, Illinois, 60069  
Tel: 1-866-438-4666
- Ship the Product (including the battery and A/C charger), in an appropriate container, prepaid and insured at the Purchaser's expense.
- If the Product is covered by Mobicom's limited warranty, Mobicom will return the repaired or replaced Product to the Purchaser at Mobicom's expense.
- Mobicom will repair or authorize the repair of the Product under the limited warranty within 10 business days of receipt of the Product. If Mobicom cannot perform repairs covered under this warranty within 10 business days, Mobicom will provide a replacement Product or refund the purchase price.
- If the Product is returned more than fourteen (14) days after the expiration of the limited warranty period, or if the Product is returned during the limited warranty period, but the problem with the Product is not covered under the terms and conditions of Mobicom's limited warranty, Mobicom will so notify the Purchaser and provide an estimate (using Mobicom's standard rates) of the charges the Purchaser must pay to repair the Product, including return shipping charges. If you refuse the estimate, Mobicom will return the Product freight collect.

8. A repaired Product may consist of used components, some of which have been reprocessed. All used components comply with Product performance and reliability specifications.

9. Returning a Product for warranty repair or replacement will not extend the original warranty period.

10. Mobicom's limit of liability under the warranty shall be the actual cash value of the Product at the time the Purchaser returns the Product for repair. The cash value shall be determined by the price paid by the Purchaser for the Product less a reasonable amount for usage. Mobicom shall not be liable for any other losses or damages.

11. The remedies set forth in this limited warranty are the Purchaser's exclusive remedies for breach of warranty.

12. THE FOREGOING LIMITED WARRANTY IS THE PURCHASER'S SOLE AND EXCLUSIVE REMEDY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR USE.

IN NO EVENT SHALL Mobicom BE LIABLE FOR SPECIAL, INCIDENTAL, CONSEQUENTIAL OR PUNITIVE DAMAGES, INCLUDING LOSS OF ANTICIPATED BENEFITS OR PROFITS, LOSS OF SAVINGS OR REVENUE, LOSS OF USE OF THE PRODUCT OR ANY ASSOCIATED EQUIPMENT, LOSS OF DATA, COST OF CAPITAL, COST OF ANY SUBSTITUTE EQUIPMENT OR FACILITIES, DOWNTIME, THE CLAIMS OF ANY THIRD PARTIES, INCLUDING CUSTOMERS, AND INJURY TO PROPERTY, RESULTING FROM THE PURCHASE OR USE OF THE PRODUCT OR ARISING FROM BREACH OF THE WARRANTY, BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY, OR ANY OTHER LEGAL OR EQUITABLE THEORY, EVEN IF Mobicom KNEW OF THE LIKELIHOOD OF SUCH DAMAGES. Mobicom SHALL NOT BE LIABLE FOR DELAY IN RENDERING SERVICE UNDER THE LIMITED WARRANTY, OR LOSS OF USE DURING THE PERIOD THAT THE PRODUCT IS BEING REPAIRED OR FOR LOSS OF DATA STORED IN THE PRODUCT. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

13. Some States do not allow limitations on how long an implied warranty lasts, so the above may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from State to State.

14. This limited warranty is the entire warranty between Mobicom and the Purchaser, and supersedes all prior and contemporaneous agreements or understandings, oral or written, and all communications relating to the Product. No representative of Mobicom or any third party seller of Mobicom PRODUCTS may modify these terms, either orally or in writing.



MOBICOM 2189

## Warranty Card

Title \_\_\_\_\_ First Name \_\_\_\_\_ Middle Name \_\_\_\_\_ Last Name \_\_\_\_\_

Street \_\_\_\_\_ Apt. No. \_\_\_\_\_

City \_\_\_\_\_ State \_\_\_\_\_ Zip \_\_\_\_\_ Country \_\_\_\_\_

Home Phone Number \_\_\_\_\_ Work Phone Number \_\_\_\_\_

Date of Purchase (Month/Day/Year) \_\_\_\_\_

Model Number \_\_\_\_\_

Serial Number \_\_\_\_\_

To register your warranty, please complete this card, tear it off along the dashed line on the left, and then mail it to:

Customer Service Department  
Mobicom Corporation  
960 Holmdel Road, Holmdel, NJ 07733  
USA



Customer Service Department  
**Mobicom**  
960 Holmdel Road,  
Holmdel, NJ 07733  
USA