


Report File No.: STROR-06-006


Date of Issue : 2006-01-24

Page: 42 of 45

FCC ID: PBNED11KTM

12. Attachment A-1 Photos of the test set up (radiated)





The results shown in this test report refer only to the sample(s) tested unless otherwise stated. This test report cannot be reproduced, except in full, without prior written permission of the Company.

SGS Testing Korea Co., Ltd.

18-34, Sanbon-dong, Gunpo-si, Gyeonggi-do, Korea, 435-040

Tel. +82 31 428 5700 / Fax. +82 31 427 2371

www.sgstesting.co.kr




Report File No.: STROR-06-006

Date of Issue : 2006-01-24

Page: 43 of 45 **FCC ID : PBNED11KTM**

Attachment A-2 Photos of the test set up (conducted)





The results shown in this test report refer only to the sample(s) tested unless otherwise stated. This test report cannot be reproduced, except in full, without prior written permission of the Company.


SGS Testing Korea Co., Ltd.

18-34, Sanbon-dong, Gunpo-si, Gyeonggi-do, Korea, 435-040

Tel. +82 31 428 5700 / Fax. +82 31 427 2371

www.sgstesting.co.kr

TM Board Test-Jig Test Setup



TM Board Test-Jig

< Test Procedure >

POWER Terminal

- 1.Input DC 3.3V to "Power Terminal".
- 2. Select either "Frequency" using "Frequency Change Switch".
- 3. Select either "Mod. or Non-Mod., or Standby" using "Mod. Switch".
- 4. Power on using "Power switch".
- 5.Measure RF Output signal.
- 6. After measuring, shall have to power off.
- 7. For next function test, go to above step 1.