



 <p>OKIN REFINED</p> <p>A Phoenix Mecano Company</p>	Issue department: Bedding Division	Date:	2018-10-30
	ProductFunction instruction	Author:	Aaron
		No: CB3342	
CB3342	Version:	1.1	
	Page 1 of 6		

CB3342 Function instruction

1. Electrical configuration diagram:



 A Phoenix Mecano Company	Issue department: Bedding Division	Date:	2018-10-30
	ProductFunction instruction	Author:	Aaron
CB3342		No: CB3342	
	Version:	1.1	
Page 2 of 6			

2. Function Picture



3. Process of test


3.1. HEAD MOTOR

Connect to head actuator, control by remote single:

Click head up button on the remote, head actuator moves out, stop when released;

Click headdown button, head actuator moves in, stop when released;

This function takes effect only by pressing the corresponding button on the remote.

 <p>OKIN REFINED A Phoenix Mecano Company</p>	Issue department: Bedding Division	Date:	2018-10-30
	ProductFunction instruction	Author:	Aaron
		No: CB3342	
	CB3342	Version:	1.1
Page 3 of 6			

3.2. FOOT MOTOR

Connect to foot actuator,control by remote single:

Click foot up button, foot actuator moves out, stop when released;

Click foot down button, foot actuator moves in, stop when released;

This function takes effect only by pressing the corresponding button on the remote.

3.3. ROTATE MOTOR

Connect to foot actuator,control by remote single:

Click Lumber up button, foot actuator moves out, stop when released;

Click Lumber down button, foot actuator moves in, stop when released;

This function takes effect only by pressing the corresponding button on the remote.

3.4. SEAT MOTOR

Connect to foot actuator,control by remote single:

Click Lumber up button, foot actuator moves out, stop when released;

Click Lumber down button, foot actuator moves in, stop when released;

This function takes effect only by pressing the corresponding button on the remote.

3.5. MASSAGE

Connect to head& Foot massage,control by remote:

Click head massage + button,head massage strengthens by one level;


Click head massage - button,head massage weakenby one level;

This function takes effect only by pressing the corresponding button on the remote.

3.6. Test for underbed light

Click button of underbed light, turns on(or turns off) the underbed light, switch the status once when click once;

This function takes effect only by pressing the corresponding button on the remote.

 <p>OKIN REFINED A Phoenix Mecano Company</p>	Issue department: Bedding Division	Date:	2018-10-30
	ProductFunction instruction	Author:	Aaron
		No: CB3342	
	CB3342	Version:	1.1
Page 4 of 6			

3.7. SYNC port

This port is a reserved port.

3.8. Power LED& PAIRING LED

Power supply for control box, PAIRINGLED of control box is blue,POWER LEDis green。

3.9. Power

Connect to the 29V DC;

3.10. RESET button

Press and hold the RESET button, the Head, Foot actuators will moves to lower position.

3.11. Pair Function

Double click RESET button, pairing LED turns on, the control box enters into mode of code paring;

Press and hold the paring LED of Remote, the backlight of paring LED flashes, the backlight of remote flashes, the remote enters into mode of code paring;


The backlight of paring LED of remote stops flashing, and the paring led of control box turns off, it indicates that the code paring is successful;

If fails, repeat all the processes above;

3.12. Bluetooth Pairing Control Test

When the blue light of the control box is flashing, the pairing operation is performed:

1. Open the jerome's app and pass the gear in the upper right corner;
2. Click "connect to bed" to jump to the device list.
3. In the device list interface, pull down and refresh, see the device name is "OKIN-0xxxxx", click to connect;
4. The pairing prompt will pop up on the IOS device, and click "pairing". After the pairing is completed, return to the main interface to realize the operation control.

 <p>OKIN REFINED A Phoenix Mecano Company</p>	Issue department: Bedding Division	Date:	2018-10-30
	ProductFunction instruction	Author:	Aaron
		No: CB3342	
CB3342	Version:	1.1	
	Page 5 of 6		

FCC Warning :

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.

ISED RSS Warning :

This device complies with Innovation,Science and Economic Development Canada licenceexempt RSS standard(s). Operation is subject to the following two conditions:

(1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

ISED RF exposure statement:

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. Le rayonnement de la classe b repecte ISED fixaient un environnement non

contrôlés.Installation et mise en œuvre de ce matériel devrait avec échangeur distance minimale entre 20 cm ton corps.Lanceurs ou ne peuvent pas coexister cette antenne ou capteurs avec d'autres.