
 <p><b>OKIN REFINED</b> A Phoenix Mecano Company</p>	Issue Department: Bedding Division	Date:	2017-8-15
	<b>System Instruction</b>	Author:	
<b>Instruction of RF3011A</b>		Edition:	1.1
		Page 1 of 5	

**Instruction of RF3011A**



Figure 1 button of remote

	Issue Department: Bedding Division	Date:	2017-8-15
	<b>System Instruction</b>	Author:	
<b>Instruction of RF3011A</b>		Edition:	1.1
Page 2 of 5			

## 1. Item

### 1.1 ZG button (button 1 in figure 1)

Click the ZG button, the actuator moves to ZG position, stop when click any button during the movement;

Press and hold the ZG button for 5s, timer LED of remote flashes, the control box records current position as ZG position;

When in the process of moving to memory positions, the head and foot actuators move first, then the tilt and lumbar actuators move;

### 1.2 AntiSnore button (button 3 in figure 1)

Click AntiSnore button, actuators move to AntiSnore position, stop when click any button during movement;

Press and hold AntiSnore button for 5s, timer LED of remote flashes, the control box records current position as AntiSnore position;

When in the process of moving to memory positions, the head and foot actuators move first, then the tilt and lumbar actuators move;

### 1.3 TV/PC button (button 4 in figure 1)

Click TV/PC button, actuators move to TV/PC position, stop when click any button during movement;


Press and hold TV/PC button for 5s, timer LED of remote flashes, the control box records current position as TV/PC position;

When in the process of moving to memory positions, the head and foot actuators move first, then the tilt and lumbar actuators move;

### 1.4 Childlock button (button 5 in figure 1)

In unlocked state, press and hold the childlock button, the red backlight of children lock button begins to flash, after 5s, the red backlight stops flashing, remote enters into locked state;

Under locked state, press any button except childlock button, the red backlight of childlock turns on, the button you pressed is invalid;

	Issue Department: Bedding Division	Date:	2017-8-15
	<b>System Instruction</b>	Author:	
	<b>Instruction of RF3011A</b>		
		Edition:	1.1
		Page 3 of 5	

Under locked state, press and hold childlock button, red backlight of childrenlock begins to flash, after 5s, the red backlight stops flashing, remote enters into the normal working condition;

### **1.5 LOUNGE button (button 6 in figure 1)**

Click LOUNGE button, actuators move to LOUNGE position, stop when click any button during movement;

Press and hold LOUNGE button for 5s, timer LED of remote flashes, the control box records current position as LOUNGE position;

When in the process of moving to memory positions, the head and foot actuators move first, then the tilt and lumbar actuators move;

### **1.6 Reset all memory positions to default settings (button 1 and 11 in figure 1)**

Press and hold ZG+FLAT buttons (button 1 and 16 in figure 2) for 5s, timer LED of remote flashes, the control box reset all memory positions to default settings;

### **1.7 Head up (button 7 in figure 1)**

Press and hold HEAD UP button of remote, head actuator moves out, stop when released;

### **1.8 Head down (button 10 in figure 1)**


Press and hold HEAD DOWN button of remote, head actuator moves in, stop when released;

### **1.9 Foot up (button 8 in figure 1)**

Press and hold FOOT UP button of remote, foot actuator moves out, stop when released;

### **1.10 foot down (button 9 in figure 1)**

Press and hold FOOT DOWN button of remote, foot actuator moves in, stop when released;

	Issue Department: Bedding Division	Date:	2017-8-15
	<b>System Instruction</b>	Author:	
<b>Instruction of RF3011A</b>		Edition:	1.1
Page 4 of 5			

When moving to flat position, lumbar actuator and tilt actuator move first, after 500ms, head and foot actuators start moving;

### 1.11 Flat (button 11 in figure 1)

Click FLAT button, the bed goes flat, stop when click any button during the process of going flat;

#### **FCC Warning:**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### **ISED RSS Warning:**

This device complies with Innovation, Science and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radioexempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

ISED RF exposure statement:


This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet general RF exposure requirement.

Le matériel est conforme aux limites de dose d'exposition aux rayonnements énoncés pour un autre environnement. ce dispositif a été évalué à satisfaire l'exigence générale de l'exposition aux rf.



Remote model  
(RF3011)

FCC ID: PCU-RF3011A  
IC: 21319-RF3011A



1	R5. 504. 01. 250	Power Cord AC	1
2	JLDP. 10. 023. 000	Power Supply	1
3	R5. 217. 01. 013	Pair&Power Cord DC	1
4		Synchronization Cable	
5	CB. 11. 20. 01	Control Box	1
6		Motor/(Head&Foot)	2
7	RF3011A	Remote model	1