



1. Lock Set	1 Set	2. U modeled iron	1 Piece
3. Keys	2 Pieces	4. Screw	2 Pieces
5. Power cord	1 Pieces		

Specification

1. If you haven't set any key on this gear lock, you will hear continued beeps & LED flash when you press the start button.

2. Setting Keys :

- 2 -1. After press the start button, you will hear continued beeps. Let the device read the key and then press the start button twice. Then you will hear a long beep ton to indicate the first key, the master key, has been set (max. is 5 keys).
- 2-2. After the first key has been set, you will hear continued beeps tell you to set the second key. Let the device read the second key and then press the start button twice to set the second key. Using the same procedure to set the third, fourth and fifth key.
- 2 -3. If you don't want to continue setting the following key, please wait until the continued beep stop. This gear lock will shut down and complete the memory procedure.

3. Erase keys

Press the start button and let the device read the master key. You will hear a short beep. Press the start button five times to erase all keys. If the procedure complete, you will hear two long and a short beeps. Only master key can erase other keys.

Standard power voltage : +12V(Car Battery)

Red cable: +12V

White cable: GND

**FEDERAL COMMUNICATIONS COMMISSION
INTERFERENCE STATEMENT**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION:

Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.