

49. 860 MHz Receiver Operational Description

The 6.0V Monster Truck is full function radio controlled toy Truck It operates on 6.0 volts supplied by 6.0V Nicd battery pack It is designed to operate on a single fixed frequency in the 49.82 – 49.90 MHz band. See the attached block diagram and schematic.

The vehicle receiver receives and demodulates the AM transmitted signal from the transmitter, using a standard super-regenerative AM receiver/demodulator circuit comprised of ANT1, Q16, L2, L3, L1 and associated passive components. L1 is a tunable core slug inductor that is used to tune the receiver for maximum sensitivity. The output of the AM receiver/demodulator is AC coupled to a high input impedance CMOS inverter is connected to the U1 decoder IC, it is biased into their linear region through C19, C24, C8, R4, R13, R6, R7 and function as amplify, filter and shape the data. After passing through the last inverter stage, the incoming waveform is a digitized enough to be fed into the IN4in for on-chip decoding.

A Zener regulator circuit comprised of C13,C7, Z2,C8, it supplied voltage VDD for the super-regenerative radio, decoder IC.

Drive motor is controlled by the U1 decoder IC, low power switching transistors Q6, Q7, and a high power H-bridge comprised of Q27 Q28, Q8,Q11,the respectively. D6, D7, are current sense diode that permit a proportional sense voltage to be developed above them that is proportional to the amount of current through the bridge. When a there will be a high signal fed into C6, After these one capacitors are charged, they will turn ON Q2 will pull low the signal to the Drive Motors. As long as the user keep pressing the button, Q2,will keep at 'ON' stage until user release the button and let C6 to discharge,

The steering motor is controlled by the U1 decoder IC low power switching transistors Q35,Q36, and high power H-bridge comprised of Q33,Q34,Q37,Q38,

All tuning and verifications are performed by the manufacturer and there are no adjustments which can be made by the user. No external ground is required or used with this receiver.