User Manual

Version: 1.0

Copyright

Copyright © 2002 by this company. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of this company.

This company makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties, merchantability or fitness for any particular purpose. Any software described in this manual is sold or licensed "as is". Should the programs prove defective following their purchase, the buyer (and not this company, its distributor, or its dealer) assumes the entire cost of all necessary servicing, repair, and any incidental or consequential damages resulting from any defect in the software. Further, this company reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any person of such revision or changes.

All brand and product names mentioned in this manual are trademarks and/or registered trademarks of their respective holders.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- 1. Reorient or relocate the receiving antenna.
- 2. Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- 4. Consult the dealer or an experienced radio technician for help.

FCC Caution: To assure continued compliance. (example-use only shielded interface cables when connecting to computer or peripheral devices). Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the Following two conditions: (1) This device may not cause harmful interference, and (2) this Device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the authority to operate equipment.



Federal Communication Commission (FCC) Radiation Exposure Statement

This equipment complies with FCC radiation exposure set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, this device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

R&TTE Compliance Statement

This equipment complies with all the requirements of DIRECTIVE 1999/5/CE OF THE EUROPEAN PARLIAMENT AND THE COUNCIL OF 9 March 1999 on radio equipment and telecommunication terminal Equipment and the mutual recognition of their conformity (R&TTE)

The R&TTE Directive repeals and replaces in the directive 98/13/EEC(Telecommunications Terminal Equipment and Satellite Earth Station Equipment) As of April 8,2000.

Safety

This equipment is designed with the utmost care for the safety of those who install and use it. However, special attention must be paid to the dangers of electric shock and static electricity when working with electrical equipment. All guidelines of this and of the computer manufacture must therefore be allowed at all times to ensure the safe use of the equipment.

EU Countries Not Intended for Use

The ETSI version of this device is intended for home and office use in Austria Belgium, Denmark , Finland , France (with Frequency channel restrictions). Germany ,Greece, Ireland , Italy , Luxembourg .The Netherlands, Portugal , Spain , Sweden and United Kingdom.

The ETSI version of this device is also authorized for use in EFTA member states Iceland, Liechtenstein, Norway and Switzerland.



EU Countries Not intended for use

None.

Potential restrictive use

France: Only channels 10,11,12 ,and 13

Manual Contents

Chapter	1	Introduction6	
Chapter	2	Installation7	
Chapter	3	Configuring Utility10	I
3.1	Mon	itor	11
3.2	Stat	istic	13
3.3	Site	Survey	14
3.4	Enc	ryption	15
3.5	Adva	anced	16
3.6	Vers	sion	17
Chapter	4	Technical Specifications	18
Chapter	5	Troubleshooting19	

Switzerland.

4

EU Countries Not intended for use None.

Potential restrictive use France: Only channels 10,11,12 ,and 13

Manual Contents

Chapter	1 Introduction6	
Chapter	2 Installation7	
Chapter	3 Configuring Utility11	
3.1	Status1	2
3.2	Statistic 1	4
3.3	Site Survey 1	5
3.4	Encryption 1	6
3.5	Advanced 1	7
3.6	Version1	8
Chapter	4 Technical Specifications19	
Chapter	5 Troubleshooting20	

Thank you for purchasing Wireless PCMCIA Card. This device features the latest innovation wireless technology making the wireless networking world happened. This manual guides you on how to install and properly use the *Wireless* PCMCIA Card in order to take full advantage of its features.

Package Contents

Before installation, please check the items of your package. The package should include the following items:

- One Wireless PCMCIA Card
- One Quick Guide
- One CD-Based software(Including the Wireless LAN Management Utility & Driver & User Guide)

If any of the above items are missing, contact your supplier as soon as possible.

Minimum System Requirements

Before installation, please check the following requirements with your equipment.

- Pentium Based (above) IBM-compatible PC system with an PCMCIA support
- CD-ROM driver
- Windows 98/2000/ME Operating System
- At least 500Kbytes of free disk space for utility and driver installation

SAFETY PRECAUTION

Only use the accessories and connection cables attached with the device package. Otherwise, the device may not function. If you miss or damage the accessories or connection cables, please contact your local dealer.

Before you proceed with the installation, it is necessary that you have enough information about the *Wireless PCMCIA Card Note1:The following installation operates under Window 2000.*

Procedures will be the same for Window 98/ME

Note2: If you ever install the Wireless PCMCIA Card before ,please uninstall the old driver and utility first. If this is the first time to install the Wireless PCMCIA Card, please continue from A step to use the Wizard to continue.

A. Execute the "Setup.exe" program under the "PCMCIA-> Driver&Utility" folder .The following InstallShield Wizard box will show up to guide you how to install properly then click "Next".



B. Below dialog show the "License Agreement". To install the device you must accept this agreement to continue the process or select no to exit the installation. Select "Yes " to



continue.

C. Choose the "*Application*, *USB*, *PCI*, *PCMCIA Drivers*" type under the Adapter Type Dialog Window. Then click the "*Next*" to continue.

tap Type Choose the cetup type that best suits you	r needs.
Click the type of Setup you prefer.	
Application and PD Application and PDMCIA driven: Application and USB driven Application Only Application USB, FOL FOMOIA driven	Desception This Satup Tops willingtall opplication FCL POHCA4 and USB chowns





- D.
- Click the "*next*" to search for already installed component. To install to this folder in program files, click "*Next*". To install to a different folder click "*Browse*" and select **E**.

Descen Bretrotten Londitor Interfactor when listig wit or	-	
Samp and Address of Market	per a de letteres con	(0.00)
Particular local data from which they are been been to the	. To provide a diverse states while	free and seen
Solitabilitati Crisque Reicholde, 1981	T VMB/ 1/8	Dame:]
Salindarida Crisqua Haris Del Inti	1	_ <u>1000</u> _]

another folder .Then click "Next ".



Index! Program Falder	
Para-skir a populitike	
firing oil and program many in the Prop	arfeite Medicent Taxate income bille
care is take an horizon analy of	to be the first success.
Constant of the second s	
Campforne .	
ALC: NOTE: N	
Quelline 2	
Concession in the second	
THE PARTY AND ADDRESS OF TAXABLE PARTY.	
Account And MC	
A watches	
	Collection of the local states



- F. Click "Next " to begin copying file to your hard disk.
- G. After Windows 2000 finishes copying the files, it shows



"Window has finished installing the software for this device".Click "Finish" to complete the installation.



When you complete the installation, the Configuration & Monitor Utility icon will be shown on system tray, If not, that mean the installation is fail. Please uninstall the driver form the system then repeat the installation process.



Now, the Wireless LAN PCMCIA Card is SUCCESSFULLY installed.



The Configuration Utility is a powerful application that helps you to configure the Wireless PCMCIA Card and monitor the statistics of the communication process. By Double Click the icon on the system tray will brings you to the configuration mode.

ATHEL USE	PRIVNET (AR)	-
us Statistics Site	Survey Encryption Advan	ed Yec
Chembing Mode	Istratini, ine	
Clustered	0 Y	Change
SHD	marketing	Sahr
Tu Role	Auts -	
Power Mgmt Mode	dobwi 🗡 .	CROOM
MAC Atdress	[00-06-F4-00-00-E1	
Status	Associated - BSEID: 00-06-F4	-00-03-0
Signal Strength		
Link Quality	95 45	

This utility can be used to change the following configuration parameters when the device is active. Following details the configuration tabs.

<u>NOTE</u>	<u>:Click the "Exit" l</u>	button will	exit the	configuration
	appl	lication.		

3.1 "Status"

Click the *"Change"* tab when set up the necessary parameters, and click *"Submit"* after the configuration has been changed.

JII IIII ODD	Pastvinel (AR)
atus Statistics Site	Survey Encomption Advanced 5
	souvey Encryption Auvanced 1
Operating Mode	Infrastructure 🔄
Channel	6 Char
SSID	marketing
Tx Rate	Auto
Power Mgmt Mode	Active Can
MAC Address	D-06-F4-00-00-E1
Status	Associated - BSSID: 00-06-F4-00-03
Signal Strength	
	100 %
Link Quality	95 %

- Operation mode : Shows the following network modes :
 - Infrastructure -- This operation mode requires the presence of an 802.11 Access Point. All communication is done via the Access Point.
 - Ad-Hoc -- This mode indicates the 802.11 peer-to-peer operation. All communication is done from client to client without the use of an Access Point.
- Channel : Shows the number of the radio channel used for the networking. Only Access Points and Ad-Hoc nodes creates the BSSID. This parameters is not active in the infrastructure operation mode.
- SSID : Shows the SSID of the BSS that one willing to join.
- Tx Rate : Shows the Data Transfer Rate. There are 1 Mbps, 2M bps, 5.5 Mbps, 11 Mbps, and auto mode. If Auto Mode is been selected, the device will select the most suitable rate automatically.
- **Power Mgmt Mode :** Shows Power Management modes. There are two optional selections for this mode.
 - Active -- Adaptor will always set in active mode.
 - Power Save -- Adaptor will enter power saving mode when it is idle.
- Signal Strength : This bar shows the signal strength level. The higher the blue bar, the more radio signal been received by the WLAN PC Card. This indicator helps to find the most comfortable antenna/workstation position for quality network operation.
- Link quality : The measured Signal Strength level gives the overall Link Quality and Connection Status.
- MAC Address : The MAC Address of the Wireless PCMCIA Card. Unique 48-bit, hard-coded Media Access Control address known as the station identifier.

Status	Statistics	Site Survey	Encryption	Advanced Version
Data			Tx	Rx
Su	ccessful		37	1
Unsuccessful			0	0
Man	agement —			
Su	ccessful		2	1237
U	nsuccessful		0	0
Reje	cted Packet	5	0	0

3.2 "Statistics"

Shows the total amounts of packets been received or transmitted by the adaptor.

- Data Field : Shows the total amounts of data packets been successful/unsuccessful transmitted or received by the adaptor..
- Management Field : Shows the total amounts of management packets been successful/unsuccessful transmitted or received by the adaptor.
- Rejected Packets Field : Shows the total amounts of rejected packets been transmitted or received by the adaptor.





3.3 "Site Survey"

This screen shows all the AP or Adaptor nearby when operating in Ad-Hoc mode.

Click "*Re-Scan* " to collect the BSSID and Channel information of all the wireless devices near by.

If one wish to connect to any device on the list, double-click the selected list and the adaptor will connect to the selected device automatically.

	ATMEL US	B FastVNI	ET (AR)	•
Status	Statistics Si	ite Survey	Encryption Ad	vanced Versio
	Encryption		Disabled	•
1	Key #1	0000000	000	
	Key #2	0000000	1000	
	Key #3 0000000		000	
	Key #4	0000000	000	
	Default Key		Key #1	*
	Mode		Mandatory	-
	Authenticatio	on Type	Open System	-
1				Submit

3.4 "Encryption"

Additional security can be achieved by using the WEP (Wired Equivalent Privacy) encryption. WEP encrypts each frame transmitted from the radio using one of the keys entered from this panel.

There are four 10 Hex digit encryption keys value available for the WEP. One can define the encryption key values of their own choice.

Enable the WEP (Wired Equivalent Privacy) option in order to activate WEP encryption for transmissions between the stations and the Access Point. WEP is an authentication algorithm which protects authorized Wireless LAN users against eavesdropping.



tus Statistics Site Survey	Encryption Advanced Version
Preamble Type	 Long Short
Fragmentation Threshold Disabled	<u></u>
R TS/C TS Threshold Disabled	 2347
Disabled	2347

3.5 "Advanced"

There are **Preamble Type**, **Fragmentation Threshold**, and **RTS/CTS Threshold** setting under this mode.

- Preamble Type (Short/Long) : Preamble is the first subfield of PPDU, which is the appropriate frame format for transmission to PHY (Physical layer). There are two options, Short Preamble and Long Preamble. The Short Preamble option improves throughput performance.
- Fragmentation threshold : The size at which packets will be fragmented. Choose a setting within a range of 256 to 2346 bytes.
- RTS Threshold : Minimum packet size to require an RTS (Request To Send). For packets smaller than this threshold, an RTS is not sent and the packet is transmitted directly to the WLAN. This is the option for the RTS Threshold activation.





It shows the current *Driver*, *Firmware*, and *Application Version* of this device.



- Standard : IEEE802.11b
- Frequency Band : 2.400 GHz ~2.4835GHz
- Data Rate : Up to 11Mbps
- Interface : PCMCIA Type
- Transmission Range : Outdoor:100~300M , Indoor: 40~100M
- LED Indicators : Link
- Power consumption : 5V DC,1.0A
- > Operating Temperature : 0 to 55
- Storage Temperature : -20 to 70
- Operating Humidity : 0% to 70% Non-Condensing
- Storage Humidity : 0% to 95% Non-condensing
- Data Encryption : 64 bit/128 bit WEP Encryption
- Software : Configuration Utility software
- Compatibility : Windows 98/2000/ME, Windows XP
- Certification : FCC, CE
- Dimensions : 110x 54x 6mm

This section provides solutions to problems usually encountered

during the installation and operation of this Wireless PCMCIA Card. Read the description below to solve your problems.

What is the IEEE 802.11b standard? The IEEE 802.11b Wireless LAN standards subcommittee, which is formulating a standard for the industry. The objective is to enable wireless LAN hardware from different manufactures to communicate.

✓ What IEEE 802.11 feature are supported?

The product supports the following IEEE 802.11 functions: CSMA/CA plus Acknowledge protocol

Multi-Channel Roaming Automatic Rate Selection RTS/CTS feature Fragmentation Power Management

✓ What is Ad-hoc?

An Ad-hoc integrated wireless LAN is a group of computers, each with a WLAN adapter, Connected as an independent wireless LAN. Ad hoc wireless LAN is applicable at a departmental scale for a branch or SOHO operation.

What is Infrastructure ?

An integrated wireless and wireless and wired LAN is called an Infrastructure configuration. Infrastructure is applicable to enterprise scale for wireless access to central database, or wireless application for mobile workers.

✓ What is BSS ID ?

A specific Ad hoc LAN is called a Basic Service Set (BSS). Computers in a BSS must be configured with the same BSS ID.

What is WEP?

WEP is Wired Equivalent Privacy, a data privacy mechanism based on a 40 bit shared key algorithm, as

described in the IEEE 802 .11 standard.

 Can Wireless products support printer sharing ? Wireless products perform the same function as LAN products. Therefore, Wireless products can work with Netware, Windows NT/2000, or other LAN operating systems to support printer or file sharing.

Would the information be intercepted while transmitting on air?

WLAN features two-fold protection in security. On the hardware side, as with Direct Sequence Spread Spectrum technology, it has the inherent security feature of scrambling. On the software side, WLAN series offer the encryption function (WEP) to enhance security and Access Control. Users can set it up depending upon their needs.

What is DSSS ? What is FHSS ? And what are their differences ?

Frequency-hopping spread-spectrum (FHSS) uses a narrowband carrier that changes frequency in a pattern that is known to both transmitter and receiver. Properly synchronized, the net effect is to maintain a single logical channel. To an unintended receiver, FHSS appears to be short-duration impulse noise. Direct-sequence spread-spectrum (DSSS) generates a redundant bit pattern for each bit to be transmitted. This bit pattern is called a chip (or chipping code). The longer the chip, the greater the probability that the original data can be recovered. Even if one or more bits in the chip are damaged during transmission, statistical techniques embedded in the radio can recover the original data without-the need for retransmission. To an unintended receiver, DSSS appears as low power wideband noise and is rejected (ignored) by most narrowband receivers.

✓ What is Spread Spectrum ?

Spread Spectrum technology is a wideband radio frequency technique developed by the military for use in reliable, secure, mission-critical communication systems. It is designed to trade off bandwidth efficiency for reliability, integrity, and security. In other words, more bandwidth is consumed than in the case of narrowband transmission , but the trade off produces a signal that is, in effect, louder and thus easier to detect, provided that the receiver knows the parameters of the spread-spectrum signal being broadcast. If a receiver is not tuned to the right frequency, a spread –spectrum signal looks like background noise. There are two main alternatives, Direct Sequence Spread Spectrum (DSSS) and Frequency Hopping Spread Spectrum (FHSS).