

SOG01

Basic Manual

Online Manual (Japanese)

Check "Online Manual" (Japanese) which describes detail explanations on various functions on the product from this procedure.

In the Home screen, slide the screen up → [お客さまサポート (Customer support)] → [取扱説明書 (Online Manual)] (Japanese)

Also, you can check "Online Manual" (Japanese) on the au homepage.
[https://www.au.com/online-manual/sog01/\(Japanese\)](https://www.au.com/online-manual/sog01/(Japanese))

In this manual, the contents on Android 9 are provided. For the latest edition, refer to "取扱説明書 (Basic Manual)" (Japanese) available on the au homepage.
[https://www.au.com/support/service/mobile/guide/manual/\(Japanese\)](https://www.au.com/support/service/mobile/guide/manual/(Japanese))

- Flash/Photo light
- RGB-IR sensor: Detects element of lighting source of shooting environment to adjust white balance automatically when shooting.
- Wi-Fi® antenna²
- Built-in antenna/Wi-Fi® antenna²
- Built-in antenna²
- Camera lens
- au IC card (SIM card)
- Wi-Fi®/GPS/Bluetooth® antenna²
- Laser AF sensor: Detects distance from an object when shooting to focus the camera on automatically.
- mark
- Wireless charging touch point
- Back cover³
- Volume key/Zoom key
- Power key/Screen lock key/Fingerprint sensor
- Camera key

*1 Do not jab with a sharp object such as a needle. Doing so may cause a malfunction.
 *2 The antenna is built into the main unit. Covering around the antenna by your hand may affect the

3 Keep the product horizontal and then push the tray in straight
 Pay attention to the direction the tray is being pushed in.
 Firmly press where circled O, and check that there is no gap between the main unit and the microSD memory card/au IC card (SIM card) slot cover (▶P.13).

Charging

When you purchase your product, the internal battery is not fully charged. Charge the battery before use.

❖Information

- When charging starts, the Notification LED of the product lights according to the battery level. To check the battery level, see the status bar in the top of the screen, or in the Home screen, slide the screen up → [Settings] → [Battery].
- If you start charging with the product turned off, a screen launches indicating the charging status but operations are not available. Thus, do not charge the product in a place where the use is prohibited.
- The charging time may take longer when charging with a PC or while using the camera function.

■ Charging with the AC Adapter
 Charging with connecting TypeC Common AC Adapter O2 (sold separately) is explained.

- Insert the power plug of TypeC Common AC Adapter O2 (sold separately) into an outlet

STEP3: Setting wireless LAN (Wi-Fi®) connection

You can use a home wireless LAN (Wi-Fi®) or public wireless LAN to access the Internet services. Set it in a place where the signal of Wi-Fi® network can be received.

- Select a Wi-Fi® network
- Enter a password (security key) → [CONNECT]

Checking the Online Manual

Check "Online Manual" (Japanese) which describes detail explanations on various functions on the product from this procedure.

- Also, you can check "Online Manual" (Japanese) on the au homepage.
[https://www.au.com/online-manual/sog01/\(Japanese\)](https://www.au.com/online-manual/sog01/(Japanese))

- In the Home screen, slide the screen up
- [お客さまサポート (Customer support)]
- [取扱説明書 (Online Manual)] (Japanese)

quality of call/communication.
 *3 The back cover is not removable. Removing forcibly might cause damage or a malfunction. Also, battery is built into the main unit and not removable by customers.

FCC ID

To view the regulatory compliance mark

- Find and tap [Settings] → [About phone] → [Certificates]

Regulatory compliance mark such as FCC ID is displayed on the screen.

au IC card (SIM card)

Your phone number etc. is recorded in au IC card (SIM card). The product is compatible with au Nano IC Card O4.

Notification LED

The Notification LED prompts charging, or informs battery level while charging, missed calls, new mails, etc. by turning on or flashing.

2 Insert the USB Type-C plug of TypeC Common AC Adapter O2 (sold separately) into the USB Type-C connection terminal of the product straight
 When charging is started with the product powered on, the start sound for charging sounds and the Notification LED of the product lights.

- When charging is complete, remove the USB Type-C plug of TypeC Common AC Adapter O2 (sold separately) from the product
- Remove the power plug of TypeC Common AC Adapter O2 (sold separately) from the outlet

STEP4: Copy apps & data

- [DON'T COPY]

- To use the data of the other Android phone etc. successively, tap "NEXT" and follow the onscreen instruction.

Preface

Thank you for buying "Xperia" (simply called "the product" or "main unit" from here on). Before using the product, read "Basic Manual" (this manual) and "Cautions on using the product" for proper handling.

About Operating Instructions

- "Basic Manual" (this manual)
Handles only basic operations for main features.
- "Online Manual" (Japanese)
Check "Online Manual" (Japanese) which describes detail explanations on various functions on the product from this procedure. For details on checking, see "Checking the Online Manual" in this manual.
- "取扱説明書 (Full Instruction Manual)" (Japanese)
For detailed descriptions on various functions, you can refer to the "取扱説明書 (詳細版) (Full Instruction Manual)" (Japanese) available on the au homepage.
[https://www.au.com/support/service/mobile/guide/manual/\(Japanese\)](https://www.au.com/support/service/mobile/guide/manual/(Japanese))



LED Status	Description
Red	The battery is charging when the remaining battery level is 14% or lower.
Orange	The battery is charging when the remaining battery level is 15% - 89%.
Green	The battery is charging when the remaining battery level is 90% or higher.
Flashing red	The remaining battery level is 14% or lower.
Flashing white ¹	Indicates a missed call, new au-mail, new message, etc.

*1 Flashes in sleep mode.

Attaching/removing au IC card (SIM card)

Before attaching/removing au IC card (SIM card), make sure to turn off the product.

■ Attaching au IC card (SIM card)

- Remove the tray from the main unit**
Put your fingertip (nail) into the groove of the microSD memory card/au IC card (SIM card) slot and draw the cover straight out.
- Set au IC card (SIM card) into the tray with the IC (metal) part facing up**
Pay attention to the location of the notch. Surely set au IC card (SIM card) into the tray not to come off.
- Keep the product horizontal and then push the tray in straight**
Pay attention to the direction the tray is being pushed in.
Firmly press where circled O, and check that there is no gap between the main unit and the microSD

Turning the power on/off

■ Turning the power on

- Press and hold Power key until the product vibrates once**
The lock screen appears. When "ようこそ (Welcome)" appears after the product is powered on, follow the onscreen instructions to set the initial settings. For details on the initial settings, see "Initial settings" in this manual.
- Swipe (flick) the screen up**
The Home screen appears.

■ Turning the power off

- Press and hold Power key (over one sec.)**
 - [Power off]**
- ❖Information
- To restart the product in safe mode (start with almost default state), press and hold Power key (over one sec.) → Long-touch "Power off" → [OK].

■ Forcely turning the power off

- Press and hold Power key and the upper part of the volume key at the same time for approximately nine seconds, and release your fingers after the product vibrates three times consecutively**

STEP5: Setting up a Google account

Set up a Google account to synchronize with Gmail, contacts of online service, calendar, etc. Setting for creating a new Google account is explained here.

- If you set up a Google account, you can use Google apps such as "Gmail" or "Google Play".
- Although you can use the product without setting of a Google account, some apps using it cannot be used. When you activate the app, the setup screen for a Google account appears.

- [Create account] → [For myself]¹
- Enter "First name", "Last name" → [Next]

For Those Requiring an English Instruction Manual

Download URL:
<https://www.au.com/english/support/manual/>

Regarding notations used in this document

- In this manual, operations of tapping menu items/ icons/buttons on the screen, etc. are indicated as [(name of the item, etc.)].
- In this manual, screens and operations for the product with au Nano IC Card O4 attached are described.
- Screen illustrations shown in this manual may look different from the actual screens. In some cases, minor details or a part of a screen may be omitted.
- In this manual, "Basic Manual" (this manual), "Cautions on using the product" and "取扱説明書 (詳細版) (Full instruction manual)" (Japanese) are collectively referred to as "Instruction Manual".
- In this manual, explanations for the wallpaper "Black" are provided.
- In this manual, operations in portrait view are described as a standard. In horizontal view, menu items, icons, buttons on the screen, etc. may differ.
- In this manual, "au Nano IC Card O4" is abbreviated as "au IC card (SIM card)".

- In this manual, "microSD™" memory card (commercially available), "microSDHC™" memory card (commercially available) and "microSDXC™" memory card (commercially available) are abbreviated as "microSD memory card".
- All of the indicated amounts exclude tax unless otherwise specified.
- Company names and product names referred to in this manual are trademarks or registered trademarks of respective companies. The TM and ® marks may be omitted in this manual.
- "The Company" as appears in the manual refers to these companies:
 Sold by: KDDI CORPORATION, OKINAWA CELLULAR TELEPHONE COMPANY
 Manufactured by: Sony Mobile Communications Inc.

memory card/au IC card (SIM card) slot cover.

■ Removing au IC card (SIM card)

- Remove the tray from the main unit**
Put your fingertip (nail) into the groove of the microSD memory card/au IC card (SIM card) slot and draw the cover straight out.
- Remove the au IC card (SIM card) from the tray**
- Keep the product horizontal and then push the tray in straight**
Pay attention to the direction the tray is being pushed in.
Firmly press where circled O, and check that there is no gap between the main unit and the microSD memory card/au IC card (SIM card) slot cover (▶P.10).

Packaged items

Before your start using the product, make sure that you have all these packaged items with the product.

- Xperia
- USB Type-C™3.5φ conversion/TV Antenna cable O1 (O3SOHSA)
- 取扱説明書 (Basic Manual) (Japanese)
- ご利用にあたっての注意事項 (Cautions on using the product)(Japanese)
- Earphones
- USB Type-C cable

These items are not included in the package.

- microSD memory card
- AC adapter

❖Information

- Purchase a specified charger (sold separately).
- The battery is built into the product.
- Illustrations used in this manual are just images for explanations. They may be different from actual ones.

Attaching/Removing a microSD memory card

Before attaching/removing microSD memory card, make sure to turn off the product.

■ Attaching a microSD memory card

- Remove the tray from the main unit**
Put your fingertip (nail) into the groove of the microSD memory card/au IC card (SIM card) slot and draw the cover straight out.
- Set a microSD memory card into the tray with the terminal side facing up**
Surely set a microSD memory card into the tray not to come off.

■ Removing a microSD memory card

- Remove the tray from the main unit**
Put your fingertip (nail) into the groove of the microSD memory card/au IC card (SIM card) slot and draw the cover straight out.
- Remove the microSD memory card from the tray**

Getting Ready

Names and functions of parts

- Headset connection terminal
- Second microphone¹: Reduces noise so that the other party can easily hear your voice.
- microSD memory card/au IC card (SIM card) slot
- Front camera
- Earpiece/Speaker
- Proximity/Light sensor: Switches the touch panel on and off to prevent from erroneous operation during a call/ Auto-control for display brightness.
- Notification LED (▶P.8)
- Display (Touch panel)
- Speaker
- Mouthpiece¹/Microphone¹
- USB Type-C connection terminal

3 Keep the product horizontal and then push the tray in straight
 Pay attention to the direction the tray is being pushed in.
 Firmly press where circled O, and check that there is no gap between the main unit and the microSD memory card/au IC card (SIM card) slot cover.

■ Removing a microSD memory card

- Remove the tray from the main unit**
Put your fingertip (nail) into the groove of the microSD memory card/au IC card (SIM card) slot and draw the cover straight out.
- Remove the microSD memory card from the tray**

Initial settings

When "ようこそ (Welcome)" appears after the product is powered on, follow the onscreen instructions to set functions and services.

STEP1: Start of setting

- [GET STARTED]
- Confirm contents¹ → Mark items you agree to → [ACCEPT]

- To change the language, tap "日本語 (Japanese)" to open the language list, select "English" → "United States".

*1 Tap "Data charges", "Detailed Diagnostics", and "Privacy Policy" to confirm the contents.

STEP6: Setting Google services

- Confirm/change each setting → [MORE]
- Confirm/change each setting → [ACCEPT]

- *1 If you have your Google account, enter the Gmail address or the phone number and tap "Next", and follow the onscreen instructions.
- *2 You can also select a Gmail address you have prepared.

STEP2: Setting up the network connection

- Select a network connection method

- When you select "Use mobile network for setup", tap "CONTINUE" to proceed to "STEP 4".

STEP7: Setting the unlock method of using fingerprint

Set whether to use the fingerprint authentication function. Before registering a fingerprint, set the screen lock unlock method.

- [NEXT]¹
- Follow the onscreen instructions²

*1 To not register your fingerprint, tap "SKIP". To not set screen lock, continue by tapping "SKIP".
 *2 To change screen lock unlock method, tap "Screen lock options".

STEP8: Setting up Google Assistant

1 Tap **[MORE]** → **[TURN ON]**¹

2 Tap **[NEXT]** → **[I AGREE]** → Follow the onscreen instruction

¹ To not set, tap "NO THANKS".

- If Google account is not set, the setting of Google Assistant is not displayed.
- When a settings screen for Google Pay, etc. appears, follow the onscreen instructions.

STEP9: Setting up additional apps

1 Tap an item to open an app introduction.

2 Tap **[OK]**

¹ Tap an item to open an app introduction.

STEP10: Setting up more things

1 Tap items you want to set, and follow the onscreen instructions.

2 Tap **[FINISH]** to complete initial settings.

¹ To make other settings, tap items you want to set, and follow the onscreen instructions. The screen for setting more things does not appear if you do not set the fingerprint authentication or screen lock unlock method.

- Tap "FINISH" to complete initial settings.
- Downloading of the applications selected in "STEP 9" starts when the product is connected to Wi-Fi[®].

au initial settings

Update preinstalled apps, setting an au ID, download previously used apps, or make settings for using the product more convenient.

- By setting an au ID, you can use various services provided by au such as auスマートパス (au Smart Pass) or 'au Kantan Kessai (Easy Payment)', which allows you to do things such as purchase apps from Google Play.
- Alternatively, after the initial setting, in the Home screen, slide the screen up → [Settings] → [au Settings Menu] → [au Initial Setting].

1 Tap **[GET STARTED]** → **[Sign in]**¹

2 Tap **[Sign in]**¹

Mark/unmark "Update" → **[GET STARTED]**

3 Enter PIN number² → **[次へ (Next)]**

4 Enter a password → **[同意して次へ (Agree, and next)]**

5 **[次へ (Next)]**

6 **[OK]**

7 **[ALLOW]**³

8 Tap **[Next]** → **[Next]**

9 Tap **[Next]** → **[Next]**

10 Tap **[Finish]**⁵

- If you have already been registered an au ID, step 3 and 4 do not appear. Proceed to step 5.
- PIN number is a four digit number chosen by the customer and noted on the application form.
- The confirmation screen for app permission appears several times. Operate in the same way.
- When "Select apps" appears in "Backed up", tap it to check the apps.
- If there is any data backed up by "Data Storage App", you can restore them. Tap "Restore from backup now" and follow the onscreen instructions.

au-mail setting

- To use au-mail, subscription to LTE NET is required. If you did not subscribe it when you purchased the product, contact an au shop or Customer Service Center.
- Perform the initial settings in a place with good signal condition in Japan. If you perform in a place with bad signal condition or while moving, the settings may fail. The initial setting cannot be made via Wi-Fi[®] communication.
- Depending on time zone, the initial settings may take from 30 seconds to 3 minutes. Wait for a while with "メールアドレスの設定中です。しばらくお待ちください。 (Setting email address. Wait for a while.)" displayed on the screen.

Making the initial settings

1 From the Home screen, **[📧]**

2 Confirm the content → **[Agree]**

3 Confirm the content → **[Agree]** → Follow the onscreen instruction

4 Checking au-mail address¹ → **[閉じる (Close)]**

¹ For change of model, the au-mail address which you have been used so far is displayed.

Checking your au-mail address

1 From the Home screen, **[📧]** → **[📧]** → [E-mail information]

Checking the operations of au-mail app

1 From the Home screen, **[📧]** → **[📧]**

2 [Operation guide] (Japanese)

Changing your au-mail address

- From the Home screen, **[📧]** → **[📧]** → [Change Address/Setting Filter] → **[OK]**
- [メールアドレスの変更へ (To change Mail address)]** → Enter the security code¹ → **[送信 (Send)]** → **[OK]**
- Confirm the content → **[承諾する (I agree)]** → Mark "ご希望のメールアドレスに変更する (Change to your desired mail address)" and enter a mail address of your choice → **[送信 (Send)]** → **[OK]**

¹ PIN number is a four digit number chosen by the customer and noted on the application form.

- When the confirmation screen appears, follow the onscreen instructions.
- The operations or the screen displays are subject to change without notice.

Transferring data from au Settings Menu

Import or export data between the product and your previous au mobile phone by using microSD memory card or via the au server.

- To import data via the au server, save data to the au server from your previous au mobile phone in advance. To use the au server, set an au ID (if there is no au Settings Menu on your previous au mobile phone, use "au Cloud" app).
- To import data by using a microSD memory card, save the data to a microSD memory card from your previous au mobile phone in advance (if there is no au Settings Menu on your previous au mobile phone, use "au backup" app).

1 In the Home screen, slide the screen up

2 **[Settings]** → **[au Settings Menu]**

3 **[Data Transfer]**

4 **[機種変更はこちら (For change of model, tap here)]** → Follow the onscreen instructions

- To back up photos and contacts to the au server automatically using "Data storage App", use this procedure. In the Home screen, slide the screen up → [Settings] → [au Settings Menu] → [Backup Setting] → Mark items to back up automatically

Phone

Making a call

- Direct input calling**
 - From the Home screen, **[📞]** → **[📞]**
 - Enter a phone number → **[📞]**
 - To make a call to a land-line phone, enter from the city code even when you stay in the same city.
 - Call → **[📞]**
 - To adjust the in-coming volume (volume of the other party's voice), press the upper part or lower part of the volume key while calling.

- Calling from history**
 - From the Home screen, **[📞]** → Tap **[📞]** tab
 - [📞]** of call history
- Calling from contacts**
 - In the Home screen, slide the screen up → [Contacts]
 - Tap a contact to call
 - Tap [Call]/phone number

Receiving a call

- When the screen is OFF or on the lock screen

1 Incoming call screen → **Swipe (flick) "📞" up**
To reject the incoming call, swipe (flick) "📞" down. To answer with Answering Machine, swipe (flick) "📞".

2 Call → **[📞]**

- When the screen is ON (except on the lock screen)

1 In the displayed notification, [ANSWER]
To reject an incoming call, tap "DECLINE". To answer with Answering Machine, tap the top part of the notification → **Swipe (flick) "📞"**.

2 Call → **[📞]**

Setting wireless LAN (Wi-Fi[®])

You can use a home wireless LAN (Wi-Fi[®]) or public wireless LAN to access the Internet services. Set it in a place where the signal of Wi-Fi[®] network can be received.

1 In the Home screen, slide the screen up

2 **[Settings]** → **[Network & internet]**

3 **[Wi-Fi]**¹

4 Select a Wi-Fi[®] network → Enter a password (security key) → **[CONNECT]**

¹ If Wi-Fi[®] is off, set it on.

Setting the lighting time of screen

The screen turns off automatically when the set time has elapsed while no operation is made. When you cannot operate readily because the screen turns off soon, change the lighting time.

1 In the Home screen, slide the screen up

2 **[Settings]** → **[Display]**

3 **[Sleep]**

4 Select the lighting time

Appendix

Peripheral devices

- USB Type-C™-3.5φ conversion/TV Antenna cable O1 (Q3SOHSA)
- TypeC Common AC Adapter O1 (O601PQA) (sold separately)
- TypeC Common AC Adapter O2 (O602PQA) (sold separately)¹
- Common AC Adapter O5 (O501PWA) (sold separately)¹
- Common DC Adapter O3 (O301PEA) (sold separately)
- Micro-B Type-C Adapter (O601PHA) (sold separately)
- au Carrying Case G Black (O106FCA) (sold separately)

¹ For use, Micro-B Type-C Adapter (sold separately) is needed.

- Information**
- Accessories can be purchased from the au Online Shop. <https://onlineshop.au.com/> (Japanese)

Main specifications

Main unit		
Display	Approx. 6.1 inches Organic EL (HDR-capable), Approx. 16.77 million colors 1,080 x 2,520 dots	
Weight	Approx. 178 g	
Dimension (W x H x T)	Approx. 71 mm x 165 mm x 7.9 mm (9.1 mm where thickest)	
Internal memory	ROM: Approx. 64 GB RAM: Approx. 6 GB	
Camera pixels	Camera: Effective pixels Approx. 12.2 million pixels / 12.2 million pixels Front camera: Effective pixels Approx. 8 million pixels	
Continuous call time	In Japan	Approx. 1,760 min.
	Overseas (GSM)	Approx. 590 min.
Continuous stand-by time	In Japan	Approx. 410 hours
	Overseas (GSM)	Approx. 420 hours

Charging time	Using TypeC Common AC Adapter O1 (sold separately): Approx. 170 min. Using TypeC Common AC Adapter O2 (sold separately): Approx. 140 min.	
Continuous Full Seg watching time	Approx. 10 hours 20 min.	
Continuous 1Seg watching time	Approx. 12 hours 0 min.	
Continuous tethering time	Approx. 660 min.	
Wi-Fi [®] tethering maximum connection number	10	
Bluetooth [®] function	Communication type	Compliant with Bluetooth [®] standard Ver.5.0
	Output	Compliant with Bluetooth [®] standard Power Class 1
	Communication coverage distance ¹	Within 10 m with good visibility
Supported Bluetooth [®] profile ²	HSP, HFP, PBAP ³ , A2DP, apt-X, AVRCP, SPP, OPP, HID, HOGP, MAP, DUN ⁴ , GATT, PAN-NAP, PANU	

Bluetooth [®] function	Radio frequency band	2.4 GHz band (2,400 MHz - 2,483.5 MHz)
---------------------------------	----------------------	--

- Varies by obstruction between communication devices or radio wave reception status.
 - It is a specification according to purpose of use of Bluetooth[®] device and is defined by Bluetooth[®] standard.
 - Some contacts data may not be displayed correctly on the other party's device.
 - Supported to some car navigation systems. For use, refer to the au homepage.
- Information**
- The continuous call time, continuous stand-by time, continuous Full Seg watching time, continuous 1Seg watching time and continuous tethering time may drop to less than half depending on the battery charging status, usage environment such as temperature, reception condition at the location where the product is used, and the function settings.

- USB Type-C™-3.5φ conversion/TV Antenna cable O1

Size	Length
Weight	Approx. 117 mm
	Approx. 5 g

For inquiries, call: Customer Service Center

For general information (toll free)
Business hours 9:00-20:00 (7 days a week)
From au mobile phones | From non-au mobile phones/general subscriber phones
157 without area code **[📞] 0077-7-111**
In case above numbers are not available (toll free).
[📞] 0120-977-033 (except Okinawa) **[📞] 0120-977-699** (Okinawa)

For theft, loss, or malfunction (toll free)
Business hours : 24 hours live support
From au mobile phones | From non-au mobile phones/general subscriber phones
113 without area code **[📞] 0077-7-113**
In case above numbers are not available (toll free).
[📞] 0120-925-314

Repair and Delivery Support Center
For theft, loss, or malfunction (toll free) | From au mobile phones/non-au mobile phones/general subscriber phones
Business hours 9:00-20:00 (7 days a week) **[📞] 0120-925-919**

