

Contents

Set up your phone	4
Phone overview	7
Key functions	8
Phone language	10
Entering letters and characters	11
Calling	12
Contacts	14
Text messages	15
Picture messages	16
Camera	16
Infrared port	17
Internet	18
Sounds & Alerts	19
Alarms	19
Settings	20
Troubleshooting	22
Important information	25
Index	38

*Congratulations on your purchase of the
Sony Ericsson K200a. For additional phone content,
go to www.sonyericsson.com/fun.*

*Register now to get free online storage and special offers at
www.sonyericsson.com/myphone.
For product support, go to www.sonyericsson.com/support.*

Sony Ericsson

GSM 850/1900

This User guide is published by Sony Ericsson Mobile Communications AB or its local affiliated company, without any warranty. Improvements and changes to this User guide necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by Sony Ericsson Mobile Communications AB or its local affiliated company at any time and without notice. Such changes will, however, be incorporated into new editions of this User guide.

All rights reserved.

© Sony Ericsson Mobile Communications AB, 2007

Publication number: EN/LZT 108 9149 R1A

Please note:

Some of the services in this User guide are not supported by all networks. *This also applies to the GSM International Emergency Number 112.*

Please contact your network operator or service provider if you are in doubt whether you can use a particular service or not.

Please read the *Guidelines for safe and efficient use* and the *Limited warranty* chapters before you use your mobile phone.

Your mobile phone has the capability to download, store and forward additional content, e.g. ringtones. The use of such content may be restricted or prohibited by rights of third parties, including but not limited to restriction under applicable copyright laws. You, and not Sony Ericsson, are entirely responsible for additional content that you download to or forward from your mobile phone. Prior to your use of any additional content, please verify that your intended use is properly licensed or is otherwise authorized. Sony Ericsson does not guarantee the accuracy, integrity or quality of any additional content or any other third party content. Under no circumstances will Sony Ericsson be liable in any way for your improper use of additional content or other third party content.

The marble logo is a trademark or registered trademark of Sony Ericsson Mobile Communications AB. Sony is a trademark or registered trademark of Sony Corporation. Ericsson is a trademark or registered trademark of Telefonaktiebolaget LM Ericsson.

T9™ Text Input is a trademark or a registered trademark of Tegic Communications.

T9™ Text Input is licensed under one or more of the following: U.S. Pat. Nos. 5,818,437, 5,953,541, 5,187,480, 5,945,928, and 6,011,554; Canadian Pat. No. 1,331,057; United Kingdom Pat. No. 2238414B; Hong Kong Standard Pat. No. HK0940329; Republic of Singapore Pat. No. 51383; Euro. Pat. No. 0 842 463 (96927260.8) DE/DK, FI, FR, IT, NL, PT, ES, SE, GB; and additional patents are pending worldwide.

Other product and company names may be the trademarks of their respective owners.

Sony Ericsson advises users to backup their personal data information.

All illustrations are for illustration only and may not accurately depict the actual phone.

Any rights not expressly granted herein are reserved.

User guide symbols

The following instruction symbols appear in this User guide:




- This arrow points you to a page with more information.
- Use the navigation key to scroll and the selection key to select.



Note

Set up your phone


Insert the SIM card and battery



- 1 Gently pull the cover away from the phone.
- 2 Insert the SIM card. Make sure the SIM card is placed under the silvery holders and that the contacts of the SIM card face downwards.
- 3 Place the battery on the back of the phone with the label side up and the connectors facing each other.
- 4 Replace the cover as shown in the picture.

 *If you have been using a SIM card in another phone, make sure that your information is saved to the SIM card before you remove it from the other phone.*

Charge the battery



- 1 Connect the battery charger to the phone.
- 2 It may take up to 30 minutes before the battery icon appears on the screen.
- 3 Wait approximately 2.5 hours or until the battery icon indicates that the battery is fully charged. If you do not see the battery icon after this time, press any key above the number keys to activate the screen.
- 4 Remove the battery charger by tilting it upwards.

 *The time and date are reset when you remove the battery.*

5

Turn on the phone



- 1 Press and hold  until the screen lights up.
- 2 Enter your PIN code, if requested and select **OK**. Each digit appears as *. Press the right selection key  to correct mistakes. If the screen turns dark, press any key to illuminate the screen.
- 3 Scroll to a language and select **Save**.
- 4 Enter the time and select **Save**.
- 5 Enter the date and select **Save**.

 *If you enter the wrong PIN three times in a row, the SIM card is blocked. To unblock it ➡ 24 PIN blocked.*


To turn off the phone

- Press and hold .

Standby

After you have turned the phone on and entered your PIN, the name of your operator appears on the screen. This is called standby – you can now make and receive calls.

Phone overview



1	Infrared port	6	Keylock
2	Strength of GSM network (Five blue bars mean full network coverage)	7	Headset and battery charger connector
3,9	Function of selection key	8	Battery status (a green battery means fully charged)
4,10	Selection keys	11	Navigation key with shortcuts
5	Call key	12	End call/On-Off key

Key functions

To go to the main menu

- From standby press  to select Menu. The first menu you will see is Message.



To navigate the menus

- Press the navigation key up  or down  to scroll.



To use the selection keys

- Press  to select the options shown immediately above these keys on the screen.

To go back one level or end a function

- Press the right selection key  to go back one level in the menus.
- Press  to end a function and go to standby.

To turn the screen light on

- Press any key.

Shortcuts

From standby, you can use the navigation key to go directly to a function:

- Press  to write a text or picture message.
- Press  to go to the camera.
- Press  to set the ring volume.
- Press  to go to your contacts.

To set the ringtone to silent

- From standby press  and select Silent.

To lock or unlock the keypad

- To avoid dialling a number by accident, press  and select Lock keys.
- To unlock the keypad, press  and select Unlock.



 You can still answer a call, and call the international emergency number 112 when the keypad is locked.

Icons

These icons appear on the screen to show status and new events.

Icon Description

-  You have received a new text or voice* message.
► 15 Text messages and ► 14 Voice messages
-  You have received a new picture message.
► 16 Picture messages
-  The phone is set to silent. ► 9 To set the ringtone to silent
-  The keypad is locked. ► 9 To lock or unlock the keypad
-  An alarm is activated. ► 19 Alarms
-  Divert calls* is activated. ► 13 Diverting calls

For more information, see www.sonyericsson.com/support.

* Some items may be operator-, network- and subscription-dependent.

Phone language

To change the phone language

- From standby select Menu ► Settings ► Language and select a language.

Entering letters and characters

You can enter letters and characters using either the Multitap or the T9™ Text Input method. T9 text input uses a dictionary to recognize words.

To change writing method

- When you enter letters, press and hold .

Common for both text input methods

- Press the right selection key to delete characters.
- Press and hold  to change writing language.
- Press  to add a comma, period, question mark, etc.
- Press  to shift between capitals and lower case letters.
- Press and hold  –  to enter numbers.

To enter letters using multitap text input

- 1 Press  –  repeatedly until the desired letter appears.
- 2 When a word is finished, press  to add a space.

To enter letters using T9 Text Input

- 1 Press each key only once, even if the letter you want is not the first letter on the key. For example, to write the word "Jane", press    .
- 2 Accept a word and add a space by pressing . To accept a word without adding a space, press . If the word shown is not the one you want, press  or  repeatedly to view alternative words.

Calling



To make a call

- 1 Enter the area code and phone number.
- 2 Press  to call. Press  to end the call.



To answer or reject a call

- Press  to answer a call.
- Press  to reject a call.

To make international calls

- 1 Press and hold  until a + sign appears.
- 2 Enter the country code, area code (without the leading zero), phone number and press .

To make an emergency call

- Enter, for example, 112 and press . Press the right selection key to correct mistakes.

To check your missed calls

- 1 When Missed calls: is displayed, select Details to display the missed calls.
- 2 To call a number, scroll to the number and press .

To change the ear speaker volume during a call

- Press  to increase the volume and  to decrease the volume.



To set the vibrating alert

- From standby select Menu ▶ Settings ▶ Sound & alerts ▶ Vibration and select an option.

Call options

During a call you can use Options, for example, to turn off the microphone.

Call list

Information about the last 30 calls is saved in Call list.

 indicates that you have missed a call.

To call a number from the call list

- 1 From standby press  and scroll to one of the numbers.
- 2 Press  to call.

Diverting calls

If you cannot answer incoming calls, you can divert them to another number, for example, your answering service.

To activate a call divert

- 1 From standby select Menu ▶ Calls ▶ Call settings ▶ Divert all calls.
- 2 Scroll to one of the divert options and select Activate.
- 3 Select an option.

Voice messages

If your subscription includes an answering service, callers can leave a voice message when you cannot answer a call.

To call your voicemail service

- From standby, press and hold  1, if you have saved your voicemail number in the phone.

To enter your voicemail number

- 1 From standby select Menu ▶ Contacts ▶ Voicemail.
- 2 Add voicemail number? appears. Select Yes.
- 3 Enter the voicemail number that you get from your service provider and select Save.

Contacts

You can save names and numbers in Contacts.

To add a contact

- 1 From standby select Menu ▶ Contacts ▶ Add contact and select an option.
- 2 Enter the name and select Options ▶ OK.
- 3 Scroll to the icon below the name.
- 4 Enter the number and select OK.
- 5 Select Save contact.

To call a contact

- 1 From standby press .
- 2 Scroll to the contact and press .

Contact options

When a contact is selected you can use Options, for example, to delete it.

Text messages

Text messages can be sent to a mobile phone number or to a contact.

To receive text messages

- 1 Read now? appears. Select **View**.
- 2 Scroll to the unread message and select **Read**.

To read text messages

- 1 From standby select **Menu ▶ Message ▶ Text message ▶ Inbox**.
- 2 Scroll to a message and select **Read**.

To write and send a text message

- 1 From standby press .
- 2 Select **Text message** and write your message. Select **Options**, for example, to add a symbol.
- 3 When the message is ready, select **Options ▶ Send message**.
- 4 Retrieve a recently used number, or look-up from contacts, or enter phone number.
- 5 Select **Send message**. If the message fails to be sent, it is saved in **Unsent**.

Text message options

When a text message is displayed you can use **Options**, for example, to delete it.

Picture messages

Picture messages are used in a similar way as text messages but can also contain pictures or camera pictures. If settings are not in your phone ► 23 *Why can't I use Internet or picture messages?*

 *Sending and receiving phones must have subscriptions that support picture messaging.*

To save an item in a received picture message

- 1 Scroll to the item and select Options.
- 2 Select Save picture or Save melody. Items are saved in corresponding folders in Extras ► My files.

Camera

Your phone has a digital camera to take pictures to save or send. Pictures taken with the camera are saved in Camera ► Camera pics. The format is JPEG.

 *Pictures downloaded via picture messages, Internet or Infrared are saved in Extras ► My files ► My pictures.*

To start the camera and take a picture

- 1 From standby press . You can see the subject on the phone screen.
- 2 Select Take pic. to take the picture.

 *A strong light source such as direct sunlight or a lamp can make the screen black out or the picture may be distorted.*

To save a picture

- When you have taken a picture, select **Save**. The picture is saved in **Camera ▶ Camera pics**.

 *When the memory is full, you need to delete items before you can save the picture.*

To delete a picture

- When you have taken a picture, select **Delete**.
- Delete picture?** appears. Select **Yes**.

Picture options

When you view a saved picture you can use **Options**, for example, to delete or send it.

Infrared port

You can use infrared to send, for example, pictures to another phone or a computer.


To turn on infrared

- From standby select **Menu ▶ Settings ▶ Infrared port ▶ On**.

 *If set to On but not used, the infrared port automatically turns off after 10 minutes.*

To connect two devices

- 1 Turn on infrared in both devices.
- 2 Make sure the infrared port on your phone is facing the infrared port on the other device with a maximum distance of 20 cm.



To transfer items using infrared

- 1 Select an item to transfer.
- 2 Select Options ► Send via IR.

Internet



If settings are not in your phone ► 23 *Why can't I use Internet or picture messages?*

 You need a phone subscription that supports data transmission.

To select an Internet profile

- 1 From standby select Menu ► Extras ► Internet ► Internet profile.
- 2 Select a profile to use.

To start browsing

- From standby select Menu ► Extras ► Internet ► Go to URL. Enter a Web address or select an already used Web address.

To stop browsing

- When you browse, select Back until you exit the Internet.

Internet options

When you browse you can select Options, for example, to create bookmarks.

Sounds & Alerts

Your phone comes with a number of standard and polyphonic melodies which can be used as ringtones.

 *Do not hold the phone to your ear when using high ringtones as this can damage your hearing.*

To select a ringtone

- From standby select Menu ► Settings ► Sound & alerts ► Ringtone.
- Select a ringtone. The sound is played when selected.

To set the ring volume

- From standby select Menu ► Settings ► Sound & alerts ► Ring volume.
- Select an option. The sound is played when selected.

Alarms

The alarm rings even if the phone is set to silent or turned off.

To set an alarm

- From standby select Menu ► Extras ► Alarm clock.
- Enter a time for the alarm and select Save.
- Select if the alarm should recur or only sound on one occasion.

To turn an alarm off when it rings

- Select Stop, or Snooze to snooze for 9 minutes. Snooze is automatically turned on if you do not press any key.

To disable an alarm

- From standby select Menu ▶ Extras ▶ Alarm clock
▶ Alarm off.

Settings

To select a wallpaper

- 1 From standby select Menu ▶ Settings ▶ Wallpaper and select an option.
- 2 Preview and select.

To select a theme

- From standby select Menu ▶ Settings ▶ Theme and select a theme.

To set the date

- 1 From standby select Menu ▶ Settings ▶ Time and date ▶ Date ▶ Set date.
- 2 Enter the date and select Save.

To set the time

- 1 From standby select Menu ▶ Settings ▶ Time and date ▶ Time ▶ Set time.
- 2 Enter the time and select Save.

Master reset

You can reset all settings in the phone to the way they were when you bought your phone.

To reset the settings you have made in the phone

- 1 From standby select Menu ▶ Settings ▶ Advanced ▶ Master reset.
- 2 Select an option. If you do not want to reset user data as contacts, messages, pictures and sounds, select Reset settings. The reset may take a few minutes.

Automatic keylock

Automatic keylock in standby means the keypad is locked a short while after you last pressed a key.

To set the automatic keylock

- From standby select Menu ▶ Settings ▶ Advanced ▶ Auto keylock and select an option.

SIM card lock

The SIM card lock protects your subscription, but not your phone itself, from unauthorized use. If you change SIM cards, the phone still works with the new SIM card.

To turn the SIM card lock on or off

- 1 From standby select Menu ▶ Settings ▶ Advanced ▶ Security ▶ SIM lock ▶ Protection and select an option.
- 2 Enter your PIN and select OK.

To edit your PIN

- 1 From standby select Menu ▶ Settings ▶ Advanced ▶ Security ▶ SIM lock ▶ Change PIN.
- 2 Enter your PIN and select OK.
- 3 Enter a new four- to eight-digit PIN and select OK.
- 4 Re-enter the new PIN to confirm and select OK.

Troubleshooting

Some problems require that you call your service provider, but most of the problems you can easily correct yourself. Remove the SIM card before handing your phone in for repair.

Why do I have problems with memory capacity and speed?

You need to restart your phone from time to time.

- 1 Turn off the phone and remove the battery cover
➡ 4 Insert the SIM card and battery.
- 2 Remove the battery for 10 seconds and then insert it in the phone.
- 3 Put the battery cover on and turn on the phone.

My screen freezes or flickers, what should I do?


- Do a master reset ➡ 20 Master reset.

Why can't I turn on my phone?

- Try charging the battery until it is fully charged. The battery icon may not appear until the phone has charged for 30 minutes.

Why can't I charge my phone?

- Attach the charger properly.
The power icon on the charger should face upwards.



Why does my phone turn itself off?

Something in your pocket or bag has probably activated the on/off key.

- Lock the keypad ➡ 21 Automatic keylock.

Why can't I use SMS/text messages?

The number to your service centre is not saved on your SIM card. You must specify the number yourself. If you cannot find your service centre number, please contact your service provider.

- 1 From standby select **Menu ▶ Message ▶ Settings ▶ Text message ▶ Service centre**. The number is shown if it is saved on the SIM card.
- 2 If there is no number, enter it, including the international "+" sign and country code. Select **Save**.

Why can't I use Internet or picture messages?

You need a phone subscription that supports data transmission (Internet) or picture messages. You also need the correct settings in your phone.

To get the necessary settings

- 1 Either receive settings in a text message from your network operator, or use a computer to go to www.sonyericsson.com/support and request that a text message with the settings is sent to your phone.
- 2 When the message with the settings arrives, **New settings received** appears. Select **Yes** to install the settings. If settings already exist in your phone you can either keep or replace them.

Why are words suggested when I am writing?

T9™ text input is turned on.

- Turn T9™ text input off ➡ 11 *To change writing method*.

What is my phone lock code?

A phone lock protects your phone against unauthorized use. If a different SIM card is inserted in the phone, the phone lock code has to be entered. The default phone lock code is 0000.

To turn the phone lock code on or off

- 1 From standby select Menu ▶ Settings ▶ Advanced ▶ Security ▶ Phone lock ▶ Protection.
- 2 Select an option.
- 3 Enter the phone lock code and select **OK**.

What do the error messages mean?

PIN blocked

You have entered the wrong PIN code three times. Your phone is now locked. Unlock your phone with your PUK code, which is provided together with your PIN code by your network operator.

- 1 Enter your PUK code and select **OK**.
- 2 Enter a new four- to eight-digit PIN and select **OK**.
- 3 Re-enter the new PIN to confirm and select **OK**.

Insert SIM card

Your SIM card is not inserted correctly or may be damaged or dirty. Try one or more of the following:

- Remove the SIM card and insert it correctly.
- Clean the connectors on the SIM card and phone with a soft brush, a cloth or a cotton bud moistened with any type of unflavoured colourless alcohol.
- Check if the SIM card is damaged.
- Contact your network operator to get a new SIM card.

Searching for network

Your phone is not receiving a signal from a network operator.

- Try moving to a location where you have received good network coverage earlier.

Emergency calls only

You are having problems accessing your own network. You can only make emergency calls from this location.

- Try moving to another location.

Important information

Sony Ericsson Consumer Web site

On www.sonyericsson.com/support there is a support section where help and tips are only a few clicks away. Here you will find the latest computer software updates and tips on how to use your product more efficiently.

Service and support

From now on you will have access to a portfolio of exclusive service advantages such as:

- Global and local Web sites providing support
- A global network of Call Centers
- An extensive network of Sony Ericsson service partners
- A warranty period. Learn more about the warranty conditions in this User guide

On www.sonyericsson.com, under the support section in the language of your choice, you will find the latest support tools and information, such as software updates, Knowledge base, Phone setup and additional help when you require it.

For operator-specific services and features, please contact your network operator for more information.

You can also contact our Call Centers. Use the phone number for the nearest Call Center in the list below. If your country/region is not represented in the list, please contact your local dealer. (The phone numbers below were correct at the time of going to print. You can always find the latest updates on www.sonyericsson.com.)

In the unlikely event that your product needs service, please contact the dealer from whom it was purchased, or one of our service partners. Save your proof of purchase, you will need it if you need to claim warranty. You will be charged for a call to one of our Call Centers according to national rates, including local taxes, unless the phone number is a toll-free number.

Australia	1-300 650 050 questions.AU@support.sonyericsson.com
Argentina	800-333-7427 questions.AR@support.sonyericsson.com
Austria	0810 200245 questions.AT@support.sonyericsson.com
Belgium	02-7451611 questions.BE@support.sonyericsson.com
Brazil	4001-0444 questions.BR@support.sonyericsson.com
Canada	1-866-766-9374 questions.CA@support.sonyericsson.com
Central Africa	+27 112589023 questions.CF@support.sonyericsson.com
Chile	123-0020-0656 questions.CL@support.sonyericsson.com
China	4008100000 questions.CN@support.sonyericsson.com
Colombia	18009122135 questions.CO@support.sonyericsson.com
Croatia	062 000 000 questions.HR@support.sonyericsson.com
Czech Republic	844 550 055 questions.CZ@support.sonyericsson.com
Denmark	33 31 28 28 questions.DK@support.sonyericsson.com
Finland	09-299 2000 questions.FI@support.sonyericsson.com
France	0 825 383 383 questions.FR@support.sonyericsson.com
Germany	0180 534 2020 questions.DE@support.sonyericsson.com
Greece	801-11-810-810 210-89 91 919 (from mobile) questions.GR@support.sonyericsson.com

Hong Kong	8203 8863 questions.HK@support.sonyericsson.com
Hungary	06 1 437 7300 questions.HU@support.sonyericsson.com
India	39011111 (Add STD code from a GSM connection) questions.IN@support.sonyericsson.com
Indonesia	021-2701388 questions.ID@support.sonyericsson.com
Ireland	1850 545 888 questions.IE@support.sonyericsson.com
Italy	06 48895206 questions.IT@support.sonyericsson.com
Lithuania	8 700 55030 questions.lt@support.sonyericsson.com
Malaysia	03-78809800 questions.MY@support.sonyericsson.com
Mexico	01 800 000 4722 questions.MX@support.sonyericsson.com
Netherlands	0900 899 8318 questions.NL@support.sonyericsson.com
New Zealand	0800-100150 questions.NZ@support.sonyericsson.com
Norway	815 00 840 questions.NO@support.sonyericsson.com
Pakistan	111 22 55 73 questions.pk@support.sonyericsson.com
Philippines	02-7891860 questions.PH@support.sonyericsson.com
Poland	0 (prefix) 22 6916200 questions.PL@support.sonyericsson.com
Portugal	808 204 466 questions.PT@support.sonyericsson.com
Romania	(+4021) 401 0401 questions.RO@support.sonyericsson.com
Russia	095 7870986 questions.RU@support.sonyericsson.com
Singapore	67440733 questions.SG@support.sonyericsson.com
Slovakia	02-5443 6443 questions.SK@support.sonyericsson.com

South Africa	0861 632222 questions.ZA@support.sonyericsson.com
Spain	902 180 576 questions.ES@support.sonyericsson.com
Sweden	013-24 45 00 questions.SE@support.sonyericsson.com
Switzerland	0848 824 040 questions.CH@support.sonyericsson.com
Taiwan	02-25625511 questions.TW@support.sonyericsson.com
Thailand	02-2483030 questions.TH@support.sonyericsson.com
Turkey	0212 47 37 777 questions.TR@support.sonyericsson.com
United Arab Emirates	43 919880 questions.AE@support.sonyericsson.com
United Kingdom	08705 23 7237 questions.GB@support.sonyericsson.com
United States	1-866-766-9374 questions.US@support.sonyericsson.com
Venezuela	0-800-100-2250 questions.VE@support.sonyericsson.com

Guidelines for Safe and Efficient Use

Please read this information before using your mobile phone.


These instructions are intended for your safety. Please follow these guidelines. If the product has been subject to any of the conditions listed below or you have any doubt as to its proper function make sure you have the product checked by a certified service partner before charging or using it. Failure to do so might entail a risk of product malfunction or even a potential hazard to your health.



Recommendations for safe use of product (mobile phone, battery, charger and other accessories)

- Always treat your product with care and keep it in a clean and dust-free place.
- **Warning!** May explode if disposed of in fire.
- Do not expose your product to liquid or moisture or humidity.

- Do not expose your product to extremely high or low temperatures. Do not expose the battery to temperatures above +60°C (+140°F).
- Do not expose your product to open flames or lit tobacco products.
- Do not drop, throw or try to bend your product.
- Do not paint your product.
- Do not attempt to disassemble or modify your product. Only Sony Ericsson authorized personnel should perform service.
- Do not use your product near medical equipment without requesting permission from your treating physician or authorized medical staff.
- Do not use your product when in, or around aircraft, or areas showing the sign "turn off two-way radio".
- Do not use your product in an area where a potentially explosive atmosphere exists.
- Do not place your product or install wireless equipment in the area above an air bag in your car.



CHILDREN

KEEP OUT OF CHILDRENS REACH. DO NOT ALLOW CHILDREN TO PLAY WITH YOUR MOBILE PHONE OR ITS ACCESSORIES. THEY COULD HURT THEMSELVES OR OTHERS, OR COULD ACCIDENTALLY DAMAGE THE MOBILE PHONE OR ACCESSORY. YOUR MOBILE PHONE OR ITS ACCESSORY MAY CONTAIN SMALL PARTS THAT COULD BECOME DETACHED AND CREATE A CHOKING HAZARD.

Power supply (Charger)

Connect the AC power adapter only to designated power sources as marked on the product. Make sure the cord is positioned so that it will not be subjected to damage or stress. To reduce risk of electric shock, unplug the unit from any power source before attempting to clean it. The AC power adapter must not be used outdoors or in damp areas. Never alter the cord or plug. If the plug does not fit into the outlet, have a proper outlet installed by a qualified electrician.

Use only Sony Ericsson branded original chargers intended for use with your mobile phone. Other chargers may not be designed to the same safety and performance standards.

Battery

We recommend that you fully charge the battery before you use your mobile phone for the first time. A new battery or one that has not been used for a long time could have reduced capacity the first few times it is used. The battery should only be charged in temperatures between +5°C (+41°F) and +45°C (+113°F).

Use only Sony Ericsson branded original batteries intended for use with your mobile phone. Using other batteries and chargers could be dangerous.

Talk and standby times depend on several different conditions such as signal strength, operating temperature, application usage patterns, features selected and voice or data transmissions when the mobile phone is being used.

Turn off your mobile phone before removing the battery. Do not put the battery into your mouth. Battery electrolytes may be toxic if swallowed.

Do not let the metal contacts on the battery touch another metal object.

Doing this could short-circuit and damage the battery. Use the battery for the intended purpose only.

Personal medical devices

Mobile phones may affect the operation of pacemakers and other implanted equipment. Please avoid placing the mobile phone over the pacemaker, e.g. in your breast pocket. When using the mobile phone, use it at the ear on the opposite side of the body to the pacemaker. If a minimum distance of 15 cm (6 inches) is kept between the mobile phone and the pacemaker, the risk of interference is limited. If you have any reason to suspect that interference is taking place, immediately turn off your mobile phone.

Contact your cardiologist for more information.

For other medical devices, please consult your physician and the manufacturer of the device.

Driving

Please check if local laws and regulations restrict the use of mobile phones while driving or require drivers to use handsfree solutions. We recommend that you use only Sony Ericsson handsfree solutions intended for use with your product.

Please note that because of possible interference to electronic equipment, some vehicle manufacturers forbid the use of mobile phones in their vehicles unless a handsfree kit with an external antenna has been installed.

Always pay full attention to driving and pull off the road and park before making or answering a call if driving conditions so require.

Emergency calls

Mobile phones operate using radio signals, which cannot guarantee connection in all conditions. You should therefore never rely solely upon any mobile phone for essential communications (e.g. medical emergencies). Emergency calls may not be possible in all areas, on all cellular networks, or when certain network services and/or mobile phone features are in use. Check with your local service provider.

Antenna

This phone contains a built-in antenna. Use of antenna devices not marketed by Sony Ericsson specifically for this model could damage your mobile phone, reduce performance, and produce SAR levels above the established limits (see below).

Efficient use

Hold your mobile phone as you would any other phone. Do not cover the top of the phone when it is in use, as this affects call quality and may cause the phone to operate at a higher power level than needed, thus shortening talk and standby times.

Radio frequency (RF) exposure and Specific Absorption Rate (SAR)

Your mobile phone is a low-power radio transmitter and receiver. When it is turned on, it emits low levels of radio frequency energy (also known as radio waves or radio frequency fields).

Governments around the world have adopted comprehensive international safety guidelines, developed by scientific organizations, e.g. ICNIRP (International Commission on Non-Ionizing Radiation Protection) and IEEE (The Institute of Electrical and Electronics Engineers Inc.), through periodic and thorough evaluation of scientific studies. These guidelines establish permitted levels of radio wave exposure for the general population. The levels include a safety margin designed to assure the safety of all persons, regardless of age and health, and to account for any variations in measurements.

Specific Absorption Rate (SAR) is the unit of measurement for the amount of radio frequency energy absorbed by the body when using a mobile phone. The SAR value is determined at the highest certified power level in laboratory conditions, but the actual SAR level of the mobile phone while it is operating can be well below this value. This is because the mobile phone is designed to use the minimum power required to reach the network.

Variations in SAR below the radio frequency exposure guidelines do not mean that there are variations in safety. While there may be differences in SAR levels among mobile phones, all Sony Ericsson mobile phone models are designed to meet radio frequency exposure guidelines.

For phones sold in the US, before a phone model is available for sale to the public, it must be tested and certified by the Federal Communications Commission (FCC) that it does not exceed the limit established by the government-adopted requirement for safe exposure. The tests are performed in positions and locations (that is, at the ear and worn on the body) as required by the FCC for each model. For body-worn operation, this phone has been tested and meets FCC RF exposure guidelines when the handset is positioned a minimum of 15 mm from the body without any metal parts in the vicinity of the phone or when used with the original Sony Ericsson accessory intended for this phone and worn on the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines.

A separate leaflet with SAR information about this mobile phone model is included with the material accompanying this mobile phone. This information can also be found, together with more information on radio frequency exposure and SAR, on: www.sonyericsson.com/health.

Accessible Solutions/Special Needs

For phones sold in the US, you can use your TTY terminal with your Sony Ericsson mobile phone (with the necessary accessory). For information on Accessible Solutions for individuals with special needs call the Sony Ericsson Special Needs Center on 877 878 1996 (TTY) or 877 207 2056 (voice), or visit the Sony Ericsson Special Needs Center at www.sonyericsson-snc.com.

Disposal of old electrical and electronic equipment

This symbol indicates that all electrical and electronic equipment included shall not be treated as household waste. Instead it shall be left at the appropriate collection point for recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.



Disposing of the battery

Please check local regulations for disposal of batteries or call your local Sony Ericsson Call Center for information. The battery should never be placed in municipal waste. Use a battery disposal facility if available.



Protection of personal information

To safeguard your privacy and prevent information being accessible to a third party, you should erase all personal data before selling or disposing of the product. To delete personal data, perform a master reset. **DELETION OF MATERIAL FROM THE PHONE MEMORY DOES NOT ENSURE THAT SAID INFORMATION CANNOT BE RECOVERED BY A SUBSEQUENT USER.** SONY ERICSSON DOES NOT WARRANT AGAINST A SUBSEQUENT USER OF THE DEVICE ACCESSING YOUR INFORMATION AND DOES NOT ASSUME ANY RESPONSIBILITY FOR SUBSEQUENT DISCLOSURE OF SAID INFORMATION EVEN IF A MASTER RESET HAS BEEN PERFORMED. If you are concerned about such potential disclosure retain your device or secure its permanent destruction.

Accessories

Sony Ericsson recommends use of Sony Ericsson original accessories for safe and efficient use of its products. Use of third-party accessories may decrease performance or pose a risk to your health or safety.

LOUDNESS WARNING:

Please adjust the audio volume cautiously when using third-party audio accessories to avoid volume levels that may be harmful to your hearing. Sony Ericsson does not test use of third-party audio accessories with this mobile phone. Sony Ericsson recommends using only Sony Ericsson original audio accessories.

End User Licence Agreement

This wireless device, including without limitation any media delivered with the device, ("Device") contains software owned by Sony Ericsson Mobile Communications AB and its affiliated companies ("Sony Ericsson") and its third party suppliers and licensors ("Software").

As user of this Device, Sony Ericsson grants you a non-exclusive, non-transferable, non-assignable license to use the Software solely in conjunction with the Device on which it is installed and/or delivered with. Nothing herein shall be construed as a sale of the Software to a user of this Device.

You shall not reproduce, modify, distribute, reverse engineer, decompile, otherwise alter or use any other means to discover the source code of the Software or any component of the Software. For avoidance of doubt, you are at all times entitled to transfer all rights and obligations to the Software to a third party, solely together with the Device with which you received the Software, provided always that such third party agrees in writing to be bound by these rules.

You are granted this license for a term of the useful life of this Device. You can terminate this license by transferring all your rights to the Device on which you have received the Software to a third party in writing. If you fail to comply with any of the terms and conditions set out in this license, it will terminate with immediate effect.

Sony Ericsson and its third party suppliers and licensors are the sole and exclusive owner of and retain all rights, title and interest in and to the Software. Sony Ericsson, and, to the extent that the Software contains material or code of a third party, such third party, shall be entitled third party beneficiaries of these terms.

The validity, construction and performance of this license shall be governed by the laws of Sweden. The foregoing shall apply to the full extent permitted by, when applicable, statutory consumer rights.

Limited Warranty

Sony Ericsson Mobile Communications AB, Nya Vattentornet, SE-221 88 Lund, Sweden, (Sony Ericsson) or its local affiliated company, provides this Limited Warranty for your mobile phone and original accessory delivered with your mobile phone (hereinafter referred to as "Product").

Should your Product need warranty service, please return it to the dealer from whom it was purchased, or contact your local Sony Ericsson Call Center (national rates may apply) or visit www.sonyericsson.com to get further information.

OUR WARRANTY

Subject to the conditions of this Limited Warranty, Sony Ericsson warrants this Product to be free from defects in design, material and workmanship at the time of its original purchase by a consumer. This Limited Warranty will last for a period of one (1) year as from the original date of purchase of the Product.

WHAT WE WILL DO

If, during the warranty period, this Product fails to operate under normal use and service, due to defects in design, materials or workmanship, Sony Ericsson authorized distributors or service partners, in the country* where you purchased the Product, will, at their option, either repair or replace the Product in accordance with the terms and conditions stipulated herein. Sony Ericsson and its service partners reserve the right to charge a handling fee if a returned Product is found not to be under warranty according to the conditions below.

Please note that some of your personal settings, downloads and other information may be lost when your Sony Ericsson Product is repaired or replaced. At present Sony Ericsson may be prevented by applicable law, other regulation or technical restrictions from making a backup copy of certain downloads. Sony Ericsson does not take any responsibility for any lost information of any kind and will not reimburse you for any such loss. You should always make backup copies of all the information stored on your Sony Ericsson Product such as downloads, calendar and contacts before handing in your Sony Ericsson Product for repair or replacement.

CONDITIONS

- 1 This Limited Warranty is valid only if the original proof of purchase for this Product issued by a Sony Ericsson authorized dealer specifying the date of purchase and serial number**, is presented with the Product to be repaired or replaced. Sony Ericsson reserves the right to refuse warranty service if this information has been removed or changed after the original purchase of the Product from the dealer.
- 2 If Sony Ericsson repairs or replaces the Product, the repair for the defect concerned, or the replaced Product shall be warranted for the remaining time of the original warranty period or for ninety (90) days from the date of repair, whichever is longer. Repair or replacement may involve the use of functionally equivalent reconditioned units. Replaced parts or components will become the property of Sony Ericsson.
- 3 This warranty does not cover any failure of the Product due to normal tear and wear, or due to misuse, including but not limited to use in other than the normal and customary manner, in accordance with the Sony Ericsson instructions for use and maintenance of the Product. Nor does this warranty cover any failure of the Product due to accident, software or hardware modification or adjustment, acts of God or damage resulting from liquid.

A rechargeable battery can be charged and discharged more than a hundred times. However, it will eventually wear out - this is not a defect and corresponds to normal wear and tear. When the talk-time or standby time is noticeably shorter, it is time to replace your battery. Sony Ericsson recommends that you use only batteries and chargers approved by Sony Ericsson.

Minor variations in display brightness and colour may occur between the phones. There may be tiny bright or dark dots on the display.

These are called defective pixels and occur when individual dots have malfunctioned and can not be adjusted. Two defective pixels are deemed acceptable.

Minor variations in camera image appearance may occur between phones. This is nothing uncommon and is not regarded as a defective camera module.

- 4 Since the cellular system on which the Product is to operate is provided by a carrier independent from Sony Ericsson, Sony Ericsson will not be responsible for the operation, availability, coverage, services or range of that system.
- 5 This warranty does not cover Product failures caused by installations, modifications, or repair or opening of the Product performed by a non-Sony Ericsson authorised person.
- 6 The warranty does not cover Product failures which have been caused by use of accessories or other peripheral devices which are not Sony Ericsson branded original accessories intended for use with the Product.
- 7 Tampering with any of the seals on the Product will void the warranty.
- 8 **THERE ARE NO EXPRESS WARRANTIES, WHETHER WRITTEN OR ORAL, OTHER THAN THIS PRINTED LIMITED WARRANTY. ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. IN NO EVENT SHALL SONY ERICSSON OR ITS LICENSORS BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE WHATSOEVER, INCLUDING BUT NOT LIMITED TO LOST PROFITS OR COMMERCIAL LOSS; TO THE FULL EXTENT THOSE DAMAGES CAN BE DISCLAIMED BY LAW.**

Some countries/states do not allow the exclusion or limitation of incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

The warranty provided does not affect the consumer's statutory rights under applicable legislation in force, nor the consumer's rights against the dealer arising from their sales / purchase contract.

***GEOGRAPHICAL SCOPE OF THE WARRANTY**

If you have purchased your Product in a country member of the European Economic Area (EEA) or in Switzerland or the Republic of Turkey, and such Product was intended for sale in the EEA or in Switzerland or in Turkey, you can have your Product serviced in any EEA country or in Switzerland or in Turkey, under the warranty conditions prevailing in the country in which you require servicing, provided that an identical Product is sold in such country by an authorised Sony Ericsson distributor. To find out if your Product is sold in the country you are in, please call the local Sony Ericsson Call Center. Please observe that certain services may not be possible elsewhere than in the country of original purchase, for example due to the fact that your Product may have an interior or exterior which is different from equivalent models sold in other countries. Please note in addition that it may sometimes not be possible to repair SIM-locked Products.

** In some countries/regions additional information (such as a valid warranty card) may be requested.

FCC Statement

This device complies with Part 15 of the FCC rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.



Index

A

alarms 19
answer a call 12
answering service 14

B

battery 4, 30

C

camera 16

D

display light 8
diverting calls 13

G

GSM frequencies 2

I

icons 10
important information 25

K

keypad lock 9, 21

L

language 10

M

menu 8
missed calls 12

P

phone lock 24
phone overview 7
phonebook See contacts 14
picture messages 16
PIN code 6, 21
PUK 24

R

reject a call 12
reset 20
restart 22
ring volume 19
ringtone 19

S

safety guidelines 28
shortcuts 9
SIM 4, 24
standby 6

T

T9™ Text Input 11
text messages 15
troubleshooting 22
turn on or off 6

W

wallpaper 20
warranty 34
writing methods 11

