



**EMC Technologies Pty Ltd**

A.C.N. 057 105 549

**16/6 Gladstone Rd  
Castle Hill, NSW 2154**

**Ph: + 612 9899 4599**

**Fax: + 612 9899 4019**

email: [syd@emctech.com.au](mailto:syd@emctech.com.au)

HTTP: [www.emctech.com.au](http://www.emctech.com.au)

**APPENDIX K  
OF  
TEST REPORT T40452F**

**USER MANUAL**

**FCC ID:** Q47-MCR200

**Manufacturer:** ERG Transit Systems

**Test Sample:** Contactless Smart Card Reader

**Model:** MCR200

**Serial No:** 0318111546

**Date:** 29<sup>th</sup> July 2004



**ERG**

**GROUP**

---

## **Device Product Group**

---

### **MCR200 User Manual**

**Document No:** DPG-00144

**Category:** 431

**Revision:** 7

<b>ERG Approvals</b>	<b>Author</b>	<b>Hardware Manager</b>	
Name:	Dan Zorde	Gino Bertino	
Signature:			
Date:			

This material is confidential to ERG and may not be disclosed in whole or in part to any third party nor used in any manner whatsoever other than for the purposes expressly consented to by ERG in writing. This material is also copyright and may not be reproduced, stored in a retrieval system or transmitted in any form or by any means in whole or in part without the express written consent of ERG.

## Document History

Revision	Revision Date	Description	Author
1.0	10 March 03	First release	Gino Bertino
2.0	04 April 03	Revised FCC compliance statement	Gino Bertino
3.0	05 May 03	Includes reference to correct FCC ID code	Gino Bertino
4.0	23 Jun 03	Removed blank second page	Gino Bertino
5.0	2 July 03	Change to Section 4.4 ferrite statement	Dan Zorde
6.0	7 May 04	Updated for Rev2 card reader with shield	Dan Zorde
7.0	5 July 04	Shield update	Dan Zorde

---

## Table of Contents

<b>1</b>	<b>INTRODUCTION .....</b>	<b>5</b>
1.1	PURPOSE.....	5
1.2	SCOPE.....	5
1.3	TERMINOLOGY .....	5
<b>2</b>	<b>OVERVIEW OF THE MCR .....</b>	<b>6</b>
<b>3</b>	<b>MODULE ARCHITECTURE.....</b>	<b>8</b>
3.1	ELECTRICAL SPECIFICATION.....	8
3.2	HOST SERIAL COMMUNICATION INTERFACE .....	8
3.3	POWER SUPPLY .....	9
3.4	RF CONTROLLER.....	9
3.4.1	<i>Transmitter</i> .....	9
3.4.2	<i>Receiver</i> .....	9
3.4.3	<i>Card Interface</i> .....	9
<b>4</b>	<b>HOST INTERFACE CONNECTIONS.....</b>	<b>10</b>
4.1	SUPPORTED ELECTRICAL INTERFACES .....	10
4.2	HOST INTERFACE CONNECTOR .....	10
4.3	INTERFACE CONNECTIONS.....	10
4.4	INTERCONNECTING CABLE.....	11
<b>5</b>	<b>MECHANICAL SPECIFICATION.....</b>	<b>12</b>
5.1	PHYSICAL DIMENSIONS.....	12
5.1.1	<i>Size</i> .....	12
5.1.2	<i>Mounting Holes</i> .....	13
5.2	INDIVIDUAL COMPONENT DIMENSIONS .....	14
5.2.1	<i>Control Board Dimensions</i> .....	14
5.2.2	<i>Antenna Dimensions</i> .....	15
<b>6</b>	<b>MOUNTING GUIDELINES .....</b>	<b>16</b>
<b>7</b>	<b>ANTENNA TUNING.....</b>	<b>17</b>

## List of Tables

TABLE 1: TERMINOLOGY .....	5
TABLE 2: SERIAL INTERFACE CONNECTIONS.....	10
TABLE 3: PHYSICAL DIMENSIONS .....	12

## List of Figures

FIGURE 1: MCR200 OEM MODULE .....	6
FIGURE 2: MCR200 OEM MODULE - OPERATION.....	7
FIGURE 3: MODULE ARCHITECTURE .....	8
FIGURE 4: INTERCONNECTING HOST CABLE .....	11
FIGURE 5: TYPICAL STACKING ARRANGEMENT .....	12
FIGURE 6: TYPICAL PHYSICAL ENVELOPE .....	13
FIGURE 7: CONTROL BOARD DIMENSIONS .....	14
FIGURE 8: ANTENNA DIMENSIONS .....	15
FIGURE 9: CLEARANCE BETWEEN ANTENNA AND METALLIC OBJECTS.....	16
FIGURE 10: LOCATION OF TUNING CAPACITOR CV1 .....	17

## FCC Compliance Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The MCR200 was submitted and a grant of authorisation received from the FCC as a modular device under the intentional radiator requirements of part 15, Subpart C.

The party that incorporates the MCR200 into their product is responsible for verification of the emissions produced by the final product and must adhere to the limits specified in the code of Federal Regulations 47, Part 15, Subpart B.

Furthermore, a label must be applied on the exterior of the final product, referring to this enclosed module, which shall state, "Contains FCC ID: Q47-MCR200" or "Contains Transmitter Module FCC ID: Q47-MCR200".

**Notice:** When an AC to DC power source is used to supply power to the integrated equipment, the final equipment will also have to comply with the AC line conducted emissions according to FCC Part 15, Subpart B.

**Warning:** Any changes or modifications not expressly approved by ERG Transit Systems could void the user's authority to operate this equipment

# 1 Introduction

## 1.1 Purpose

The purpose of this document is to provide summary technical details of the electrical interface and physical characteristic of the Multiprotocol Card Reader (MCR200). It is intended for use by third party developers wanting to integrate the MCR200 OEM Module into new or existing products.

## 1.2 Scope

This manual is intended for use by third party developers and integrators familiar with similar type of equipment. This manual contains technical information sufficient to give technical personnel an operational understanding of the MCR200.

## 1.3 Terminology

The following table contains a list of Equipment Terminology and their meanings.


**Table 1: Terminology**

Term	Definition
A	Amp(s), Ampere(s)
ASK	Amplitude Shift Keying
bps	Bits per second
BPSK	Binary Phased Shift Keying
CMOS	Complementary Metal-Oxide Semiconductor
CPU	Central Processing Unit (microprocessor)
CSC	Contact-less Smart Card
Host	A processing unit communicating directly with and housing the MCR200.
EIA	Electronic Industry Association
EMC	Electromagnetic Compatibility
GND	Ground – negative supply
Hz	Hertz, cycles per second
IEC	International Electrotechnical Commission
ISO	International Standards Organisation
MCR	Multiprotocol Card Reader
mm	millimetre(s)
NRZ-L	Non-return to zero - level
OOK	On-Off keying
PCB	Printed Circuit Board
s	second(s)
TIA	Telecommunications Industry Association

**2**

## Overview of the MCR

The MCR200 OEM Module is an easy-to-use, economical means of introducing contact-less smart card capability into a host. Figure 1 contains a picture of the MCR200 OEM Module. Section 3 provides an overview of the module architecture. Section 4 provides a description of the interface connector and pins. Section 5 provides dimensional details, section 6 describes how the MCR200 is to be mounted inside the host and Section 7 describes the final tuning procedure.




**Figure 1: MCR200 OEM Module**

The MCR200 OEM module is a compact contact-less reader, which enables developers to rapidly add contact-less functionality to new or existing products.

Each MCR200 consists of a Control Board and Antenna Board; this set is tuned and tested at the factory prior to shipment. Each set is shipped with a 100 mm interconnecting cable as shown in Figure 1.

The MCR200 serves as the data communications link between customer smart cards and the host in which the MCR200 is installed.

For MCR-to-Card communications, the Control Board receives data signals from the host. It then transmits the data signals via RF to a smart card held within reading distance of the MCR200's Antenna Board. For Card-to-MCR communications, RF data signals from the smart card are received by the Control Board via the Antenna Board where they are sent to the host via connector 1 located on the Control Board. Figure 2 contains a block diagram that illustrates the MCR200 mode of operation.



**Figure 2: MCR200 OEM Module - Operation**

## 3 Module architecture

The Control Board contains a microprocessor, non-volatile memory, and radio frequency transmitting and receiving circuitry. This board communicates with smart cards via a RF link provided by the Antenna Board, and to the terminal via a TIA/EIA-485 or TIA/EIA-232 serial protocol.

The Antenna Board consists of a printed circuit board with copper traces forming the transmit and receive antenna. The board is attached to a ferrite plate and a metal back plate that serves as a ground plane.

The module architecture is illustrated in Figure 3.




Figure 3: Module Architecture

### 3.1 Electrical specification

### 3.2 Host serial communication interface

Item	Description
MCR to Host communication interface	Serial TIA/EIA-232F and TIA/EIA-422 full duplex.
MCR to host baud rate	Serial 9600bps, 19.2 Kbps, 38.4 Kbps, 57.6 Kbps, and 115.2 Kbps.

### 3.3 Power Supply

The MCR200 OEM module derives power directly from the host. After supply power is applied to the MCR200, the MCR200 will be operational in less than 1.2 seconds.

Item	Description
Supply voltage	12Vdc +10%/-5%, with ripple of less than 50mV peak-peak.
Supply current	Maximum 300 mA, typical 150 mA
Input power requirements	Maximum 3.60 Watts

### 3.4 RF controller

The standards supported by the RF controller are ISO/IEC 14443 Type A, ISO/IEC 14443 Type B and Mifare Standard.

#### 3.4.1 Transmitter

The MCR200 transmitter complies with the following specifications:

Item	Description
Carrier Frequency	13.56 MHz $\pm$ 7 kHz (ISO/IEC 14443-2:2001, 6.1)
Modulation Rise and Fall Time	< 2.0 $\mu$ sec (ISO/IEC 14443-2:2001, 8.1.2 and 9.1.2)
ASK Modulation	100% Modified Miller (ISO/IEC 14443-2:2001, 7 and 8) 8%-14% NRZ (ISO/IEC 14443-2:2001, 7 and 9)

#### 3.4.2 Receiver

The MCR200 receiver complies with the following specifications:

Item	Description
Carrier Frequency	13.56 MHz
Subcarrier Frequency	847.5 kHz (ISO/IEC 14443-2:2001, 7, 8 and 9)
Subcarrier Data	OOK Manchester (ISO/IEC 14443-3:2001 7 and 8) BPSK NRZ-L (ISO/IEC 14443-2:2001, 7 and 9)

#### 3.4.3 Card Interface

The MCR200 module supports contact-less smart cards conforming to the following signal interface protocols:

- ISO/IEC 14443 Type A.
- ISO/IEC 14443 Type B.

## 4 Host Interface Connections

### 4.1 Supported Electrical Interfaces

The serial interface between the Host and MCR supports both:

- TIA/EIA-485, half duplex
- TIA/EIA-232-F

The MCR200 is connected to the host via a 10-pin connector located on the Control Board. The interconnection between the host and the MCR200 may be achieved using an interconnecting cable as shown in Figure 4.

The default terminal to CAD communication speed is 115,200 bps. Other communication speeds are available.

### 4.2 Host Interface Connector

The MCR200 interface connector mates with a straight connector.

**Straight connector:** *Molex #22-01-2105 or equivalent*


### 4.3 Interface Connections

Pin	Designation	Signal Level	Function
1	Reset	CMOS logic	Can be used to reset the MCR.
2	GND	Ground	Ground (Power Supply negative)
3	+12V	+12Vdc	Power Supply positive
4	Rx-	TIA/EIA-485 -ve	Serial data from Host to MCR
5	Rx+	TIA/EIA-485 +ve	Serial data from Host to MCR
6	Tx-	TIA/EIA-485 -ve	Serial data from MCR to Host
7	Tx+	TIA/EIA-485 +ve	Serial data from MCR to Host
8	TxD	TIA/EIA-232	Serial data from MCR to Host
9	GND	Ground	Ground (Power supply negative)
10	RxD	TIA/EIA-232	Serial data from Host to MCR

**Table 2: Serial Interface Connections**

If the Host provides a hardware reset, it will be a logic-level, active-low signal with a minimum pulse width of 10 microseconds.

## 4.4 Interconnecting cable



**Figure 4: Interconnecting Host Cable**

Ferrite bead, Steward #28B1122-100, must be fitted as shown in Figure 4, on the DC power cable connecting to the MCR200.

## 5 Mechanical specification

### 5.1 Physical Dimensions

The two components that form the MCR200 (Control and Antenna boards) are organised so that they can be physically separated by a distance of up to 100 mm, and connected via a connecting cable. It is possible to stack the two components into a thickness of 24.5 mm.




Figure 5: Typical stacking arrangement

#### 5.1.1 Size

The guaranteed Reader volumetric envelope is shown in Figure 6. It is acceptable to mount the MCR in a larger volumetric envelope if space is available.

The Control Board and Antenna have the following dimensions:

	Length (mm)	Width (mm)	Height (mm)	Tolerance (mm)
Control Board	104	67	15.5	± 0.5
Antenna Board	104	67	5.5	± 0.5

Table 3: Physical Dimensions




Figure 6: Typical physical envelope

### 5.1.2 Mounting Holes

All mounting holes are M3.2. The mounting holes are aligned and may be used with screws and plastic spacers to secure the MCR200 inside the product. The 100 mm cable allows the Control Board and Antenna Board to be separated to accommodate different mounting scenarios. For instance, the boards could be stacked, mounted side by side or mounted on an angle.

Spacers between the shield and control pcb, ensure the shield remains fixed to the control pcb, and eliminates shield deformation during assembly into the final product.

## 5.2 Individual Component Dimensions

### 5.2.1 Control Board Dimensions

The Control Board dimensions, and the placement of the connectors, conform to those shown in Figure 7.




Figure 7: Control Board Dimensions

## 5.2.2 Antenna Dimensions

The Antenna conforms to the dimensions shown in Figure 8. The Antenna thickness is 5.5 mm.




Figure 8: Antenna Dimensions

## 6 Mounting guidelines

These guidelines are intended to assist product designers maximise the operation of the MCR200 in products:

- Ensure that any metalwork and/or EMC coatings are at least *15 mm* away from the sides of the antenna board in a horizontal plane and more than *5 mm* below the vertical plane. Designers should use the maximum possible clearance.
- The top of the antenna PCB (non-metallic side) must face towards the card reading surface of the terminal and be *less than 5 mm* from the top surface. Any increase in this distance will impact the Reader performance, and may result in the product being unable to meet the project's specifications, particularly the operating distance.
- The surface of the target area, which is directly above the Antenna Board, must be a non-metallic surface such as plastic and be free of any metallic particles.
- It should be possible to tune the reader using the tuning capacitor shown in Figure 10 while leaving the antenna PCB fixed to the product. The product should ideally be designed to permit re-tuning once the MCR200 is fitted.
- Removal of the shield to mount the MCR200 in ways not otherwise possible will breach the FCC regulations and void all warranty.
- Ensure that the cable interconnecting the Antenna Board to the Control Board is located away from metal surfaces and that the cable is fixed to avoid movement. Any movement may degrade the reader performance, as the cable is an active part of the antenna system.
- Ideally, both the control and antenna PCBs should be kept together as a unit.




Figure 9: Clearance between antenna and metallic objects.

## 7 Antenna Tuning

The MCR200 is tuned at the factory for maximum operating range. It may be necessary to retune the MCR200 when it is mounted into a host device to compensate for the effects of the mounting environment (such as metallic parts or metallic paint near the antenna) and to ensure optimum performance. For this function, use an active smart card that is initialised for use with the particular host application.

- 1) With the MCR200 mounted in its operational environment place the test smart card onto the card reading surface of the terminal. Use a non-metallic spacer with the depth of the desired operating range. For example, if the desired operating range is 50 mm, then place a 50 mm spacer. Ensure that the host and MCR200 are powered.
- 2) Verify operational range by running the host internal diagnostic routines. Via the tuning hole in the shield, adjust the tuning by rotating CV1 using a plastic tuning tool to maximise the operating distance.




Figure 10: Location of tuning capacitor CV1