



Sensor installation


1 Unscrew the valve cap




2 Insert the dustproof cover into the valve stem




3 Screw in the nut




4 Screw on the sensor



5 Tighten up the nut to the sensor by using the spanner




6 Check air leakage by spraying soapy water




Sensor battery replacement

1 Unscrew the nut



2 Unscrew the sensor




3 Take out the washer




4 Unscrew the sensor cover by using the sensor tool



5 Replace new battery




6 Repeat steps in "Sensor installation"



Functional test after installation

1 Display will show real-time tire data automatically when the speed is over 25km/h (15.5MPH)

> 25 km/h



Specifications

Sensor:

Operating frequency: 433.92±0.015MHz

Operating voltage: 2.0~3.3V

Operating temp: -20°C~+60°C/
-4°F~+140°F

Pressure range: 0~6Bar/0~86PSI

FCC warning statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement
The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.