

Power Management

---

User Guide

© Copyright 2007 Hewlett-Packard  
Development Company, L.P.

Microsoft and Windows are U.S. registered  
trademarks of Microsoft Corporation.

The information contained herein is subject  
to change without notice. The only  
warranties for HP products and services are  
set forth in the express warranty statements  
accompanying such products and services.  
Nothing herein should be construed as  
constituting an additional warranty. HP shall  
not be liable for technical or editorial errors  
or omissions contained herein.

First Edition: January 2007

Document Part Number: 431180-001

Antenna House XSL Formatter


# Table of contents

<b>1 Setting power options</b>	
Using power-saving states .....	1
Initiating or exiting Sleep .....	1
Initiating or exiting Hibernation .....	2
Using power plans .....	3
Viewing the current power plan .....	3
Selecting a different power plan .....	3
Customizing power plans .....	3
Setting a password prompt on wakeup .....	4
<b>2 Using battery power</b>	
Using the battery meter .....	6
Displaying the remaining battery charge .....	6
Hiding or displaying the battery meter icon .....	6
Inserting or removing the battery .....	7
Charging a battery .....	8
Managing low-battery conditions .....	9
Identifying low-battery conditions .....	9
Resolving a low-battery condition .....	10
Resolving a low-battery condition when external power is available .....	10
Resolving a low-battery condition when a charged battery is available .....	10
Resolving a low-battery condition when no power source is available .....	10
Resolving a low-battery condition when the computer cannot exit Hibernation .....	10
Calibrating a battery .....	11
Step 1: Fully charge the battery .....	11
Step 2: Disable Hibernation and Sleep .....	11
Step 3: Discharge the battery .....	12
Step 4: Fully recharge the battery .....	13
Step 5: Reenable Hibernation and Sleep .....	13
Conserving battery power .....	14
Storing a battery .....	15
Disposing of a used battery .....	16
<b>3 Using external AC power</b>	
Connecting the AC adapter .....	18
<b>4 Shutting down the computer</b>	

# EVALUATION XSL FORMATTER

# 1 Setting power options

## Using power-saving states

 **CAUTION** To prevent possible audio and video degradation, or loss of audio or video playback functionality, or loss of information, do not initiate Sleep or Hibernation while reading from or writing to a disc or an external media card.

 **NOTE** You cannot initiate any type of networking communications or perform any computer functions while the computer is in the Sleep state or in Hibernation.


The computer has two power-saving states enabled at the factory: Sleep and Hibernation.

When you initiate Sleep, the power lights blink and the screen clears. Your work is saved to memory, letting you exit Sleep faster than exiting Hibernation. If the computer is in the Sleep state for an extended period or the battery reaches a critical low-battery state while in the Sleep state, your work is saved to the hard drive.

When you initiate Hibernation, your work is saved to a hibernation file on the hard drive and the computer turns off.

### Initiating or exiting Sleep


The system is set at the factory to initiate Sleep after 10 minutes of inactivity when running on battery power and 25 minutes of inactivity when running on external power.

 **NOTE** Power settings and timeouts can be changed using Power Options in Windows Control Panel.

With the computer on, you can initiate Sleep in any of the following ways:

- Press **fn+f5**.
- Close the display.
- Click **Start**, click the icon next to the Lock button, and then click **Sleep**.

To exit Sleep, press the power button. When the computer exits Sleep, the power lights turn on and your work returns to the screen where you stopped working.

 **NOTE** If you have set a password to be required upon wakeup, you must enter your Windows password before your work will return to the screen.

## Initiating or exiting Hibernation

The system is set at the factory to initiate Hibernation after minutes of inactivity or if the battery reaches a critical low-battery state.



---

**NOTE** Power settings and timeouts can be changed using Power Options in Windows Control Panel.

---

To initiate Hibernation:

- Press the power button.

– or –

- a. Click **Start**, and then click the arrow next to the Lock button.
- b. Click **Hibernate**.

To exit Hibernation, press the power button. The power lights turn on and your work returns to the screen where you stopped working.



---

**NOTE** If you have set a password to be required upon wakeup, you must enter your Windows password before your work will return to the screen.

---

## Using power plans

A power plan is a collection of system settings that manages how the computer uses power. Power plans can help you conserve power and maximize performance.

Windows Vista provides 3 power plans:

- **Balanced**—Balances energy consumption and system performance.
- **Power saver**—Conserves power by reducing system performance.
- **High performance**—Provides the highest level of system performance.

You can change the settings of these power plans or create your own power plan.

### Viewing the current power plan

- Move the pointer over the battery meter icon in the notification area, at the far right of the taskbar.

– or –

Select **Start > Control Panel > System and Maintenance > Power Options**.

### Selecting a different power plan

- Click the battery meter icon in the notification area, at the far right of the taskbar, and then select a power plan from the list.

– or –

Select **Start > Control Panel > System and Maintenance > Power Options**, and then select a power plan from the list.

### Customizing power plans

1. Click the battery meter icon in the notification area and then click **More power options**.

– or –

Click **Start > Control Panel > System and Maintenance > Power Options**.

2. Under the computer's selected power plan, click **Change plan settings**.
3. Change the **Turn off display** and **Put computer to sleep** timeout settings, as needed.
4. To change additional settings, click **Change advanced power settings** and make your changes.

## Setting a password prompt on wakeup

To set the computer to prompt for a password when the computer exits Sleep:

1. Select **Start > Control Panel > System and Maintenance > Power Options**.
2. Click **Require a password**.
3. Click **Save changes**.



## 2 Using battery power

When a charged battery is in the computer and the computer is not plugged into external power, the computer runs on battery power. When the computer is plugged into external AC power, the computer runs on AC power.

If the computer contains a charged battery and is running on external AC power supplied through the AC adapter, the computer switches to battery power if the AC adapter is disconnected from the computer.



**NOTE** The display brightness is decreased to save battery life when you disconnect AC power. To increase display brightness, use the **fn+f8** hotkey or reconnect the AC adapter.

---

You can keep a battery in the computer or in storage, depending on how you work. Keeping the battery in the computer whenever the computer is plugged into AC power charges the battery and also protects your work in case of a power outage. However, a battery in the computer slowly discharges when the computer is off and unplugged from external power.



**WARNING!** To avoid potential safety issues, use only the battery provided with the computer, a replacement battery provided by HP, or a compatible battery purchased as an accessory from HP.

---

## Using the battery meter

The battery meter allows you to quickly access power settings and select a different power plan. To display the percentage of remaining battery charge and the current power plan, move the pointer over the battery meter icon, located in the notification area at the far right of the taskbar. To access Power Options or the Mobility Center, or to change the power plan, click the battery meter icon.

The battery meter icon changes shape to indicate whether the computer is running on battery or external power. The icon also displays a message if the battery has reached a critically low level.

### Displaying the remaining battery charge

- Move the pointer over the battery meter icon in the notification area, at the far right of the taskbar.

You can view the estimated number of minutes of charge remaining in the Mobility Center. To open Mobility Center.

The time indicates the approximate running time remaining *if the computer continues to consume power at the current level*. For example, the time remaining decreases when playing a DVD and increases when a DVD stops playing.

TBD - I do not have a unit with Mobility Center working, so this will be updated at a later date.

### Hiding or displaying the battery meter icon


1. Right-click the taskbar, and then click **Properties**.
2. Click the **Notification Area** tab.
3. Under System icon, clear the **Power** check box to hide the battery meter icon, or select the **Power** check box to display the battery meter icon.
4. Click **OK**.

## Inserting or removing the battery

**CAUTION** To prevent loss of information when removing a battery that is the sole power source, initiate Hibernation or turn off the computer before removing the battery.


To insert the battery:

1. Turn the computer upside down on a flat surface.
2. Insert the battery into the battery bay (1) and rotate it downward until it is seated (2).  
The battery release latches (3) automatically lock the battery into place.



To remove the battery:

1. Turn the computer upside down on a flat surface.
2. Slide the battery release latches (1) to release the battery.
3. Pivot the battery (2) away from the computer and remove it from the computer (3).



## Charging a battery



**WARNING!** Do not charge the computer battery while you are onboard aircraft.

The battery charges whenever the computer is plugged into external power through an AC adapter, an optional expansion product, or an optional power adapter.

The battery charges whether the computer is off or in use, but it charges faster while the computer is off.

Charging may take longer if a battery is new, has been unused for 2 weeks or more, or is much warmer or cooler than room temperature.

To prolong battery life and optimize the accuracy of battery charge displays, follow these recommendations:

- If you are charging a new battery, charge it fully before turning on the computer.
- Charge the battery until the battery light turns off.



**NOTE** If the computer is on while the battery is charging, the battery meter in the notification area may show 100 percent charge before the battery is fully charged.

- Allow the battery to discharge below 5 percent of a full charge through normal use before charging it.
- If the battery has been unused for one month or more, calibrate the battery instead of simply charging it.

The battery light displays charge status:

- On: The battery is charging.
- Blinking: The battery has reached a low-battery condition and is not charging.
- Off: The battery is fully charged or not installed.

## Managing low-battery conditions

The information in this section describes the alerts and system responses set at the factory. Some low-battery condition alerts and system responses can be changed using Power Options in Windows Control Panel. Preferences set using Power Options do not affect lights.

### Identifying low-battery conditions

When a battery that is the sole power source for the computer reaches a low-battery condition, the battery light blinks.

If a low-battery condition is not resolved, the computer enters a critical low-battery condition, and the battery light continues to blink.

In a critical low-battery condition:

- If Hibernation is enabled and the computer is on or in the Sleep state, the computer initiates Hibernation.
- If Hibernation is disabled and the computer is on or in the Sleep state, the computer remains briefly in the Sleep state, and then shuts down and loses any unsaved information.

## Resolving a low-battery condition



**CAUTION** To reduce the risk of losing information when the computer reaches a critical low-battery condition and has initiated Hibernation, do not restore power until the power lights turn off.

### Resolving a low-battery condition when external power is available

Connect one of the following devices:

- AC adapter
- Optional expansion product
- Optional power adapter

### Resolving a low-battery condition when a charged battery is available

1. Turn off the computer or initiate Hibernation.
2. Remove the discharged battery, and then insert a charged battery.
3. Turn on the computer.

### Resolving a low-battery condition when no power source is available

- Initiate Hibernation.
  - or –
  - Save your work and shut down the computer.

### Resolving a low-battery condition when the computer cannot exit Hibernation

When the computer lacks sufficient power to exit Hibernation:

1. Insert a charged battery or plug the computer into external power.
2. Exit Hibernation by pressing the power button.

# Calibrating a battery



**NOTE** It is not necessary to calibrate a new battery.

Even if a battery is heavily used, it should not need to be calibrated more than once a month. Calibrate a battery under the following conditions:

- When battery charge displays seem inaccurate
- When you observe a significant change in battery run time
- When the battery has been unused for one month or more

Three steps are involved in calibrating a battery: fully charging, discharging, and then fully recharging.

## Step 1: Fully charge the battery



**WARNING!** Do not charge the computer battery while you are onboard aircraft.



**NOTE** A battery can charge whether the computer is off or in use, but it will charge faster when the computer is off.

To fully charge the battery:

1. Insert the battery into the computer.
2. Connect the computer to an AC adapter, optional power adapter, optional expansion product, or optional docking device, and then plug the adapter or device into external power.

The battery light on the computer turns on.

3. Leave the computer plugged into external power until the battery is fully charged.

The battery light on the computer is turns off.

## Step 2: Disable Hibernation and Sleep

1. Click the battery meter icon in the notification area, and then click **More power options**.

– or –

Click **Start > Control Panel > System and Maintenance > Power Options**.

2. Under the current power plan, click **Change this plan**.
3. Record the **Turn off display** and **Put computer to sleep** settings listed in the **On battery** column so that you can reset them after the calibration.
4. Change the **Turn off display** and **Put computer to sleep** settings to **Never**.
5. Click **Change advanced power settings**.
6. Click the plus sign next to **Sleep**, and then click the plus sign next to **Hibernate after**.
7. Record the **On battery** setting under **Hibernate after** so that you can reset it after the calibration.
8. Change the **On battery** setting to **Never**.

9. Click **OK**.
10. Click **Save settings**.

### Step 3: Discharge the battery

The computer must remain on while the battery is being discharged. The battery can discharge whether or not you are using the computer but will discharge faster while the computer is in use.

- If you plan to leave the computer unattended during the discharge, save your information before beginning the discharge procedure.
- If you use the computer occasionally during the discharge procedure and have set energy-saving timeouts, expect the following performance from the system during the discharge process:
  - The monitor will not turn off automatically.
  - Hard drive speed will not decrease automatically when the computer is idle.
  - System-initiated Hibernation will not occur.

To discharge a battery:

1. Unplug the computer from its external power source, but do *not* turn off the computer.
2. Run the computer on battery power until the battery is discharged. The battery light begins to blink when the battery has discharged to a low-battery condition. When the battery is discharged, the battery light turns off and the computer shuts down.



## Step 4: Fully recharge the battery

To recharge the battery:

1. Plug the computer into external power and maintain external power until the battery is fully recharged. When the battery is recharged, the battery light on the computer turns off.

You can use the computer while the battery is recharging, but the battery will charge faster if the computer is off.

2. If the computer is off, turn it on when the battery is fully charged and the battery light has turned off.

## Step 5: Reenable Hibernation and Sleep



**CAUTION** Failure to reenable Hibernation after calibration may result in a full battery discharge and potential information loss.

1. Right-click the **Power Meter** icon in the notification area, at the far right of the taskbar, and then click **Adjust Power Properties**.

– or –


Select **Start > Control Panel > Performance and Maintenance > Power Options**.

2. Reenter the settings that you recorded for the items in the **On battery** column.
3. Click **Change advanced power settings**.
4. Click the plus sign next to **Sleep**, and then the plus sign next to **Hibernate after**.
5. Reenter the setting that you recorded for **On battery**.
6. Click **OK**.
7. Click **Save settings**.

## Conserving battery power

- Use the operating system to select a power plan with low power-use settings.
- Turn off wireless and local area network (LAN) connections and exit modem applications when you are not using them.
- Disconnect external devices that are not plugged into an external power source, if you are not using them.
- Stop, disable, or remove any external media cards that you are not using.
- Use the **fn+f8** and **fn+f7** hotkeys to adjust screen brightness as needed.
- Use optional powered speakers instead of the internal speakers, or adjust speaker volume as you needed.
- If an external display device is connected to the computer, press **fn+f4** to switch the screen image from the computer display to the external display.
- If you leave your work, initiate Sleep or Hibernation, or shut down the computer.

## Storing a battery

 **CAUTION** To prevent damage to a battery, do not expose it to high temperatures for extended periods of time.

---

If a computer will be unused and unplugged from external power for more than 2 weeks, remove the battery and store it separately.

To prolong the charge of a stored battery, place it in a cool, dry place.

Calibrate a battery before using it if it has been stored for one month or more.

## Disposing of a used battery



**WARNING!** To reduce the risk of fire or burns, do not disassemble, crush, or puncture a battery; short the external contacts on a battery; or dispose of a battery in fire or water. Do not expose a battery to temperatures above 60°C (140°F). Replace the battery only with a battery approved for this computer.

Refer to the *Regulatory, Safety, and Environmental Notices* for battery disposal information.

## 3 Using external AC power

External AC power is supplied through one of the following devices:

- AC adapter included with the computer
- Optional docking device or expansion product
- Optional power adapter

Connect the computer to external AC power under any of the following conditions:

- When you are charging or calibrating a battery pack.



---

**WARNING!** Do not charge the computer battery while you are onboard aircraft.

---

- When you are installing or modifying system software.
- When you are writing information to a CD or DVD.

When you connect the computer to external AC power, the following events occur:

- The battery begins to charge.
- If the computer is turned on, the battery meter icon in the notification area changes appearance.

When you disconnect external AC power, the following events occur:

- The computer switches to battery power.
- The display brightness is automatically decreased to save battery life. To increase display brightness, press the **fn+f8** hotkey or reconnect the AC adapter.

## Connecting the AC adapter

**!** **WARNING!** To reduce the risk of electric shock or damage to the equipment:

Plug the power cord into an AC outlet that is easily accessible at all times.

Disconnect power from the computer by unplugging the power cord from the AC outlet (not by unplugging the power cord from the computer).

If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature.


To connect the computer to external AC power:

1. Plug the AC adapter into the power connector **(1)** on the computer.
2. Plug the power cord into the AC adapter **(2)**.
3. Plug the other end of the power cord into an AC outlet **(3)**.



## 4 Shutting down the computer

---

 **CAUTION** Shutting down the computer results in the loss of unsaved information.

---


The Shut Down command closes all open programs, including the operating system, and then turns off the display and computer.

Shut down the computer under any of the following conditions:

- When you need to replace the battery or access components inside the computer.
- When you are connecting an external hardware device that does not connect to a USB port or a 1394 port.
- When you have installed a program or update that requires Windows to restart to complete the installation.
- When the computer will be unused and disconnected from external power for an extended period.

To shut down the computer:

---

 **NOTE** If the computer is in the Sleep state or in Hibernation, you must first exit Sleep or Hibernation before shutdown is possible.

---

1. Save your work and close all open programs.
2. Click **Start**, and then click the arrow next to the Lock button.
3. Click **Shut Down**.

If the computer is unresponsive and you are unable to use normal Windows shutdown procedures, try the following emergency procedures in the sequence provided:

- Press **ctrl+alt+delete**. Then, click the arrow next to the power button icon and click **Shut Down**.
- Press and hold the power button for at least 5 seconds.
- Disconnect the computer from external power and remove the battery.