

**Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Helpful Hints**

- ❑ Use fresh batteries. The use of weak batteries may cause your vehicle to have slow response times.
  - ❑ Do not mix old and new batteries.
  - ❑ Do not mix alkaline, standard (Carbon-Zinc) or rechargeable (Ni-Cd) batteries.
  - ❑ Your vehicles will not run if the batteries are installed incorrectly, please refer to the illustration located inside the battery compartment.
  - ❑ Sometimes the vehicle is driven beyond the radio signal range causing loss of control. Range in your vehicle is approximately 30' to 50'.
  - ❑ Running times may vary, alkaline batteries generally last between 25 to 40 minutes.
  - ❑ Sometimes loss vehicle control is due to being in an area near interfering sources. CB radios, microwave transmitters, cordless telephones, wireless communications, security systems, high voltage transformer or even certain buildings can cause interference.
  - ❑ Avoid driving in damp or wet areas.
  - ❑ Shielded cables must be used with this unit to ensure compliance with the Class FCC limits.
- Toll Free Kid Galaxy Hot Line: 800-816-1135



**WARNING:**  
CHOKING HAZARD - Small parts  
Not for children under 3 years.

**Introduction**

DRV Truck & ATV is an unique radio controlled vehicle. With a single radio control you can control each vehicle independently. Double the fun. Double the adventure.

**Operating Instructions**

**Truck**


1. Unscrew the battery cover on the bottom of the truck with a Philips screw driver.
2. Install 4 AA batteries with polarities as shown inside the battery compartment.
3. Replace the battery cover and replace the screw.

**ATV**

1. Unscrew the battery cover on the bottom of the ATV with a Philips screw driver.
2. Install 2 AAA batteries with polarities as shown inside the battery compartment.
3. Replace the battery cover and replace the screw.


**Handset**

1. Unscrew the battery cover on the bottom of the handset with a Philips screw driver.
2. Install a 9v battery with polarities as shown inside the battery compartment.
3. Replace the battery cover and replace the screw.



**How to Install the Truck Pull-Out Ramp**


1. Slide out the plastic ramp extension.
2. Push the ramp extension up to a 45° angle.
3. Pull out the bottom half of the ramp extension.
4. Place the ramp on a level surface.



**How to operate the Truck & ATV**


**Truck**

1. Turn the switch located at the bottom of the vehicle to the ON position.
2. Turn the switch located on the hand set to the ON position.
3. The button on the handset should be in the UP position to operate the Truck.
4. Refer to illustrations to operate the truck.




**ATV**

1. Turn the switch located at the bottom of the vehicle to the ON position.
2. Turn the switch located on the hand set to the ON position.
3. Push DOWN the button located on the hand set.
4. To drive the ATV refer to the illustrations.
5. Pull out the ramp to drive the ATV the ramp.



**Operation Tips**

If your vehicle pulls to the right or left while driving forward, you can adjust the steering with the calibrator. The calibrator is located on the bottom of the vehicle. Make slight adjustments until you have the correct forward motion.



**Operation Tips**

If your vehicle pulls to the right or left while driving forward, you can adjust the steering with the calibrator. The calibrator is located on the bottom of the vehicle. Make slight adjustments until you have the correct forward motion.

