全成电子有限公司

TSUEN SHING ELECTRONICS LTD

TUNE-UP PROCEDURE

(The hand held MURS)

1. TRANSMITTING

1.1 TX VCO ADJUSTMENT

- a) Connect the DC voltmeter to the test point "TP1".
- b) Press the PTT Button.
- c) Adjust L2
- d) Specification: 0.8Vdc to 2.5V @ CH1

1. 2 FREQUENCY ADJUSTMENT

- a) Connect the frequency counter to ANT point
- b) Adjust VC1.
- c) Specification: TX Frequency +/- 500Hz

1.3 TX POWER CHECK

- a) Connect the RF level meter to the ANT point (RF Impedance: $50\,\Omega$)
- b) Press the PTT button.
- c) Check the TX Power.
- d) Specification: 1.5W $\pm 0.2W$

MAX. DEVIATION ADJUSTMENT

- a) Connect the deviation meter to the ANT point
- b) Apply the audio signal 1KHz, 40mVrms to the test point "TP1" (MIC input).
- c) Observe the dipped signal on the scope.
- d) Adjust VR1
- e) Specification: 2.5KHz Dev +/- 0.2KHz

MODULATION SENSITIVITY ADJUSTMENT

- a) Connect the deviation meter to the ANT point.
- b) Apply the audio signal 1KHz, 4mVrms to the test point "TP1" (MIC input).
- c) Adjust VR1.
- d) Specification: 0.9 1.5KHz Dev

CALL DATA MODULATIN SENSITIVITY CHECK

- a) Press the Call Button and observe the deviation meter to check the deviation.
- b) Specification: 1.5KHz +/- 0.3KHz

2. RECEIVING

2.1 RX VCO CHECK

- a) Connect the DC voltmeter to test point "TP1"
- b) Check the DC voltage
- c) Specification: 0.8Vdc to 2.5V @ CH1
- 2.2. How to adjust the IF sensitivity, low-frequency distortion and power output:
 - a. To connect the speaker output terminal to the IF input terminal of radio communication analyzer.
 - b. To turn T1 to adjust the audio output is min and distortion is max.
 - c. To observe, thaen the audio signal outputs 12dB, now IF input is < 25dBemf .
 - d. To observe audio output power is $\geq 150 \text{mW}$.
- 2.3. How to adjust high-frequency RX sensitivity and image suppress
 - a. To connect the output terminal of speaker and antenna input terminal to the radio communication analyzer.
 - b. To adjust L5 to make the RX sensitivity is $\leq -4 \, \text{dBu}$ emf and image suppression is>50dB.
 - c. To adjust VR1 to make the RX squelch turn on sensitivity is =-4 ± 2 dBu emf.

Otheres:

- 1. Press 'MON' key to make the unit to receive thin signal.
- 2. Press 'UP' and 'DOWN' key to ditect the frequency point relatively, which displaying.
 - 3. Check the cosmetic and tlecommunication function.

编	制: 辛 永 枝	軍	核:	批	准:
Н	期: 02 年 8 月 21 日	Н	期:	日	期: