



■ PANTONE 425C
■ PANTONE 382C



7.8011 cm

12.5042 cm



Package Contents

1

- 1 x TuneTap - Wireless Audio Receiver
- 1 x Power Adapter
- 1 x 3.5mm Audio Adapter
- 1 x Quick Start Guide
- 1 x Warranty Card

System Requirements

- Android™ Smartphone / Tablet
- iPod® touch (2nd generation and later)
- iPhone® (3G and later)
- iPad® (all models)
- Windows® Phone / Tablet
- Works with any music player with Bluetooth audio (A2DP Profile)

NFC Phones / Tablets:

- For NFC-enabled phones / tablets with Android 4.1 and higher

Overview

2

Top View:

1. LED Indicator
 - Lights solid when Bluetooth link is established



1

Back View:

1. Optical Output
2. 3.5mm Audio Output
3. Micro USB Power Jack




1 2 3

Hardware Installation

3

1. Connect TuneTap to an audio input on your home stereo music system.
 - Use the included 3.5mm to RCA cable or a 3.5mm auxiliary cable (not included) for an analog audio connection.
 - Use an Optical cable (not included) for a digital audio connection.
2. Connect the power adapter to the TuneTap power jack and plug the power adapter into a power outlet.
3. The LED will flash twice to indicate that the unit is powered and ready to be paired with your Bluetooth enabled device.



Pairing your Smart Device

4

For NFC enabled smart devices with Android 4.1 or later:

1. Go to the **Settings** menu on your device and turn on NFC pairing.
2. Once enabled, tap your device on the TuneTap for up to 3 seconds to automatically set up an audio link with your device.

For non-NFC enabled smart devices:

1. Go to the **Settings** menu on your device and turn on the Bluetooth function.
2. Add (Search) for new devices. Select **IOGEAR TuneTap** from the list of available devices.
3. The device will show connected after the **IOGEAR TuneTap** has been successfully paired.

Switching between Source Devices

1. Start by disconnecting the smart device that is currently paired to TuneTap through the device's Bluetooth settings menu.
2. Once disconnected, TuneTap will be ready to pair to a different smart device.
3. To connect to another smart device, follow the steps for **Pairing your Smart Device** above.

Troubleshooting

5

Reconnecting your device

If you move out of range or disable Bluetooth on your smart device, TuneTap will disconnect from your device. To reconnect, simply access the Bluetooth settings on your device and select **IOGEAR TuneTap** to reconnect.

Out of Range or Lost Signal

If your device is out of range (over 30 feet) from TuneTap or if there is something blocking the Bluetooth signal, the LED will turn off to indicate that the Bluetooth connection is lost. To avoid a lost connection, move your device back into range (within 30 feet) or reduce any obstructions between your device and the audio receiver. Within 15 seconds, the connection will automatically be re-established and the LED will light solid. If the connection is lost for more than 15 seconds, the connection will need to be re-established manually, follow the directions for **Reconnecting your device**.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Statement

6

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CE Statement

This device has been tested and found to comply with the following European Union directives: Electromagnetic Capability (2004/108/EC), Low Voltage (2006/95/EC) and R&TTE Directive (1999/5/EC).

Limited Warranty

7

WE'RE HERE TO HELP YOU! NEED ASSISTANCE SETTING UP THIS PRODUCT?

Make sure you:

1. Visit www.iogear.com for more product information
2. Visit www.iogear.com/support for live help and product support

Warranty Information

This product carries a 1 Year Limited Warranty. For the terms and conditions of this warranty, please go to <http://www.iogear.com/support/warranty>

Register online at <http://www.iogear.com/register>

Important Product Information

Product Model _____
Serial Number _____

Contact

IOGEAR

iogear.custhelp.com
support@iogear.com
www.iogear.com
19641 Da Vinci, Foothill Ranch, CA 92610