

Installation Instructions

GENERAL INFORMATION
The ION MICRA recessed transmitter is a reed switch magnetic contact transmitter that provides concealed protection for a window. The transmitter is powered by a long-life lithium battery that is easily replaceable when a low battery is indicated by the control.

Programming the ID Number
Each ION MICRA has its own unique identification code (serial number) permanentrly assigned during manufacturing.

The control unit is required to "enroll" the transmitter's ID during installation of the alarm system.

PRELIMINARY CONSIDERATIONS

Read all of this and the next section before installing the unit.

1. Select a location for the transmitter on the frame of the window.

Do not use on metal frame doors or windows.

iON MICRA TRANSMITTER
The ION MICRA transmitter will require a 3/4" diameter hole (using a 3/4" Forstner bit) drilled into the edge of the window frame no more than 1/3"

deep.
BEFORE DRILLING ANY HOLES, SEE ITEM 2 BELOW AND MOUNTING SECTION
ON THE NEXT PAGE.

FOR VINYL SLIDING WINDOWS the preferred direction of mounting is

vertical.

FOR HUNG WINDOWS the iON MICRA must be mounted horizontally in the window sill with the accompanying surface mount magnet in the lower window sash. (see Step 1 - Measure & Drill in Figure 1)

2.Before drilling any holes, tape the transmitter and magnet in their approximate locations (with battery installed and unit together as described under BATTEXY INSTALLATION FERLACEMENT (see page back) and conduct GRONG Go tests (see control's instructions) to verify adequate signal strength. Reorient or relocate the transmitter if necessary.

Make sure that no more than a $1/2^{\circ}$ gap will be present between the faces of the transmitter and the magnet cases when they are installed and set. Also make sure the 10° Graphic on the transmitter is perpendicular to the length of the magnet as per Step 3.


When installed, an alarm signal must be obtained before a clear space of $2^{\prime\prime}$ is reached as the window is opened.

3. For door applications, the alternate Plunger package can be used. In this case, the 34th hole is drilled into the door frame on the hinge side, and should be 1,00° deep, with a smaller hole drilled further into the frame to accomodate the wire antenna. The electronics are identical, however with the plunger package, the magnet is captive in the platic housing, and does not require a separate magnet on the door itself. This makes the installation easier, and minimizes the gap require between the door and the door frame.


MARNING:

Under no circumstances should the outer wall of the window frame be penetrated by the Forstner bit.

ION MICRA Recessed Transmitter







iON MICRA

Recessed Transmitter



Reed Switch Positioning

MOUNTING (See Figure 1)

1. Mark the selected location for the transmitter on the frame of the window.

CAUTION: Before drilling any holes, make sure that successful

- 2. Mark the location for the magnet on the window sash, directly opposite the transmitter location. Before drilling any holes, make sure that the successful Go/No Go Transmission receptin tests have been conducted as called for in the ION MICRA transmitter section. (see page back)
- 3. Drill holes at the location marked, for the transmitter (3/4" diameter, no more than 1/3" deep).
- Insert the transmitter into the hole so that the cap is flush with the surface. Make sure the antenna goes into the cavity as straight as possible.

DO NOT hammer the transmitter or the magnet in place with hard blows. Press them into their respective holes by hand.

The iON MICRA uses a santaprene case that, once placed, is designed to self-seal in the mounting hole. However, if desired, a thin bead of silicon may be applied for additional moisture protection







FCC

SPECIFICATIONS



CAUTION: BATTERY CAUTION: Risk of fire, explosion and but not recharge, disasterable, heat above 212°F (100°C) or incinerate. Disposil used batteries promptly. Keep away from children.

Dowel Package Additional Info Wire Antenna Fits Cavity Depth

ION MICRA transmitters

0.750" diameter
Dowel Lid 0.850" diameter x 0.060" thick
11" x 0.050" diameter (24 gauge)
0.330" depth
1.00" Lithium Coin Cell Battery CR1620
Typically 550" tr. open air
10" to 120" F. (-10" to 50" C)

Viryl, Wood Casement, Awning, Double-Hung and Access. Plunger Pkg

ved by ION Digital LLF can void the user's auth



TO THE INSTALLER

TO THE INSTALLER Regular maintenance and inspection (at least annually) by the installer and frequent testing by the user are vital to continuous satisfactory operation of any alarm system. The installer should assume the responsibility of developing and offering a regular maintenance program to the user, as well as acquasitring the user with the proper operation and limitations of the alarm system and its component parts. Recommendations must be included for a specific program of frequent testing (at least weekly) to insure the system's operation at all times

RECEIVER / CONTROL WITH WHICH THIS DEVICE IS USED, FOR WARRANT' INFORMATION AND FOR DETAILS REGARDING LIMITATIONS OF THE ENTIRE ALARM SYSTEM.

BATTERY INSTALLATION & REPLACEMENT

- 1. Remove the transmitter from the window by inserting the flat blade of . Remove the transmitter from the window by inserting the flat blade of a small screenfvier into the psy-fot on the cap end and twisting slightly counter-clockwise. The transmitter must be removed from the window complete in order to refit the transmitter properly back into the hole once the internal battery has been replaced.
- 2. Using the flat blade of a small screwdriver in the pry-slot again, separate . Using the flat blade of a small screwdriver in the pry-dot again, separate the white cap from the orange base with a slight counter-clockwise twist. Once open, slide the cap with the transmitter PC board assembly apart from the orange base. Pull the antenna through the hole in the orange base just enough to allow the battery to be replaced. Do not pull the antenna completely out of the orange base.

US Patent No. 6,737,969 Copyright © 2005 iON Digital LLP

- Observe correct polarity (see Figure 3 Step 3 & 4) and insert the fresh battery into the battery holder (positive polarity indicator is shown or the battery holder).
- Slide the cap with the PC board assembly back into its orange base by gently pulling on the antenna, easing the transmitter cap into place.
- 6. Snap the transmitter cap back onto the orange base, locking it into place. Placing the antenna into the cavity first, reinsert the transmitter into its original mounting hole in the window. Be sure to point the "iON" graphic on the cap in the same direction as the "iON" graphic on the accompanying sash-mounted magnet.

Toll Free 1-800-407-4389

ON

Remove the old battery from it's battery holder on the bottom of the PC board.

THE SENSE OF SECURITY"