

San Jose, California, 95134

# Maximum Permissible Exposure Calculation for the Airespace AP 1200 FCC ID: QTZWNAP1200A

The Airespace Access Point is an IEE802.11 A radio. The access point operates on the 5GHz UNII band. The MPE distance for this band is calculated below.

## **Operating Environment:**

The operating environment for the for the radio in all cases is a fixed, uncontrolled environment, however, the devices are classified as being "Mobile"

## Fixed, Uncontrolled Environment:

The FCC limit for the power density for uncontrolled exposure to RF devices operation at 2.4GHz and 5GHz is:

1 mW/cm2

Power density is calculated from the following equation:

1 1

Exposure (mW/cm<sup>2</sup>) = Pout (mW)\*Duty Cycle\*(Antenna Gain(as a ratio)/(4\*PI\* Radius<sup>2</sup>(cm)))

Solving the above equation for Radius yields:

Radius = 
$$V \xrightarrow{P_{out}(mw) * Duty Cycle*Antenna Gain_{(ratio)}}{Exposure(mW/cm^2) * 4 * Pi}$$

#### **5 GHz UNII Band MPE distance Calculation**

On channels 1 and 11 of this band, the power is reduced to meet other regulatory criteria. On all other channels of the band the transmit power is set to the +17dBm setting.

MAX Pout: 19.7 dBm (93.32mW) MAX Ant Gain 5.9 dBi (3.89x) EIRP: 25.6 dBm (363.07 mW EIRP)

#### Calculating the MPE distance based on this EIRP:

Calculating the radius of the sphere around which the power density is at the FCC limit. This radius is the MPE distance. To calculate the worst case, a 100% duty cycle is also assumed for each band.

The following RF Exposure statement will appear near the front of the users / installation manual for the VAP 1200A

# **RF Exposure Safety FCC RF Exposure Requirements**

To ensure compliance with FCC RF exposure requirements, this device must be installed in a location such that the antenna of the device that will be greater then 20cm (8 in.) from all persons. Using higher gain antennas and types of antennas not covered under the FCC certification of this product is not allowed.

Installers of the radio and end users of the system must adhere to the installation instructions outlined in this manual.