

X22SW

4-CHANNEL HEIGHT HOLD HOVER TRANSMITTER DRONE



USER MANUAL

MAIN FEATURES

- Special 4-axis structure-fast and agile. Suitable for flying in spacious indoor areas.
 - Duckin Beaks gyroscope ensures accurate position hold.
 - Modular design for easy upgrades and maintenance.
 - Capable of doing 300 degrees stunts.
 - Headless mode for easy recall of the drone.
 - Improved height hold stability.
 - Improved auto take-off/landing function.
 - Enjoy aerial photography with high definition wireless real time video transmission.
- Note: The company will not be held responsible for any printing inconsistencies and may or not inform end users regarding any new potential updates. For further information, please visit the syrna website.

- ### Safety Guide
- Please, keep the small drone accessories out of reach of children.
 - This drone is very powerful. During the first time, avoid sudden movements of the throttle. When ascending, push the throttle stick slowly to avoid unintended high take-offs.
 - After flying, turn off the transmitter before turning off the drone.
 - Do not fly over people or animals. Do not fly over water or near tall objects.
 - It is strongly recommended to operate the drone at 2-3 meters away from a pilot and other people or animals. Children are not allowed to fly the drone.
 - When landing the drone, avoid crashing it into other people.
 - Adult or experienced RC pilot's supervision is required for children.
 - Non-schrapnel batteries should not be recharged. Batteries should be recharged with a correct polarity. Different types of batteries, new or used, batteries should not be mixing.
 - Turn off the drone/batteries and remove the batteries when not in use.
 - The supply terminals should not be short-circuited.
 - When not in use for more than 10 days, please measure to protect the drone's battery life by reducing the drone battery level to 40%-50% of its capacity/charge the battery when fly the drone for half of its flying time.
 - Keep away from the rotating blades (rotating blades may cause bodily injuries, or damage to property).
 - To avoid interfering with traffic, control signals avoid flying a drone within 5000 meters of an airport. Avoid operating RC equipment during the periods set by the local authority.
 - Only use the included charger.
 - Liquids can be used to clean the product. Turn off the equipment and unplug the charger from the power source before cleaning the drone. Do not perform routine inspection of the charger (check, point, split and other parts) on a regular basis. If any abnormalities are found, immediately stop using the charger and contact the manufacturer.
 - Attention: Drone assembly under adult supervision.
 - Do not touch directly into the LED light source as it can damage your eyes.
 - Open the battery cover of the toy with care.
 - The packing has to be kept since it contains important information.
 - Do not touch the rotating parts, avoid loose clothing or hair that could be caught in the rotor, do not fly near the face.
 - Advise to keep the instructions for safe.

- ### Repair and Maintenance
- Use clean and soft cloth to clean the product.
 - Keep away the product from heat sources.
 - Avoid water exposure to this product. Moisture may cause damages of the aircraft electronic parts, should be examined regularly, such as the cord, plug, enclosures and other parts. In case of any damages is found, please stop using it unless it is repaired or replaced.

- ### Box Contents
- Items included:
- Drone
 - USB Charging Cable
 - USB Headset
 - Blades X4
 - Transmitter
 - Mobile Phone Mount
- ### Re-installing the Blades
- Remove the screws before re-installing the blades.
 - A labeled blades fit on the A labeled motor. B labeled blades fit on the B labeled motor. Use the screws to tighten the blades, refer to the image.

- ### Installing the Mobile Phone Mount
- To install the mobile phone mount, insert it into the mobile phone mount's slot at the top of the transmitter.

- ### Removing the Mobile Phone Mount
- To remove the mobile phone mount, pull it up from the back of the transmitter.

- ### Charging the Drone Battery Method 1
- Turn to the drone off, press down on the drone's on/off button for 1-2 seconds.
 - Press the battery cover and pull the battery out.
 - Connect the USB charging cable to the battery.
 - Insert the charging cable into computer USB (when charging the light will be on, uplug the charger when the light goes off, charging time about 90 minutes).

- ### Charging the Drone Battery Method 2 (Optional Purchase)
- Connect the charging cradle to the charging cable, insert the charging cable into computer USB.
 - After observe the charging cradle light, if the connection is successful the cradle's charging indicator light will be off. Insert the battery into the charging cradle. When charging, the cradle's charging indicator light will glow. Unplug the charger when the light goes off.
- Charging time is about 90 minutes. Dronem hover time is about 6-8 minutes.
- #### Important: battery charging information
- Do not keep the battery in high temperature areas, such as fire or heat sources. Otherwise, it may damage the battery or even trigger an explosion.
 - Do not put the battery into water. Store the battery in a cool and dry environment.
 - Avoid dampening the batteries.
 - During the charging of battery, avoid leaving the charging cradle. Rechargeable batteries should be removed from the toy before being charged.
 - Rechargeable batteries should only be charged under the supervision of adults.
 - Charged batteries should be removed from the aircraft.
 - Caution: Risk of explosion if battery is replaced with incorrect ones. Please dispose the batteries according to the instructions.

- ### Understanding the Transmitter
- Transmitter functions:
- ON/OFF Button
 - Mobile Phone Mount
 - Right stick: Long press to activate headless mode. Press the stick to change speed mode.
 - Left stick: Press the stick to enter mode, let the stick to exit from mode. To reset trim, press the stick and turn on the transmitter.
 - 3D Stunt
 - Auto take-off and landing
- ### Installing transmitter batteries:
- Transmitter battery installation: open the battery cover at the back of the transmitter, install 4pcs AA batteries according to the polarity indicators. (Note: batteries are not included).
- Caution: Do not mix old and new batteries. Do not mix different brands of batteries. Do not mix different types of batteries together. No battery should be installed with the opposite polarity. Please do not mix old and new batteries together.

- ### Installing the Drone's Battery
- Reminder: when installing the battery, ensure that the arrow sign on the battery is pointing up.
- ### Preparation for Flight
- Flight preparation
 - Turn on the transmitter.
 - Turn on the drone, press down the drone on/off button for 1-2 seconds.
 - Move the left stick (throttle) fully up, and after fully down. The drone indicator lights will turn solid (glow) indicating the drone is ready to fly.
 - Arming Motors

WARNING: 1. Move the left stick (throttle) fully up, after let it come back to the middle, the motors will start spinning.

- ### Disarming Motors
- Push the left stick (throttle) fully down and hold it there for 2-3 seconds, and the motors will stop spinning.
 - Push both sticks at the same time (left stick to the bottom-right corner and the right stick to the bottom-left corner) and hold for 1 second and the motors will stop spinning.
 - After the drone is in a stable hovering position, press the R button and the drone will automatically disarm.

- ### Fly the Drone
- #### Operations
- Ascend/Descend
 - Forward/Backward
 - Left/Right Rotation
 - Left/Right
- When the left stick (throttle) is moved up/down, the drone will ascend/descend.
- When the left stick (throttle) is moved left/right, the drone will rotate to the left/right.

- ### Trimming
- #### Forward/Backward Trim Control
- If the drone drifts quickly forward or backward while hovering, please adjust forward/backward trim. Press the left stick and hold it, then move the right stick forward/backward until the drone starts hovering as normal.
- #### Left/Right Trim Control
- If the drone drifts quickly to the left or right while hovering, please adjust left/right trim. Press the left stick and hold it, then move the right stick left/right until the drone starts hovering as normal.
- #### Left/Right rotation trim
- If the drone rotates quickly to the left or right while hovering, please adjust left/right rotation trim. Press the left stick and hold it, then move it to the left/right until the drone starts hovering as normal.
- ### Product Features
- Low-Voltage Protection: When the drone battery is low, the drone indicator lights will start flashing. After this warning, return your drone to the ground location and land it. After the drone's low voltage battery protection is activated, the drone will start losing altitude and will gradually land.

- Overflow Protection: When the drone is in the air and the propellers collide with objects or become jammed, the drone overflow protection will be activated.
 - Balance Calibration: Place the drone on a flat level surface and after push both sticks to the lowest right corner and hold them there for 2 to 3 seconds. The drone indicator lights will start flashing quickly. Wait until the drone indicator lights stop flashing and are solid again (glow) indicating successful balance calibration.
 - Low/High Speed Mode: To change the speed mode, gently press the right stick once, the transmitter will emit two beeps indicating high speed mode. Gently press the right stick again and the transmitter will emit one beep indicating low speed mode.
 - 3D Stunts: After the basic operational skills are mastered, you can start performing 3D stunts. The recommended safety height is at least 3 meters above the ground. Press the 3D stunt button (right button on the transmitter) and at the same time push the directional stick completely forward/backward/left/right. The drone will perform Forward/Backward/left/right 3D stunt.
- NOTE: Fully charged drone battery will ensure the best 3D stunt performance.

- ### 6. Height Hold:
- Use the left stick (throttle) to achieve the desired height and after allow the left stick to fall back to its default mode position.
- ### 7. Headless Mode:
- #### Setting Forward Direction:
- Turn on the transmitter.
 - Turn on the drone, press down the drone on/off button for 1-2 seconds. To set the drone's headless mode forward direction, ensure the front of the drone is pointing in the desired forward direction.
 - Move the left stick (throttle) fully up and after fully down. The transmitter will emit one long beep indicating successful pairing and defined forward direction.
- #### Calibration:
- When in headless mode, the forward direction may start deviating due to magnetic crashes. Re-set the forward direction and after push both sticks simultaneously to the lowest left corners. The drone indicator lights will start flashing and after 3 seconds will turn solid (glow) indicating successful calibration.

- ### Activating/Deactivating Headless Mode:
- After successful pairing observe the drone indicator lights and wait until they turn solid (glow). Press the right stick and hold it for 2 seconds, the transmitter will emit 3 beeps indicating headless mode is activated. Press the right stick again and hold it for 2 seconds after the transmitter will emit one long beep indicating headless mode is deactivated.
 - When flying in the headless mode, it does not matter in which direction the front of the drone is facing. It will fly forward/backward/left/right relative to the position of stick.
- ### Real Time Video Transmission
- Software Download/Install Instructions: Android: Please download and install the software SYMA FLY from www.syrna.com or scan the QR code. IOS: Please download and install the software SYMA FLY from the App Store, or scan the QR code.
- NOTE: QR codes can be found on the packaging box or at the last page of the user manual. "SYMA FLY" app version can be downloaded from the App Store.
- For more connection instructions, please refer to the App.

- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment operates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
- However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/television help.
- *This device complies with FCC radiation exposure limits set forth for general population (uncontrolled exposure). This device must not be collocated or operating in conjunction with any other antenna or transmitter.*
- Declaration of Conformity Intests: "Hesley, Guangdong Syrna model drone industrial co., ltd. declares that this drone is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU."
- A copy of the full DOC is attached.

- ### Accessories/Parts (Optional)
- Please, look through the parts below. For your convenience, we have specified every part and accessory. The parts and accessories can be purchased through local distributors. Please specify detailed colours at the time of purchase.
- | | | | |
|------------------------|--------------------|----------------------------|----------------------------|
| Body (White) | Body (Black) | Blade | Protective Guard |
| Light Protective Cover | Main Body Elements | Battery Storehouse (White) | Battery Storehouse (Black) |
| Battery (White) | Battery (Black) | Camera | X22SW Receiver |
| Motor A | Motor B | Light Board | USB Charger |

- ### Product Main Parts and Components
-
- | Part No. | Part Name | Quantity | Part No. | Part Name | Quantity |
|----------|------------------------|----------|----------|---------------|----------|
| 01 | Transmitter | 1 | 08 | Motor (Black) | 1 |
| 02 | Mobile Phone Mount | 1 | 09 | Motor (White) | 1 |
| 03 | USB Charging Cable | 1 | 10 | Motor (Black) | 1 |
| 04 | Drone | 1 | 11 | Motor (White) | 1 |
| 05 | Blade | 4 | 12 | Motor (Black) | 1 |
| 06 | Protective Guard | 1 | 13 | Motor (White) | 1 |
| 07 | Light Protective Cover | 1 | 14 | Motor (Black) | 1 |

- ### Main Specifications
-
- Drone length: 16.6cm
Drone width: 17.6cm
Drone height: 3.7cm
Motor size: Ø7
Battery: 3.7V 400mAh Lithium battery

- ### Troubleshooting
- | Problem | Reason | Solution |
|---|---|---|
| The drone does not respond. | 1. The drone has activated low voltage battery protection.
2. The transmitter battery is low.
3. The transmitter indicator light flashes. | 1. Recharge the drone's battery.
2. Charge the transmitter's battery. |
| The transmitter sticks are not sensitive. | 1. The transmitter battery is low.
2. There is another transmitter with the same frequency causing interference. | 1. Change the transmitter's battery.
2. Please change flying location. |
| The drone is unstable, hovering or moving in one direction. | | Perform balance calibration. Please refer to page number 6. |
| When in headless mode the drone deviates direction. | | Re-set Forward direction. Please refer to page number 11. |

- | Problem | Reason | Solution |
|--|---|----------|
| The drone does not respond set altitude. | 1. Balance calibration is needed.
2. Flapping the drone in reverse under conditions (strong wind, rain, snow, fog, thunder etc.)
3. Perform balance calibration.
4. Perform speed calibration.
5. Please refer to page number 10. | |

-
- Manufacturer: Guangdong Syrna Model Aircraft Industrial Co., Ltd.
Address: No. 2 West Xinyue Road, Intersection of North Xinyue Road, Lantian Industrial Park, Changning District, Shenzhen City, Guangdong Province, China. Postal Code: 518500
Sales department: +86 0754 8636068 After-sales service: +86 0754 8636068
Website: www.syrna.com
Email: syrna@syrynatoys.com
- The company has the right of final interpretation of this user manual.

- 16-