

## SonicWALL SonicPoint - Model APL13-02C

### **FCC Part 15 Class A Notice**

**NOTE:** This equipment was tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy. And if not installed and used in accordance with the instruction manual, the device may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user is required to correct the interference at his own expense.

Complies with EN 55022 Class A and CISPR22 Class A.

\*Refer to the label on the bottom of the unit for device information including Class A or Class B FCC information.

**Caution:** *Modifying this equipment or using this equipment for purposes not shown in this manual without the written consent of SonicWALL, Inc. could void the user's authority to operate this equipment.*

### **BSMI Statement**

警告使用者：  
這是甲類的資訊產品，在居住的環境中使用時，可能會造成射頻干擾，在這種情況下，使用者會被要求採取某些適當的對策。

### **VCCI Statement**

この装置は、クラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

VCCI- A

## Canadian Radio Frequency Emissions Statement

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe A est conforme à toutes la norme NMB-003 du Canada.

### CISPR 22 (En 55022) Class A

**Warning:** *This is a class A product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures.*

#### **Declaration of Conformity**

Application of council Directive	Directive 89/336/EEC (EMC) and 72/23/EEC (LVD) Directive 1999/5/EC (R&TTE) and standards EN 301 489-1/-17 and EN 300 328-1/-2
Standards to which conformity is declared	EN 55022 (1998) Class A EN 55024 (1998) EN 61000-3-2 (1995) + A1, A2, A14 EN 61000-3-3 (1994) EN 60950 (1992) + A1, A2, A4, A11  National Deviations: AT, AU, BE, CH, CN, CZ, DE, DK, FI, FR, GB, GR, HU, IE, IL, IN, IT, JP, KR, NL, NO, PL, SE, SG, SI

### FCC RF Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimetres (7.9 inches) between the radiator (antenna) and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

For more information regarding the above statement, please contact SonicWALL, Inc. at 1143 Borregas Avenue, Sunnyvale, CA 94089-1306 or 1-408-745-9600.

### Cable Connections

All Ethernet and RS232 (Console) cables are designed for intra-building connection to other equipment. Do not connect these ports directly to communication wiring or other wiring that exits the building where the SonicWALL is located.

### Power Supply Information

If the power supply is missing from your SonicWALL product package, please contact SonicWALL Technical Support at 408-752-7819 for a replacement. This product should only be used with a UL listed power supply marked "Class 2" or "LPS", with an output rated 5 VDC, minimum 1.66 A.

## **Federal Communication Commission Interference Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

### **Canada (IC):**

**To prevent radio interference to the licensed service, this device is intended to be operated indoors and away from windows to provide maximum shielding. Equipment (or its transmit antenna) that is installed outdoors is subject to licensing.**

### **Canada (IC):**


**To prevent radio interference to the licensed service (i.e. co-channel Mobile Satellite systems) this device is intended to be operated indoors and away from windows to provide maximum shielding. Equipment (or its transmit antenna) that is installed outdoors is subject to licensing.**



## Wall Mounting the SonicWALL SonicPoint

Follow the instructions below to mount the SonicPoint on the wall.


1. Using the mounting plate as a template, mark the places to insert the mounting anchors.
2. Using a #2 Phillips screw driver, press the tip of the anchor into the marked places on the hollow wall.



3. Turn the screwdriver clockwise until the anchor is flush with the wall. Repeat for the second anchor.



4. Insert a #6 x 1 1/4" pan head Phillips self-tapping screw into each anchor leaving a gap for the mounting plate.



5. Hang the mounting plate on the screws. Use the middle row of mounting holes.



- Slide the plate down to the narrowest part of the keyhole so that the mounting plate rests on the screws.



- Tighten the mounting screws to secure the mounting plate.



- Snap the SonicPoint onto the mounting plate.



## Mounting the SonicWALL SonicPoint on the Ceiling

1. Locate a metal support to hang the SonicPoint.
2. Using the mounting plate as a template, mark the places to insert the mounting anchors.
3. Drill two holes for #6 x 1-1/4" screws in the marked location.




4. Install the #6 x 1-1/4" self-tapping screws leaving a slight gap for the mounting plate.



5. Hang the mounting plate on the screws.
6. Slide the plate down to the narrowest part of the keyhole so that the mounting plate rests on the screws.



7. Tighten the mounting screws to secure the mounting plate.



8. Snap the SonicPoint onto the mounting plate.



### **Other Considerations for Mounting the SonicWALL SonicPoint**

- Mount in a location away from direct sunlight and sources of heat. A maximum ambient temperature of 104° F (40° C) is recommended.
- Route cables away from power lines, fluorescent lighting fixtures, and sources of noise such as radios, transmitters, and broadband amplifiers
- Ensure that no water or excessive moisture can enter the unit.
- Allow unrestricted airflow around the unit and through the vents on the side of the unit. A minimum of 1 inch (25.44mm) clearance is recommended.



SonicWALL, Inc.  
1143 Borregas Drive  
Sunnyvale, CA 94089  
Tel: (408) 745-9600  
Fax: (408) 745-9300  
E-mail: [info@sonicwall.com](mailto:info@sonicwall.com)  
Web: [www.sonicwall.com](http://www.sonicwall.com)

P/N 232-000512-00  
Rev A. 04/04