

FCC NOTE:

The antenna provided is a unique antenna. By installation of unauthorized antenna to this equipment. Such unauthorized installation could void the user's authority to operate the equipment. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could also void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

©2006 Innovage, Inc.
All Rights Reserved
Printed in China

Imported by:
Innovage, Inc., 19511 Pauling,
Foothill Ranch, CA 92610
The artwork and design of this package are protected by US copyright law and may not be reproduced, distributed, displayed, published or used for any purpose without prior written permission. It is not permitted to alter, remove or reproduce any trademarks or copyright notice from this package.

programmerz

Programmable Remote Control Stunt Car

OPERATING INSTRUCTIONS


Please read this entire manual before operating this product.



CAUTION! ELECTRIC TOY: Not recommended for children under 6 years of age. As with all electrical products, precautions should be observed during handling and use to reduce the risk of electric shock.

ATTENTION PARENTS: It is recommended that this toy and all accessories be periodically examined for potential hazards and that any potentially hazardous parts be repaired or replaced.

PARTS IDENTIFICATION



PROGRAM KEYS AND FUNCTIONS

	LEFT 180°		LEFT 90°
	FORWARD		ROLL FORWARD AND BOUNCE
	REVERSE		SHAKE
	RIGHT 180°		FORWARD AND REVERSE
	FORWARD LEFT		SWING 60°
	FORWARD RUN		ZIG ZAG
	FORWARD RIGHT		PAUSE AND HORN
	REVERSE LEFT		ROTATE 720°
	REVERSE RIGHT	Demo	DEMONSTRATION (MANUFACTURER'S PRE-SET PROGRAM)
	BOUNCE UP AND DOWN	Go	FUNCTION KEY (EXECUTE ACTION)

BATTERY PRE-CAUTION


- Insert batteries according to the correct polarity.
- Do not short circuit battery contacts.
- Remove batteries in remote control and car if they will not be used for a long period of time.
- Check batteries regularly for leakage.
- Exhausted batteries should be removed immediately and must be recycled or disposed of properly according to state or local government ordinances and regulations.
- Do not dispose batteries in a fire - batteries may leak or explode.

BATTERY WARNING:

- Do not mix alkaline, standard (carbon-zinc) and rechargeable batteries (nickel hydride).
- Do not mix old and new batteries.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the item before being charged (if removable).
- Rechargeable batteries are only to be charged under adult supervision (if removable).
- Exhausted batteries are not to be removed.
- The supply terminals are not to be short-circuited.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity (see diagrams below).

KEEP THIS MANUAL FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

BATTERY REPLACEMENT



TROUBLE-SHOOTING

PROBLEM	POSSIBLE SOLUTIONS
Car does not move or run slowly	<ul style="list-style-type: none"> • Make sure power switch on car and transmitter are in the "ON" position • Make sure the batteries in the car and transmitter are installed properly • Replace all exhausted batteries with new "AA" alkaline batteries
Car moves erratically or transmitter range is short	<ul style="list-style-type: none"> • Change locations as there may be radio interference in the area • Move away from other remote control cars as they may be operating on the same frequency • Make sure antenna in transmitter is screwed in tight and fully extended • Make sure transmitter battery connections are in good condition
Car does not work after going through water or snow	<ul style="list-style-type: none"> • Allow car to dry thoroughly for 24 hours • Avoid driving in water or snow

SAFETY PRE-CAUTIONS

- Do not operate during thunderstorms or rain.
- Avoid water, sand and snow when operating your car.
- Do not submerge car or controller in water.
- Never operate your car on the street or highway.
- Never operate your car in a confined or crowded area, and do not use people or animals as obstacles.
- Do not run your car into furniture, objects or hard surfaces, as this will cause damage to both the objects and the car.
- Keep fingers, hair and loose clothing away from the tires, gears and motor while the car is switched to "ON".
- Do not leave car or transmitter near sources of heat or under direct sunlight for long periods of time.
- Do not leave car or transmitter outside overnight. Dampness is harmful to interior components.
- Remove all batteries when not in use to avoid accidental operation.
- Adult supervision is recommended when operating this car.

REMOTE CONTROL TRANSMITTER SET-UP

1. Use a Philips screwdriver to remove the battery compartment cover on the back of the transmitter. Insert 3 "AA" alkaline batteries into the compartment according to the polarity shown. Replace the battery cover.
2. Insert the antenna to the top of the transmitter and screw in tightly.
3. Turn unit to "ON" position (red light appears).
4. Volume switch can be "ON" or "OFF".

CAR SET-UP


1. Use a Philips screwdriver to remove the battery compartment cover from the rear end of the car and slide to the left to open. Slide out the battery tray and insert 4 "AA" alkaline batteries into the battery compartment according to the polarity shown.
2. Insert the battery tray in the compartment with "THIS SIDE UP" facing you and the arrow pointing upward. Put the cover on, slide it to the right and screw tight.
3. Switch the power of the car, located on the rear end bottom, to "ON" position.

OPERATIONS


1. Extend the remote transmitter antenna to the full length.
2. Switch both the transmitter and car to the "ON" position.
3. Operate the car by maneuvering the controls of the transmitter according to the diagrams below to your desired actions. Press any of the function keys and then "GO" key, the car will perform the action accordingly.
4. Four blue buttons are Wheel Control Keys - forward, reverse and turns as shown in the following diagrams.
5. Press "DEMO" and then "GO" keys, the car will perform pre-set list of actions.

NOTE: For maximum performance, hold the transmitter upright so the antenna points up (do not point the antenna at the car, this will reduce the signal range).


WHEEL CONTROL KEYS (BLUE)



WHEEL CONTROL KEYS (BLUE) [CONT'D]



FUNCTION KEYS



FUNCTION KEYS

