

BT-H258

Product Introduction

Earphone multi-function(touch) button



Earphone LED indicator

PRODUCT USER MANUAL

ONE Turn on / Turn off the bluetooth earphone

TURN ON

Method 1: Take out the earbuds from charging case ,the earbuds will turn on automatically. The led indicator will flash red and blue.

Method 2: Touch and hold the MF button for 2-3 seconds .

TURNOFF

Method 1: Touch and hold the MF button for 2-3 seconds to turn OFF the Earphone, the led indicator will flash red rapidly then lights off.

Method 2: Put back the earbuds into charging case ,the earbuds will turn off automatically and start being charging.

Tips: If the earphone without paired any mobile device, the both units will be turn off after 5 minutes; or if the bluetooth distance is beyond 10-12m and without paired any device, the both units will be turn off after 5 minutes

TWO Earphone TV/PS pairing (L & R)

Take out the both earbuds from charging case, it will auto turn on and auto paired with each other. Once paired , the led indicator will flash red & blue quickly.

Tips: If pairing is unsuccessful, Touch and hold the MF button on both Earphone around 5 seconds simultaneously till the led indicator flash blue ONE time; Then turn on both unit again, they will auto pairing.

THREE Pairing TWS Earphone with Bluetooth devices (smart phone,etc)

Activate the Bluetooth function on your mobile device, select the "TWS 5.0" from the list of available Bluetooth devices. Click it to pairing, once earphone paired with mobile device, you will hear a beep tone and the led indicator will off.

FOUR Button function

PLAYING MUSIC

Previous track : Short Press(Touch) the MF button of Left Earphone twice.

Next track : Short Press(Touch) the MF button of Right Earphone twice.

Increase Volume : Short Press(Touch) the MF button of Right Earphone 3 times.

Decrease Volume : Short Press(Touch) the MF button of Left Earphone 3 times.

Pause/Play Music : Short Touch the MF button of either Earphone will Pause/Resume the music.

ANSWER/ END/ REJECT A CALL

Answer incoming call : Short Press(Touch) the MF button of either earphone.

Reject Incoming Call : Press(Touch) the MF button of either earphone for 2 seconds and release.

End a call : Short Press(Touch) the MF button of either earphone after phone conversation.

VOICE ASSISTANT:

Activated the voice assistant : Short Press(Touch) around 1.5 seconds of either earphone to activate the SIRI voice assistant function, only IOS system supported.

Close the voice assistant : After activated, short Press(Touch) around 1.5 seconds of either earphone to close the SIRI voice assistant function, only IOS system supported.

FIVE Charging Instructions

Put the Bluetooth Earphone back into the charging slots correctly and securely to charging.

SIX Care and Maintenance

ATTENTION

1.Please kindly read this user manual before using the product carefully, and keep it for future reference.

2.Please charging the product battery fully when first use.

3.If do not use the product exceed 2 weeks, please charging it.

4.Please only use the supplied cable to charging the product and certified adaptor.

5.If the earphone can not be paired with mobile phone, please check first if the earphone was in bluetooth mode; if the earphone unable paired with mobile phone device, please turn off the earphone first, then turn on and make sure it is in bluetooth pairing mode; If the mobile phone didn't response, please reboot the mobile phone; If the earphone didn't response, please reboot the earphone or recovery default setting.

CAUTION

- Do not use the product at excessive volume levels or long time, as damage to hearing may occur.
- Do not charging the earphone with current exceed 2A, the battery might get damaged.

SEVEN FAQ

Q: Why just only one working?

A: Put the earbuds back to charging case,then take out to check if it is stereo mode,if not please reset the earbuds to settle this problem.

Q: The mobile shows can not connected with the earbuds, how to settle?

A: Deleting the pairing name on your mobile and research the pairing name again to connect.

Q: Why there is no voice with the music and phone call?

A: For android mobile, there is an icon on the right of the pairing name,click it and cancel two audio item then select again.
For IOS mobile,find the setting general function,click it and you can see audio calling mode,select automatic. If it is automatic itself, change into another option first, then select the automatic again. If still have not voice, delete the pairing name research again to pairing.

Q: Why is the video/games delayed?

A: Influenced by the environment,network,mobile edit code speed,will lead to audio data any transfer delays from mobile to earbuds.

Q: Why is the earbuds stop/interrupted?

A: Dear, if you are in a place with many Wi-Fi connects/4G signal/high power appliance interference,may occur stop or interrupt situation, please change a place and reconnect again to solve this problem.

Common sense,get to know!

The Self characteristics of true wireless earbuds,a few of earbuds turn on at the first time,the left and right earbuds cannot pair automatically, at this time,we need to reset these two earbuds.Turn on the two earbuds again with 8-10 seconds,the both earbuds will be paired automatically,(the first time to pair,it needs a little longer time.But next time,it will be paired with one second,after successful of pairing,left earbud will alternately flash by red and blue LED,if not paired, the both earbuds with red / blue LED flashing alternately.

P.S.:When operated by hand,the surround of earbuds cannot with the similar wireless bluetooth products and the device must be in the state of power-on.Or pairing unsuccessfully.

RESET OPERATION:

When the left and right earbuds are on the state of power-on,touch two earbuds together about 8 seconds,until the red and blue LED flash alternately,then continue touch 2 seconds to the red/blue LED flash on second time,the reset is successful.

The earbuds on the state of charging,take out of two earbuds and touch multi-function pad with 8 seconds until the red and blue LED flash alternately,then continue to touch 2 seconds to the red/blue LED flash on second time,the reset is successful.

Clear the pairing record

(if earbuds cannot connected normally,please try with this method.)

If paired before,just search TWS 5.0 in bluetooth list,then get into the setting , choose canceling or ignoring.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.