

SIT50 User Guide

2015 08 05

In the box

CIRCUIT
WIRELESS ACTIVITY TRACKER

BC Bluetooth

Location of controls

- LED Screen
- Mode Button
- Clasp
- Charging Port

Charging

- Open the cover of the charging port.
- Insert the charging pin.
- Plug the USB cable into a computer or a USB power adaptor (not included).

Charging port

Charging pin

Connect to a computer to charge

Modes

Press the **mode button** to toggle through the different modes of the band.

Band display while charging

Band display when fully charged

1 You will see this icon on the band when it is fully charged.
You can also check the battery status of your band on the settings screen of the "Me by Sharper Image" app.

Battery level indicator (Settings)

home screen: 12:00 PM, 00320 steps

distance: 015.0, calories: 0,350

App installation

Launch the Google Play store or iOS app store (Apple devices) on your smartphone or tablet.

1 The device is only compatible with:
• Android devices that run OS 4.3 or later, and that supports Bluetooth 4.0.
• Apple iPhone 4S and later, iPod Touch (5th gen.), iPad 3 - 4, Mini, and Air.

Search for "Me by Sharper Image" on the app store.

Select "Me by Sharper Image"

Pairing & connecting to a Bluetooth® device

Before launching the app, make sure your device's Bluetooth feature is enabled, and the band is charged.

When you open the app for the first time, you will be prompted to connect your device to the band.

- Select "PAIR NOW" as shown below.

2 When the "pairing screen" appears, press the "mode" button of the band.

3 When the band is connected and paired to your device, "connected" is displayed on the bottom of the home screen.

When the band is not connected or paired to device, "disconnected" is shown.

paired screen

mode button

home screen (connected)

home screen (disconnected)

1 The band will disconnect when separated from your device (over 20 ft).

Home Screen

After connecting your device, you will be taken to the home screen where your daily activities will be displayed.

Daily goal

Steps

Calories burned

Distance traveled

Syncing

Swipe down on the home screen to sync the band to the app and update your activity data.

1 About Syncing
1. Make sure that the band is connected to your device when syncing.
2. After using the band, be sure to sync it with your device within 48 hours so that you do not lose your data.

Menu

On the menu screen, you can view activity history, adjust your goal, or access settings.

menu screen

Goal

Your daily goal is set to 10,000 steps by default. You can change the goal by using the arrows as shown below.

my goal screen

You can only adjust the first two digits.

15000

Settings

settings screen

Pair or unpair your band by tapping on band status

1 Updating the software of your band
1. To check for updates, tap "band software" in "settings".
2. If there is an update available, your band will begin updating automatically.

Care & safety tips

Keep the following tips in mind when caring for your Trax band:

- Clean and dry the Trax band regularly, particularly under the band.
- Wipe your Trax band (occasionally) to allow air circulation.
- Use skin care products sparingly on the areas of the wrist covered by the Trax band.

Important Safety Instructions

- Do not expose your Trax band to liquid, moisture, humidity, or rain while charging. Exposure of the Trax band to moisture while charging could result in electric shock.
- Do not temper with or abuse the Trax band. For example, without limitation, do not drop, disassemble, open, crush, stretch, bend, deform, puncture, shred, microwave, incinerate, pierce, or insert foreign objects into the Trax band.
- Do not use your Trax band in areas with high or low temperatures.
- Do not expose your Trax band to direct sunlight for extended periods of time.
- Do not leave your Trax band near open flames such as cooking burners, candles, or fireplaces.
- Do not bring your Trax band into contact with any sharp objects. This could cause scratches and damage.
- Do not insert anything into your Trax band unless otherwise specified in the user instructions. This may damage the internal components.
- Do not attempt to repair, modify, or disassemble your Trax band. It does not contain any user-serviceable components.

Battery Precautions

- Use only the supplied USB Cable to charge the Trax band.
- Only charge the battery in accordance with the user instructions supplied with the Trax band.
- Avoid charging your Trax band in extremely high or low temperatures.
- Do not wear your Trax band while you are charging it.
- Do not attempt to disassemble the Trax band or force open the built-in battery.
- Do not charge the Trax band in damp areas because this could result in electric shock.
- Do not clean the Trax band when it is being charged, always unplug the charger first before cleaning the Trax band.
- Do not clean the Trax band in a fire. The battery could explode causing injury or death.
- Do not dispose of your Trax band in a fire. The battery could explode causing injury or death.

WARNING TO REDUCE THE RISK OF FIRE OR ELECTRICAL SHOCK, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

WARNING TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT OPEN.

WARNING TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVERING FROM THE PRODUCT. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICE TO QUALIFIED SERVICE PERSONNEL.

THE DECLARATION OF CONFORMITY WITH THE CE MARKING. THIS PRODUCT IS IN CONFORMANCE WITH THE REQUIREMENTS OF THE EUROPEAN DIRECTIVE ON THE SUBJECT OF LOW VOLTAGE (LVD) AND THE EUROPEAN DIRECTIVE ON THE SUBJECT OF ELECTROMAGNETIC COMPATIBILITY (EMC).

Legal information

FCC Part 15B
This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15B of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Do not attempt to repair or modify this equipment.
Warning: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15B of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Disabled USB cables must be used with this unit to ensure compliance with the Class B FCC limits.

Battery Dispose & Recycle
This device contains a Lithium-ion battery. The battery must be recycled or disposed of properly. Contact your local waste management office or information on battery recycling or disposal. **801-855-8287**

Distributed by Southern Telecom, Inc. Brooklyn, NY 11232
©2015 Southern Telecom, Inc. All rights reserved. Made in China.

SHARPER IMAGE® name and logo are registered trademarks. Manufactured and marketed by Southern Telecom, Inc. under license to Sharper Image. All rights reserved.

Apple is a registered trademark of Apple Inc., registered in the U.S. and other countries, used with permission.

Google and the Google Play logo are registered trademarks of Google Inc., used with permission.

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc.

Limited Warranty

This Product (including any accessories included in the original packaging) as supplied and distributed here by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

Product Type: Fitness band Warranty: United States / Canada: Labor Warranty: 90 days

To obtain warranty service:

- Call the Customer Support number located below, or go to our website portal to receive an RMA number.
- Provide proof of the date of purchase within the package (dated bill of sale).
- Prepay all shipping costs to the authorized service center, and remember to insure your return.
- Consult the dealer or an experienced radio/TV technician for help.
- Include a return shipping address (no P.O. Boxes), a telephone contact number, and the defective unit within the package.
- Describe the defect or reason you are returning the product.

Customer Support:
877-768-8481 (Toll Free)
Monday - Friday: 8AM - 10PM (EST)
www.southern telecom.com
Click on "Product Support"

To receive Warranty service, the original consumer purchaser must contact Southern Telecom, or an authorized service provider for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the Product is within the applicable warranty period, MUST be presented to distributor, or an authorized service provider of the Distributor, in order to obtain the requested service.
This Warranty covers manufacturing defects in materials and workmanship encountered in the normal, non-commercial use of the product, and does not cover consequential damage, delivery, installation, software issues, set-up, adjustments, cosmetic damage or damage due to acts of nature, accidents, misuse, abuse, negligence, component or modification of or any part of the Product. In addition, this Warranty does not cover "image burn" into the screen.
This Warranty applies to the original consumer only and does not extend to anyone other than the original consumer. This Warranty is void if the factory-applied serial number has been altered or removed from the Product. This Warranty is valid only in the country where the consumer purchased the product, and only applies to products purchased and serviced in that country.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE MADE BY SOUTHERN TELECOM, INC. OR ITS DISTRIBUTORS. OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE, SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT, OR TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT, OR TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT.

SOME COURTESY, TERMS & CONDITIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES OR ALLOW LIMITATIONS ON WARRANTIES, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

