

BTG200


Quick Start Guide

Revision 1.0

Step 1. Please power on BTG200 with provided power adapter. Once properly powered on, the PWR light will stay on with green light.

Step 2. Default IP of BTG200 is 192.168.100.1. Please configure your programming device to 192.168.100.10, connect directly to BTG200 and access via the url below.

<http://192.168.100.1>



The screenshot shows the Mediatek logo at the top, followed by the text "Welcome to LinkIt Smart 7688" and "Please set a password." Below this are two input fields: "Account" with "root (default)" entered, and "Password*" which is currently empty. A "SHOW PASSWORD" link is positioned below the password field. At the bottom of the form is a large orange "SUBMIT" button.

By default, no password is set, please setup root password according to the **Property Installation Worksheet**.

Step 3. Once password is set, please login via the same url

<http://192.168.100.1>



MEDIATEK

Welcome to **LinkIt Smart 7688**.

Account:

root(default)

Password *

.....|

SHOW PASSWORD

SIGN IN

Step 4. Once logged in, please select the Network Tab for Network Configuration.

Welcome to MediaTek LinkIt Smart 7688

For advanced network configuration, go to [OpenWrt](#).

System information

Network

Platform information

Device name

mylinkit

Current IP address

192.168.100.1

Account information

Account

root(default)

Password *

•••••

Step 5. Please select Station Mode, then select with WiFi SSID provided in the **Property Installation Worksheet**.

Welcome to MediaTek LinkIt Smart 7688

For advanced network configuration, go to [OpenWrt](#).

System information

Network

Network setting

 AP mode Station mode Repeater mode

Detected Wi-Fi network *

REFRESH

CANCEL

CONFIGURE & RESTART

Step 6. BTG200 will be restarted after SSID and WPA Key is entered. Please allow 3~5 minutes for restart. The WiFi green LED in the front will blink when properly connected to the internet. If WiFi/NET LED is not blinking, please contact support.

FCC warning

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Notice

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- This class B digital apparatus complies with Canadian ICES-003.
- Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

RF exposure warning

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.