

# User manual 11n+ BT WiFi module (SDIO)

SDIO interface for WLAN

**HS-UART interface for Bluetooth** 

Version: 1.0

Release date: 20160705

**General Specification** 

Model Name	WORD AS ACCUMENT			
	WSDB-104GNI(BT)			
Droduct Name	802.11b/g/n WiFi+ BT IOT module			
Product Name	X SDIO interface for WLAN and HS-UART interface for Bluetooth			
Standards	IEEE 802.11b/g/n/d/e/h/i			
Standards	Bluetooth v2.1+EDR/ v3.0/ v3.0+HS/ v4.1			
	WLAN:			
	802.11b: 11, 5.5, 2, 1 Mbps			
	802.11g: 54, 48, 36, 24, 18, 12, 9, 6 Mbps			
	802.11n: MCS0 to 7 for HT20MHz			
Data Transfer Rate	Bluetooth:			
	Basic rate: 1Mbps Enhanced data rate: 2, 3 Mbps			
	High Speed: 6, 9, 12, 18, 24, 36, 48, 54 Mbps			
	WLAN:			
	802.11b: CCK, DQPSK, DBPSK			
Modulation Method	802.11g: 64QAM, 16QAM, QPSK, BPSK			
	802.11n: 64QAM, 16QAM, QPSK, BPSK			
	Bluetooth: 8DPSK, π/4 DQPSK, GFSKFSK			
	WLAN 2.4GHz:			
	11: (Ch. 1-11) – United States			
Operating Channel	13: (Ch. 1-13) – Europe			
Operating Channel	14: (Ch. 1-14) – Japan			
	BT 2.4GHz:			
	Ch. 0 to 78			
Frequency Range	2.4GHz ISM band (2.400GHz to 2.4835 GHz)			
	WLAN IEEE 802.11b: DSSS (Direct Sequence Spread Spectrum)			
Spread Spectrum	WLAN IEEE 802.11g/n: OFDM (Orthogonal Frequency Division Multiplexing)			
	Bluetooth: FHSS (Frequency Hopping Spread Spectrum)			
	WLAN:			
	17dBm - 802.11b@11Mbps			
	15dBm - 802.11g@6Mbps			
\	15dBm - 802.11g@54Mbps			
RF Output Power	13dBm - 802.11n@MCS0_HT20			
(tolerance ±1.5dBm)	13dBm - 802.11n@MCS7_HT20			
M - # /////				
111/0/1/1/1/1/1/1/1/1/1/1/1/1/1/1/1/1/1	Bluetooth:			
	Output Power: Class1			
	WLAN:			
	Ad hoc mode (Peer-to-Peer)			
	Infrastructure mode			
Ma.,	Software AP			
Network architecture	WiFi Direct			
	BT:			
	Pico Net			
	Scatternet			
	WLAN:			
	-76dBm – 802.11b@11Mbps			
Receiver Sensitivity	-65dBm – 802.11g@54MBps			
	-64dBm - 802.11n@MCS7_HT20			
	Bluetooth:			
	-89dBm@1Mbps			
	-90dBm@2Mbps			
	-83dBm@3Mbps			
OS Support	Windows XP/ Linux/ Android			
Security	WLAN: WEP, WPA Personal, WPA2 Personal, WMM, WMM-PS(U-APSD), WMM-SA, WAPI,			

	BT: Simple Paring
Bus interface	WLAN: SDIO 2.0
	BT: High Speed UART
Operating Temperature	-20 ~ 60° C ambient temperature
	5 to 90 % (non-condensing)
Storage Temperature	-20 ~ 70°C ambient temperature
	0 to 95 % (non-condensing)
Dimension	19 x 12 x 2 mm (LxWxH)



### 1. Power Supply

The CM-43438-V1 module supports SDIO bus power level DC 3.3V, 2.8V or 1.8V. If the voltage level of SDIO bus is DC 3.3V, like most PC or NB, then CM-43438-V1 can be powered by this single DC 3.3V from SDIO bus. But if the voltage level of SDIO bus is DC 2.8V or 1.8V, most the embedded platforms.

SDIO bus power	3.3V	2.8V	1.8V
Supply			
Jumper 4	Short Jumper4	Open Jumper4	Open Jumper4
	(Plug in jumper	(Remove jumper	(Remove jumper
	connector)	connector)	connector)

# WiFi interface and SDIO bus power option

The WiFi interface on CM-43438-V1 is SDIO, and it works under different SDIO bus power conditions such as DC 3.3V, 2.8V or 1.8V.

Please open the connector of J4 to provide an additional DC 3.3V power supply to CM-43438-V1 when it be used under SDIO bus power of DC 2.8V or 1.8V(The additional DC 3.3V is supplied from a PWM circuit from power of micro-USB, so remember to connect DC power into the micro-USB).

Please close the connector of J4 when SDIO bus power is DC 3.3V.



# **Bluetooth interface**

The Bluetooth interface on CM-43438-V1 is through UART, provided signal of UART Tx, Rx, RTS, CTS pins.



## 2. Power on sequence

- 1. Use an USB cable to connect the USB connector of EVB to a PC USB port, to supply DC 5V to EVB.
- 2. Plug in SD adapter into your target platform.
- 3. Your platform will acknowledge the CM-43438-V1 module.

#### **FCC Warning**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### **FCC Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance.

Note 1: Compliance of this device in all final host configurations is the responsibility of the Grantee.

OEM integrators are responsible to satisfy RF exposure requirements. SAR evaluation is valid for portable, mobile and fixed applications.

**Note 2:** Any modifications made to the module will void the Grant of Certification, this module is limited to OEM installation only and must not be sold to end-users, end-user has no manual instructions to remove or install the device, only software or operating procedure shall be placed in the end-user operating manual of final products.

**Note 3:** The device must not transmit simultaneously with any other antenna or transmitter.

**Note 4:** To ensure compliance with all non-transmitter functions the host manufacturer is responsible for ensuring compliance with the module(s) installed and fully operational. For example, if a host was previously authorized as an unintentional radiator under the Declaration of Conformity procedure without a transmitter certified module and a module is added, the host manufacturer is responsible for ensuring that the after the module is installed and operational the host continues to be compliant with the Part 15B unintentional radiator requirements. Since this may depend on the details of how the module is integrated with the host, SparkLAN Communications, Inc shall provide guidance to the host manufacturer for compliance with the Part 15B requirements.

**Note 5:** FCC ID label on the final system must be labeled with "Contains FCC ID: RYK-WSDB104GN I BT" or "Contains transmitter module FCC ID: R YK-WSDB104GNIBT".

The transmitter module must be installed and used in strict accordance with the manufacturer's instructions as described in the user documentation that comes with the host product. SparkL AN Communication, Inc is responsible for the compliance of the module in all final hosts.