


## Packing contents

1. Pedometer
2. AC-DC Power adapter
3. Charging box
2. Wrist strap (Silicon gel)


## Product Overview



### Pedometer


1. Ornamental lens –covers four LED indicators.
2. Contact points for charging

*Note: There is one motor enclosed in the device.*



### Charging box

3. Micro USB port
4. Contact points for charging



### Wrist strap (Silicon Gel)

5. Fixing buckle
6. Slot for holding the unit
7. Positioning holes

## LED Indication

There are four white LED indicators inside the device indicating the battery level and amount of exercise, accompanied with motor vibration:

### 1) Indicating Battery Level

During charging:

When the battery level is less than 25 per cent, the 4 LED will light one by one repeatedly;

When the battery level is between 25-50 percent, LED 1 will keep lighting, with the other 3 lighting one by one repeatedly;

When the battery level is between 50-75 percent, LED 1 and LED 2 will keep lighting, with other 2 lighting one by one repeatedly;

When the battery level is over 75 percent but less than 100 percent, LED 1, LED 2 and LED 3 will keep lighting, with LED 4 blinking;

When the batter level is full, i.e. it reaches 100 percent, the 4 LEDs all will keep lighting before the power adapter is disconnected.

Note:

- a. Once the battery level is less than 20 percent, 4 LEDs will light together;
- b. Once the power adapter is disconnected after the battery has been fully charged, all LEDs will go out immediately.

### 2) Indicating the Amount of Exercise

In the case that you have preset a target amount of exercise on the device:

If only 25 percent of the target amount reached, only LED 1 will light with motor vibrating;

If half the target amount reached, only LED 1 and LED 2 will light with motor vibrating;

If 75 percent of the target amount reached, LED 1, LED 2 and LED 3 will light with motor vibrating;

Once the total target has been reached, 4 LEDs will light for 10 seconds, with motor vibrating.

*Note: In the case that user has set no target amount of exercise, the 4 LED will not respond.*

## Motor Response

- 1) Target reached: If the preset target amount of exercise has been reached, the motor will vibrate briefly 3 times, indicating that user should stop after 3 cycles, with the 4 LEDs keep lighting for 10 seconds.
- 2) Battery level too low: once the battery level is too low, the motor will keep vibrating for 2-3 seconds, and the device will shut down automatically.

## About the Sensitivity and Reliability

1. High Sensitivity- Suitable for vigorous exercises or sports;
2. Medium Sensitivity (default) - Suitable for normal exercises by ordinary people.
3. Low Sensitivity – Suitable for gentle exercises.

Note: The sensitivity should be judged based on the extent of adaptation.

### FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio

frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

C €2200