Thank you for purchasing Memobird, a mini printer developed by Xiamen Intretech Inc. that can transfer notes. **Box Contents**










Quick Start Guide x1

Product Information

Product: Memobird Model Number: MEMOBIRD GT1 Dimensions: 40*79*79mm Print Type: Thermal Print Supply Specifications: 57*25mm (Standard Specifications) Battery: Internal 900mAh lithium battery Voltage: 5.0V===1A Charging Port: Micro-USB

Installation

1 On initial use, press and hold the power button on your Memobird for 2 seconds; once turned on, the Memobird will automatically print a welcome note.



Note Download and install the Memobird APP. Open the app and allow related authorizations, then register and login Exterior



Follow the steps in the APP to bind your device: use the

QR code printed after double pressing the printer's

power button to bind your device. Once bound, use

bluetooth pairing to connect. Once connected, you can

Pair with bluetooth

 Press and hold for 2 seconds to turn on/off: Press and hold the power button then plug in power source for recovery.

Charging Before initial use, please plug in the USB cord and charge

normal operation.

Power Button

your Memohird: If a red light is flashing on the power button, it means the printer is low on power; please plug in to charge to ensure

Paper Dispenser

- Power Button

USB Socket

Power Button Flashing Notifications:

During use Green light: Normal operation Flashing green light: Printing Red light: Abnormal status (no paper/overheated) Flashing red light: Low power (less than 20%)

When charging: Slow flashing red light: Charging Green light: Fully Charged, normal operation

Paper Replacement:

- Remove paper cartridge Tip the button
- ② Push outward to remove paper cartridge.



- Change printing paper ① Lightly press the latch
- 2 Push the lid to open it



3 Install the new paper according to the direction. (Attention: Paper must be coming out 2cm from cartridge)



Press power button and replace cartridge back into



Make sure the printer is on.

Memobird Warranty Card

Product Details: MEMOBIRD GT1 Warranty Period: 1 year Customer Information:

Customer Name			
Gender	∘Female	∘Male	
Contact Method			
E-mail			
Address:			
Retailer			
Purchase Date			
Order Number			

- The warranty card is effective with the stamp (stamp of retail distributor) of a retailer approved and licensed by Xiamen Intretech Inc.: Please carefully read the warranty guidelines;
- Please store and keep this warranty card in a safe place.

Memobird Warranty Service

Consumers who have purchased a Memobird through a legal channel can have the service commitment of "Repair/Refund/Replace" (referred to as the "Three Guarantees") in the event of any non-human error damages.

- Within 7 days from signing for the package, if the product malfunctions due to non-human damages, consumers may choose to return the product, exchange for a Memobird of the same model and specifications, or repair:
- Within 8-15 days from signing for the package, if the product malfunctions due to non-human damages, consumers may choose to exchange for a Memobird of the same model and specifications, or repair:
- Within 12 months from signing for the package, if the product malfunctions due to non-human damages. consumers may have free repair services.

Actions that Void Warranty

- Unlicensed repair/misuse/impact/neglect/abuse/water damage/accident/modifications/incorrect use, or ripping/altering labels;
- 2 The "Three Guarantees" period has expired:
- Malfunctions due to human damage.

Frequently Asked Questions

Q: When adding the device in my APP, I can't find a Memobird to connect with?

A: Try charging the printer to ensure the bluetooth is

Q: My Memobird won't print, what do I do?

- A: 1 Verify if bluetooth is toggled on in your smartphone and make sure that no one else is connected to your
- 2 Check if there's no more thermal paper and change printing paper:
- Check if your printer is overheated; if so, please wait for it to cool before you resume printing.
- 4 Restart the device. If your problem persists, press and hold the power button then plug in the power cord to enter recovery:

6 E-mail to customer service: ydkf@intretech.com

Q: Why is it printing white paper without any content? A: This may be caused by incorrect installation of printer paper; please try placing the paper on the reverse side.

Warning:

- . Do not expose the battery to excessive heat, such as sunlight or fire:
- Do not use the product in rain or humid environments; do not remove or replace the battery:
- . If you believe there is an issue with your battery, please contact after sales service center for assistance.
- Replacing and using incorrect battery models carry the risk of explosion, please dispose of used batteries according to instructions:
- (!\sum 70°C (The maximum printing temperature of the printer is 70°C, please refrain from touching:
- Be careful when ripping the paper as the sides of sharp, please refrain from touching.

FCC Statement

to your account.

begin to print.

Double press the power

button to print QR code

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by

turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

-Reorient or relocate the receiving antenna.

specific absorption ration

- -Increase the separation between the equipment and
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.
- This equipment complies with FCC radiation exposure limits set forth for uncontrolled equipment and meets the FCC RF exposure guidelines . This equipment has very low levels of RF energy that are deemed to comply without testing of
- FCC RF Radiation Exposure Statement (Greater than 20 cm distance between users and equipment)

IC Statement

This device complies with Industry Canada license-exempt RSS standard(s). Operation is

- subject to the following two conditions:
- (1) this device may not cause interference, and (2) this device must accept any interference, including
- interference that may cause undesired operation of the Le présent appareil est conforme aux CNR d'Industrie
- Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :
- (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique
- subi, même si le brouillage est susceptible d'en compromettre le fonctionnement. This equipment complies with Canada radiation exposure
- limits set forth for uncontrolled environments. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Service Details:

Customer Service E-mail: ydkf@intretech.com Memobird Official Website: www.memobird.shop Manufacturer: Xiamen Intretech Inc. Address: No.588, Jiahe Rd., Xiamen, Fujian Province, China

Quick Start Guide