

o9o

Quickstart
Guide



swisscom

Table of Contents

Table of Contents	2
Welcome!	4
Getting to Know Your Ogo	5
External Parts.....	5
External Keys.....	6
Identifying the Keyboard Functions	7
Shortcut Keys.....	8
Navigation Keys	8
Text Keys	9
Getting Started	10
Installing the Battery.....	10
Charging the Battery	10
Powering On Your Ogo	10
Using the Messaging Wizard.....	11
Using the Home Screen	11
Using the Application Selector	12
Using the Ogo as a Phone	12
Bluetooth Pairing instructions	12
Data Sheet	13
Using the Mailbox	15
Accessing the Mailbox.....	15
Using the <i>Compose</i> Screen	15
Saving a Draft of a Message	18
Deleting the Draft of a Message.....	19
Instant Messaging (IM)	20
Accessing the <i>IM</i> Screen.....	20
Identifying IM Contacts Status Icons	21
Reading and Composing IM Chat Messages.....	21
Using the Phone	24
Accessing the Phone Screen	24
Receiving an Incoming Phone Call	25

Ending a Phone Call	26
Muting a Phone Call.....	26
Dialing an Outgoing Phone Call	27
Using the <i>My Status</i> Screen	29
Accessing the <i>My Status</i> Screen.....	29
Logging On/Off or Signing In/Out	29
Changing Your IM Status	30
Adding a New IM Account or E-mail Account.....	30
Removing an E-mail Account	31
Using the <i>News</i> Screen.....	33
Adding News Feeds	33
Accessing News Feeds	34
Using the <i>Extras</i> Screen	36
Viewing Games	36
Viewing Technical Support Information	37
Setting Your Preferences	39
Accessing the <i>Settings</i> Screen.....	39
Setting Phone Preferences	40
Setting IM Preferences.....	41
Setting E-mail Preferences.....	41
Setting Device Preferences.....	42
Setting Sounds.....	45
Setting the Time and Date.....	46
Setting Network Preferences.....	47
Setting System Preferences.....	48

Welcome!

Thank you for joining the Ogo community!

Ogo is all about connecting, creating and sharing with anyone, from anywhere, all the time. You can flirt, chat, rant or sweet-talk from the bus, the bar or a park bench.

Read on to see how to get started!

For all things Ogo and staying in touch with other Ogolovers, go to <http://www.ogo.com>.

Getting to Know Your Ogo



External Parts

Part	Description
External LCD	Displays time, messages and status information when the flip cover is closed.
Earpiece and Microphone	Lets you conduct a phone call when the flip cover is closed.
Ogo Clip	Can be replaced by any of the Ogo Clip accessories.
USB Charger Socket	Connects to the provided USB cable for charging the device.
Headphone Socket	Connects to the provided headphones

External Keys

Key	Name	Description
	Call	Press this key to accept an incoming call or to switch between the active call and the call on hold. When no call is active, press this key to see the list of dialed calls, or to initiate a call to the highlighted item.
	End	Press this key to hang up the active call or to reject the incoming call.
	Vol +	Use these keys to adjust the speaker or headphone volume during a call or to adjust the ringer volume when no call is active. You can silence the Ogo by pressing and holding the Vol - key
	Vol -	

Identifying the Keyboard Functions




Figure 1: Ogo Keyboard

Shortcut Keys

Key	Name	Description
	Power On/Off	Powers your Ogo on and off.
	Mailbox	Shortcut to your Inbox, where you can see incoming email and text messages.
	Instant Messaging	Shortcut to the Instant Messaging screen where you can chat with your contacts.
	Compose	For writing a new email or text message.
	Home	Returns to the Home screen.
	Ogo	Displays a list of current chats, unread and draft email and text messages.

Navigation Keys

Key	Name	Description
	Application Selector	Press this key to display the Application Selector, which enables you to navigate to any application, from anywhere in the Ogo.
	Scroll Wheel	Rotate the Scroll Wheel in either direction to change the selection or to move the text cursor when editing text.
	Scroll Wheel Button	Press the button in the center of the Scroll Wheel to select the highlighted item.
	Outer Arrows	<p>Press the:</p> <ul style="list-style-type: none"> Left and right arrows to move between tabs. Up and down arrows to scroll one page at a time (page up/down). <p>In a text message, press the:</p> <ul style="list-style-type: none"> Left and right arrows to move to the beginning and end of a line of text. Up and down arrows to move to the beginning and end of a message.

Key	Name	Description
	Inner Arrows	Press the: <ul style="list-style-type: none">Left and right arrows to scroll left and right within a screen or a line of text.Up and down arrows to move between lines in a screen or the lines of text in a message.
	Enter	Press this key to activate the highlighted item on the screen.
	Back	Press this key to go to the previous screen. Pressing this key also closes any element open on top of the main screen, such as a menu or a pop-up window.
	Options	Opens the Options menu for the current screen, if available.

Text Keys

Key	Name	Description
	Letter Keys	Inserts letters, numbers and other symbols. A long press on an accented letter key opens a palette with the available accented options, such as: "Ã Ä Å".
	Capitalize	Shifts the letter keys to capitals. For example, press CAP and then the A key to type an uppercase "A". Pressing the A key without CAP types a lowercase "a".
	Alternate	Shifts the letter keys to the symbol located above the letter on the key. For example, press the ALT key and then the A key to insert "&".
	ALT + Spacebar	Pressing ALT together with the spacebar opens a symbol palette that enables you to insert special characters into your email or text messages.
	Emoticons	Opens an emoticon palette that enables you to insert emoticons into your text messages.
	Clear	Deletes the highlighted item in a list. Deletes the last character or emoticon inserted in a text field.

Getting Started

Installing the Battery

- 1 Turn your Ogo over and remove the back cover.
- 2 With the battery label facing up, match the battery contacts with the contacts in the battery slot. Push the battery in, with the contacts side down first, as shown below:



Figure 2: Installing the Battery

- 3 Push the other side down to slide the battery into place.
- 4 Replace the back cover.

Charging the Battery

Connect the charger's power plug to the charging socket on the front of your Ogo (Figure 3). Charge your Ogo for 12 hours.



Figure 3: Connecting the Charger

Note: Make sure that the battery has been properly installed before charging or powering on your Ogo.

Powering On Your Ogo

After your Ogo is fully charged, press the Power On/Off key  until the startup animation appears on the screen.

Using the Messaging Wizard

Once your device is powered on for the first time, the Messaging Wizard screen appears. Follow the instructions displayed by the Messaging Wizard to set up your Instant Messaging and email accounts.

Using the Home Screen

Once you have configured your Ogo with your instant messaging and email accounts, the Home screen (Figure 4) appears. This is the screen that is displayed each time you power on.




Figure 4: Home Screen

Each icon represents one of the Ogo's applications. Use the arrow keys or the Scroll Wheel to highlight the desired icon. The name of the application is shown at the bottom of the screen.

Press **ENTER** to open the selected application. You can always return to the Home screen by pressing Back key () several times.

Tip: To initiate a call, you can start dialing from the Home screen.

The following describes the Ogo applications:

Application	Enables you to...
Status bar (top of screen)	See current application and message indications and device status.
Mailbox	Read, write and manage email and text messages.
Compose	Write and send email and text messages.
Instant Messaging (IM)	Chat with your IM contacts.
Browser	Surf the Web. The Homepage provides useful Internet functions and services.
News	Read latest news via RSS feeds.
Calendar	Manage your appointments from a daily, weekly or monthly view.
Contacts	Manage your contacts and to store contacts' phone numbers, email and other addresses.
Phone	Make phone calls, view missed calls and previously dialed and received calls.

Application	Enables you to...
Extras	Play games and find contact information to Ogo's technical support.
Settings	Choose a ring tone, set the date and time and configure all of the Ogo options according to your preferences.

Using the Application Selector

From any application you can quickly navigate to another application by pressing the Application Selector key. A list of applications is then displayed, as shown below:



Figure 5: Application Selector

Use the Scroll Wheel to highlight the desired application and then press the Scroll Wheel's button (or press **ENTER**) to go there. You can also press the Application Selector key again, to navigate into the sub-menus of the highlighted application.

Using the Ogo as a Phone

You have several options for using the Ogo as a phone:

- When the flip is closed, hold the device so that the earpiece is next to your ear and the microphone is placed near your mouth. Accept or Reject incoming calls using the external keys.
- When the flip cover is open and no headset is connected, your Ogo is in speakerphone mode. Use the navigation keys to access all phone options.
- Alternatively, you can use the wired headset provided in the package or use any Bluetooth headset, after pairing it with the Ogo, as described below.

Bluetooth Pairing instructions

To pair a Bluetooth device with your Ogo, navigate to **Settings** (marked by), and navigate to the **Device** tab. Scroll to the bottom of the tab and press **ENTER** when the item **Bluetooth settings** is highlighted. In the displayed window, select **Search for devices**, after turning on your Bluetooth device. Ogo will scan for Bluetooth devices and offer you the option to pair after it detects your device.

Data Sheet

QVGA display, stereo speakers & QWERTY keyboard

- Instant Messaging with MSN & ICQ
- Push Email
- Integrated phone
- Multimedia player with removable microSD memory
- HTML Web Browser
- RSS reader
- **CDMA2000 1xEV-DO(Rel.0), Dual** band, Bluetooth 2.0, optional WiFi(will be tested later not now)
- Contact & Calendar—synchronized OTA, Bluetooth or USB
- And...OgoClips, keep expanding your Ogo...

IM—MSN and ICQ built-in; other communities can easily be supported

- Email—push Email supporting POP3, IMAP4, SSL, MS Exchange server, and MSN Hotmail—supports multiple Email accounts simultaneously
- Phone application—fully integrated and with speakerphone
- Multimedia—video, music, ring tones and DRM
- Email attachments—Images, PDF, DOC, TXT, PPT and more, with data traffic optimization
- Java—full support of Java applications
- SMS—fully integrated with Email application
- Browser—HTML and WAP
- RSS—dedicated reader with configurable channels
- Calendar and Contacts
- Synchronization—Over-the-Air, Bluetooth or USB

Size [mm] 118 (L) x **72.5 (W)** x 21 (H)

Weight [g] 150

Keyboard 5 row QWERTY or QWERTZ

Navigation 8-way navigation, menu selection

wheel, application hard

keys, talk/end & volume

Display QVGA 320x240 TFT **262k** colors

Sub display 132x32 pixels, mono STN

Memory **64MB** RAM, **128MB** Flash

Connectivity Bluetooth 2.0, GPS, optional WiFi

(802.11 B/G) on **OGO2.0**

Wireless **CDMA2000 1xEV-DO(Rel.0) Dual** band

Cellular bands/PCS bands

Battery life **2hr** talk time, 160hr standby time

Removable memory microSD

Connectors Mini-USB (charging and synchronization),

stereo 2.5mm

headset connector

Using the Mailbox

The *Mailbox* screen lets you see and manage your e-mail and SMS/text messages. If you see a number displayed in the Mailbox icon (錯誤! 找不到參照來源。), you have new or unread e-mail or SMS/text messages.

Before you can send an e-mail message, you must first set up an e-mail account with a portal provider. If you have not set up an e-mail account during registration, you see "SMS Only" in the *From* field on the *Compose* screen.

For information about setting up an e-mail account, see [錯誤! 找不到參照來源。](#) on page [錯誤! 尚未定義書籤。](#).

E-mail messages can contain up to 4000 characters, including spaces. SMS/text messages are limited to 600 characters, including spaces.

Note: SMS messages may be referred to as *Text messages*; your SMS number may also be referred to as your *Text number*.

Accessing the Mailbox

You can access the *Mailbox* screen in two ways:

- From the *Home* screen, select the *Mailbox* icon and press **ENTER**.
- Press the *Mailbox* key.

The *Mailbox* screen (錯誤! 找不到參照來源。) displays four default tabs and in addition, a tab for each e-mail account you add. The *Inbox* tab is selected by default. Each of the other tabs displays a single category of messages – all messages for a single e-mail provider, all SMS/text messages, all outgoing messages, etc.

Using the *Compose* Screen

Accessing the *Compose* Screen

You can access the *Compose* screen in two ways:

- Press the *Compose* key.
- From the *Contacts* screen, in the following manner:
 1. From the *Home* screen, select the *Contacts* icon (Figure 6) and press **ENTER** to display the *Contacts* screen.




Figure 6: Identifying the Contacts icon

2. Scroll to highlight the contact you wish to send an e-mail to and press the Options key; an *Options* pop-up window will appear (錯誤! 找不到參照來源。).
3. Make sure that Compose is highlighted and press **E N T E R**; a blank *Compose* screen with that contact's e-mail address already inserted into the *To* field will appear.

Sending an E-mail or SMS/Text Message

1. Access the *Compose* screen (錯誤! 找不到參照來源。) as described on page 15.
2. Add an address to the *To* field; do one of the following:
 - Type the e-mail or SMS/text address in the *To* field.
 - With the cursor in the *To* field, long press **ENTER** and then select the desired contact and address from your contact list.

Notes:

- If you accessed the *Compose* screen through *Contacts*, the recipient's e-mail address will already appear in the *To* field.
 - You can send the same message to both e-mail and SMS/text addresses.
3. Use the inner ring of the 8-Way Navigation key to move to the *Subject* field and then type the subject of your message.
 4. Scroll to the message text box and type your message.

Note: E-mail messages can contain up to 4000 characters, including spaces. SMS/text messages have a limit of 600 characters (up to 4 concatenated messages), including spaces.

Optional: You can also use accented Latin characters commonly used in European languages with your Ogo's Extended Character palette. For more information, see [錯誤! 找不到參照來源。](#) on page [錯誤! 尚未定義書籤。](#)

5. Scroll to select *Send* and press **ENTER**.

*Note: You can also press the Options key, select *Send* (錯誤! 找不到參照來源。), and press **ENTER** to send your message.*

For more information on addressing e-mail or SMS/text messages, see [錯誤! 找不到參照來源。](#) on page [錯誤! 尚未定義書籤。](#)

Note: An e-mail message can include up to 4000 characters. E-mail messages that exceed this limit trigger the following pop-up window: "This message exceeds the maximum allowed text limit and will be trimmed accordingly."

Choosing an E-mail Address in the *From* Field

If you have more than one e-mail account, you can choose the address from which you want to send your message.

1. On the *Compose* screen, select the *From* field and press **ENTER**.
2. Select the e-mail address for the message and press **ENTER**; your message now reflects the new address in the *From* field.

Changing Your Default E-mail Address for Sending Messages

When composing an e-mail message, your default e-mail address (in the *From* field) is the address of the first (or the only) e-mail account you originally set up on your Ogo.

If you have more than one e-mail account and want to change your default e-mail address:

1. From the *Home* screen, select *Settings* and press **ENTER**.
2. Select the *E-mail* tab.
3. Select the name of the e-mail account you want to make your default account and press **ENTER**.
4. In the *Mailbox Settings* screen scroll down to select the *Default Account* checkbox.
5. Press **ENTER** to select the checkbox.
6. Scroll down to select *Done* and press **ENTER**; your *Compose E-mail* screen now lists the new default address in the *From* field.

Sending SMS/Text Messages

If all of the recipient addresses for your message are mobile phone numbers, your message is sent as an SMS/text. The *From address* that the recipients see is your SMS/text (also called MSISDN) number. The *From address* you see when sending the message from your Ogo is your default e-mail address.

Saving a Draft of a Message

After composing a message, if you want to save it as a draft; press the Options key, select *Save as draft* and press **ENTER**.

You can find your draft later by pressing the Mailbox key.

In the *Inbox* message list, drafts are indicated by the draft icon:

Note: You can also quickly save your draft while in the Compose screen by pressing the Up key. The Save draft? pop-up window appears asking you if you want to save changes to the draft (錯誤! 找不到參照來源。); select Yes to save.

Deleting the Draft of a Message

If you decide not to keep a draft message, perform one of the following operations:

- While composing a message, press the Options key and select *Delete this message*. Press **ENTER** to delete; a pop-up window appears asking you to confirm that you want to delete the message.
- From the *Mailbox* screen, select the message and press the Options key. Select *Delete this Message* and press **ENTER**.
- Press the Ogo key, select the draft message to be deleted, and press **CLR**.

Instant Messaging (IM)

The *IM* screen allows you to chat with your IM contacts in MSN. The number displayed in the *IM* icon indicates the number of open chat sessions (read and unread).

Accessing the *IM* Screen

You can access the *IM* screen in two ways:

- From the *Home* screen, select the *IM* icon and press **E N T E R**.
- Press the Instant Messaging key.

Note: You may be prompted to log on; sign in if you have not already done so.

Your IM contacts are displayed in the *IM* screen (錯誤! 找不到參照來源。). Each line shows the contact's alert icon (if applicable), contact's screen name, and IM status (*Away*, *Online*, etc.).

You can IM chat with an IM contact by pressing **E N T E R** when an IM contact's name is selected.

Note: The maximum number of active IM chats is 20.

When one of your contacts sends you an instant message, you receive an *IM Chat* alert next to that contact's online status indicator. *IM Chat* alerts are animated if the IM chat message is unread.

Identifying IM Contacts Status Icons

You can identify the presence of your IM contacts by simply looking at the IM status icon located on the IM screen. Table 1 describes the various IM contact status icons that may appear.

Table 1: IM contact status icons

Icon	Name	Description
	Online	Indicates that your contact is connected to the IM community and is available for an IM chat.
	Busy	Indicates that your contact is connected to the IM community, but may or may not be readily available to respond to an instant message you send.
	Be Right Back	Indicates that your contact is connected to the IM community, but is momentarily unavailable.
	Away	Indicates that your contact is connected to the IM community, but is temporarily unavailable.
	On the phone	Indicates that your contact is connected to the IM community, but is using the phone, and may or may not respond to your instant message.
	Out to Lunch	Indicates that your contact is connected to the IM community, but is out to lunch.
	Offline	Indicates that your contact is not connected to the IM community, and is unavailable for instant messaging.
	Blocked	Indicates you have blocked this contact. You appear offline to blocked contacts.

Reading and Composing IM Chat Messages

Accessing IM Chat Messages Using the Ogo Key

An easy way to read and respond to IM chat messages is to use the Ogo key. You can press this key at any time to access a list of your current IM chats, as well as recent e-mail and SMS/text messages. For more information about the Ogo key see [錯誤! 找不到參照來源。](#) on page [錯誤! 尚未定義書籤。](#).

Sending an Instant Message (Starting an IM Chat Session)

1. Press the Instant Messaging key, or select *IM* from the *Home* screen and press **ENTER**.
2. Select the screen name of the contact with whom you want to IM chat. Make sure that the contact is available. Press **ENTER** to open an IM chat window.

3. Type your message.
4. Select *Send* and press **E N T E R** to send your message.

Note: You cannot IM chat with a contact who is offline. For MSN, a Compose message screen opens so that you can e-mail the offline contact.

Adding Emoticons to Your IM Chat

You can use the set of emoticons supported by MSN to personalize your IM chat messages. Emoticons can be used only in IM chat sessions.

1. Press the Emoticon key. An emoticon palette appears (for example, see [錯誤! 找不到參照來源。](#)).
2. Using the 8-Way Navigation key, select the emoticon you want, and press **E N T E R** to insert it. You can also insert the selected emoticon by pressing the corresponding letter key on your Ogo's keyboard.

Emoticons appear in the view message section (upper portion) of your IM chat screen.

*Note: For MSN emoticons, **A L T** toggles between emoticon palettes.*

For a list of emoticons, see [錯誤! 找不到參照來源。](#) on page [錯誤! 尚未定義書籤。](#) .

Closing an IM Chat Session

You can close an IM chat session in the following ways:

- **Ogo key:** Press the Ogo key to display the Ogo pop-up window. Then select the IM chat session and press **C L R** .
- **Options key:** While in an IM chat session, press the Options key, select *Close Chat* and press **E N T E R** .

IM chat sessions are automatically closed under the following circumstances:

- **Log Off/Sign out:** log off or sign out of MSN from the *Options* menu to close all open IM chat sessions.
- **Power off:** all chat sessions are closed when you power off.
- There is no IM chat activity from either IM contact in a 24-hour period.
- The maximum number of active IM chats (20) is reached.

Using the Phone

The *Phone* screen allows you to make phone calls, view phone numbers previously dialed, call received and missed calls. If you see a number displayed in the *Phone* icon, you have that many waiting voice messages.

Note: You must have a Bluetooth headset paired with your Ogo in order to use the device as a cellular phone. For more information see 錯誤! 找不到參照來源。 on page 錯誤! 尚未定義書籤。.

Accessing the Phone Screen

You can access the *Phone* screen by selecting the *Phone* icon from the *Home* screen and pressing **ENTER**.

The following tabs are available in the *Phone* screen:

Dial – enter a phone number and place the call.

Dialed – a list of the recently dialed numbers.

Received – a list of phone numbers from which phone calls were received. If a call was from someone in your contacts list, the name will appear.

Missed – phone numbers (or names) of calls that were not answered.

Timers – measured times of selected call parameters.

Receiving an Incoming Phone Call

When a call comes in to your Ogo, a pop-up window will appear asking if you want to *Accept* the call, *Reject* it or *Silence* it (錯誤! 找不到參照來源。):

Press **ENTER** to accept the call; the connection will be made and an *Incoming Call* screen will be displayed showing the caller's name or phone number, and a call-duration timer (錯誤! 找不到參照來源。):

Caller's name or number:

- The caller's name will be displayed if the incoming call is from a number who is listed in your Ogo *Contacts* list.
- The caller's phone number will be displayed if the caller is not listed in the *Contacts* list.
- *Private number* will be displayed if the caller's *Own number sending* option is blocked.

Other options for incoming calls:

- **Reject** ends the incoming call before it is answered and lists it in the *Received calls* tab.
- **Silence** stops the ring and displays a pop-up window showing the call's origin and offering the *Accept*, *Reject* and *Silence* options.

Ending a Phone Call

To end a phone call press the **ENTER** button; a *Call options* pop-up window will appear in the *Call* screen :

Hang Up is the default option in the pop-up window. Press **ENTER** again to end the call; the *Dial* screen will be displayed.

Muting a Phone Call

To mute a phone call (disable the Ogo's microphone so the other party cannot hear you):

1. Press **ENTER** and scroll down to the *Mute* option in the *Call options* pop-up window (錯誤! 找不到參照來源。).
2. Press **ENTER** again; the pop-up window will disappear and a *Muted* flag will be displayed on the *Call screen* (錯誤! 找不到參照來源。):

To Unmute the call (re-enable the Ogo's microphone):

1. Press **ENTER** and scroll down to the *Unmute* option in the *Call Options* pop-up window.
2. Press **ENTER** again; the *Muted* flag will disappear and you may resume the conversation.

Dialing an Outgoing Phone Call

Dialing a New Phone Number

When you want to call a phone number that is not recorded in your *Contacts*, proceed as follows:

1. Access the *Phone* screen by selecting the *Phone* icon from the *Home* screen and pressing **ENTER**.
2. Type the phone number on the Ogo's keypad; the number will appear as typed in the *Dial* screen's *Dialed number field*. Type the phone number as an uninterrupted string with no spaces. The +, * and # characters may be used when necessary.

*Press **ENTER** to initiate the call. When the call is answered the Outgoing Call screen will be displayed, showing the number being called and the call duration timer.*

Using the *My Status* Screen

From the *My Status* screen you can log on/off or sign in/out and change your IM status.

The *My Status* screen shows whether you are online and available. Use the outer ring of the 8-Way Navigation key to switch between the *IM* and *E-mail* tabs.

Accessing the *My Status* Screen

From the *Home* screen, select the *My Status* icon (錯誤! 找不到參照來源。) and press **ENTER** to display the *My Status* screen (錯誤! 找不到參照來源。).

Logging On/Off or Signing In/Out

1. Press the Options key.
2. Select *Log on/off* and press **ENTER**.

Changing Your IM Status

Note: You must be signed into MSN to change your IM status.

1. From the *Home* screen, select *My Status* and press **ENTER**; the *My Status* screen appears (錯誤! 找不到參照來源。).
2. Select *MSN* and press **ENTER**.
3. From the status pop-up window select the status you want and press **ENTER**.

To change your IM status when your Ogo is closed:

1. From the *Home* screen select *My Status* and press **ENTER**.
2. Select *When Closed* and press **ENTER**; the selections include:
 - *No Change* (default setting)
 - *Away*
 - *Busy*
 - *Be Right Back*
3. Scroll to select the status you want and press **ENTER**; your *IM status when Ogo is closed* is set.

Adding a New IM Account or E-mail Account

1. From the *Home* screen select *My Status* and press **ENTER**.
2. Select either the *IM* tab or the *E-mail* tab.
3. Press the Options key, then select *Add IM (or Add E-mail) Account* and press **ENTER**; you are taken to the *Messaging Wizard*.
4. Provide the requested information to set up your new account. See [錯誤! 找不到參照來源。](#) on page 錯誤! 尚未定義書籤。 for step-by-step information.

Removing an E-mail Account

1. From the *Home* screen select *My Status* and press **ENTER**.
2. Use the outer ring of the 8-Way Navigation key to select the *E-mail* tab.
3. Press the Options key, then select *Remove E-mail Account* and press **ENTER**; the *Account Summary* screen appears.
4. Select the e-mail account you want to remove and press **ENTER**.
5. Select *Next* and press **ENTER**; a message appears indicating that the account has been removed.
6. Select *Finish* and press **ENTER** to return to the *My Status* screen.

Note: If you want to delete your IM account, you must use the Settings menu (Settings > IM > Remove).

Using the *News* Screen

From the *Home* screen select the *News* icon (錯誤!找不到參照來源。) and press **E N T E R** to display the *News* screen (錯誤!找不到參照來源。).

News Reader provides a simple and intuitive interface for receiving updates from web sites featuring standard RSS feed. The user can monitor several feeds concurrently.

Adding News Feeds

The first time you access the *News Reader* window, you are asked to contact Customer Care or browse the web site in order to obtain news feeds. You can select the news bundles that interest you, and they will be automatically provided to your Ogo.

To activate new news feeds, power up your Ogo and select *Check for updates* on the *System* tab of the *Settings* screen. Your Ogo will display a pop-up notification that news channels were successfully configured on the device.

Accessing News Feeds

The *News Reader* screen (錯誤! 找不到參照來源。) may contain several tabs, depending on the number of news feeds you have configured. Each of the other tabs displays a single category of news.

Green envelope icons indicate unread items and pink envelope icons indicate items that have been read.

Select a news item and press **ENTER** to read it.

Using the *Extras* Screen

From the *Home* screen select the *Extras* icon (錯誤!找不到參照來源。) and press **ENTER** to display the *Extras* screen.

From the *Extras* screen you can access technical support information and play games on your Ogo.

Use the outer ring of the 8-Way Navigation key to switch between the *Games* and *Tech Support Info* tabs.

Viewing Games

The *Games* tab (錯誤!找不到參照來源。) provides access to games that are available on your Ogo.

Select a game and press **ENTER** to start it.

The Blocks Game

The Blocks game comes pre-installed on your Ogo. In this game, you rotate shapes as they fall so that they fit together with as few spaces between them as possible.

Table 2 shows the keys that can be used to play the Blocks game.

Table 2: Blocks Game Controls

Control	Functionality
A, Z, Left (inner ring)	Move a piece to the left
L, " Right (inner ring)	Move a piece to the right
S,X,K,M, Up (inner ring), Page Up (outer ring)	Rotate a piece
Space, Down (inner ring), Page Down (outer ring)	Drop the piece, or Un-pause a paused game
P	Pause or Un-pause an active game

Viewing Technical Support Information

The *Tech Support Info* tab (Figure 7) displays Ogo's technical support phone number and Internet contact information.

Note: Tech Support Info screens may vary by carrier. Figure 7 represents an example of a Tech Support Info screen that you may see.



Figure 7: Tech Support Information tab

Setting Your Preferences

You can control many aspects of how your Ogo looks, sounds and behaves by customizing the settings.

Accessing the *Settings* Screen

From the *Home* screen select the *Settings* icon (錯誤! 找不到參照來源。) and press **E N T E R** to display the *Settings* screen.

The *Settings* screen (錯誤! 找不到參照來源。) includes the following tabs. Select a tab by pressing left or right on the outer ring of the 8-Way Navigation key:

- *Phone*
- *IM*
- *E-mail*
- *Device*
- *Sounds*
- *Time & Date*
- *Network*
- *System*

Setting Phone Preferences

Use the settings on the *Phone* tab to configure how your Ogo will respond to various calling conditions.

Table 3: Phone Settings

Option	Description
Call forwarding	<p>The following <i>Call forwarding</i> options may be configured to <i>Enable</i> or <i>Disable</i>:</p> <ul style="list-style-type: none">• <i>Forward all calls</i> – Ogo will re-route all incoming calls to another pre-determined number.• <i>Forward if busy</i> - Ogo will re-route incoming calls to another pre-determined number if you are engaged in an active phone call.• <i>Forward if not answered</i> – Ogo will re-route an incoming call to another pre-determined number if you do not answer the call.• <i>Forward if not reachable</i> – Ogo will re-route an incoming call to another pre-determined number if the network cannot locate your Ogo to deliver the call. <p>Activating the <i>Query</i> button in the four <i>Forward</i> configuration screens will tell you if the option is enabled or disabled.</p> <p><i>Cancel all</i> – activate this option to disable all of the <i>Forward</i> options that have been enabled.</p>
Voice mailbox number	<p>Use this option to change the phone number of the mailbox where you receive voice messages (this number is assigned by your cellular service carrier).</p>
Own number sending	<p><i>Own number sending</i> means that the person you are calling can read your phone number on caller ID-equipped telephones:</p> <ul style="list-style-type: none">• Set to <i>On</i> – your number can be read by the person you are calling.• Set to <i>Off</i> – your number cannot be read by the person you are calling.• Set by <i>Network</i> – leaves this option setting to the discretion of your cellular service carrier (usually <i>On</i>).
Call waiting	<p>When enabled, Ogo will notify you of an incoming while you have a call in progress rather than delivering a busy signal to the new caller.</p>
Incoming call alert	<ul style="list-style-type: none">• The type of ring tone may be changed to any of the available options.• The ring tone's volume may be adjusted.• The vibrating option may be turned on or off.

Setting IM Preferences

Use settings on the *IM* tab to manage your IM accounts.

Table 4: IM Settings

Option	Description
MSN Sign In	The <i>IM</i> tab includes <i>Sign In</i> options for each of the providers you chose: <ul style="list-style-type: none">• <i>MSN Sign In</i>
Add IM account	To add an IM account select <i>Add IM account</i> and then press ENTER .
Remove IM account	To remove an IM account select <i>Remove IM account</i> and then press ENTER .

Setting E-mail Preferences

Use settings on the *E-mail* tab to manage your e-mail accounts and the stored e-mail messages you have sent.

Table 5: E-mail Settings

Option	Description
Mailbox name	When the mailbox name is selected (i.e., <i>MSN Hotmail</i>), press ENTER to display the <i>Mailbox Settings</i> screen. See Table 6 on page 42 for more information.
Add account	To add an e-mail account, select <i>Add account</i> , and press ENTER .
Remove account	To remove an e-mail account, select <i>Remove account</i> , and press ENTER .
Brand autosignature	When this box is checked, the following message is inserted at the end of your e-mail messages: <i>These words brought to you by Ogo. Find out more at www.ogo.com.</i>
Sent items to keep	To set the number of sent items you want to keep in the <i>Outbox</i> tab, select <i>Sent items to keep</i> , and press ENTER ; a pop-up window appears on screen. Select the number of items (from 10–50) and press ENTER again.

Table 6: Mailbox Settings

Option	Description
Mailbox name	Enter the name of your mailbox. This is the custom name of the account and is displayed as a tab in the <i>Mailbox</i> and in the <i>E-mail</i> tab of <i>My Status</i> .
E-mail address	Enter your e-mail address for the selected Mailbox.
User name	Enter your user name for the e-mail account.
Password	Enter your password for the e-mail account.
Default account	If you have only one e-mail account set up, this check box is selected by default. If you have more than one account, press ENTER to select the checkbox next to the e-mail account you want to set as the default. When you compose a message, it is sent from the account selected as default.
Display name	Enter the name that appears in the <i>From</i> field of an e-mail account that you send from this account.
Server name	If you have a custom e-mail account set up, this field displays the server name for that account. It cannot be directly edited, but you can click <i>Configure server</i> to edit it.
Configure server	Open to configure your e-mail port settings. This option is unavailable if you have configured only an MSN e-mail account.
Check interval	Change intervals for Ogo to check for new e-mail messages. Choose from <i>OFF</i> , <i>10m</i> , <i>30m</i> , <i>1h</i> , <i>2h</i> , <i>4h</i> , <i>12h</i> .

Setting Device Preferences

Use the settings on the *Device* tab to control the look of your Ogo screen and how it displays alerts when messages are received, sent, or deleted.

Table 7: Device Settings

Option	Description
Contrast	To set the contrast level for your Ogo screen, select <i>Contrast</i> . Then use the inner ring of the 8-Way Navigation key and press left or right to decrease or increase the level. The contrast level of Ogo's screen changes immediately as you move from one level to the next. Choose from six levels of contrast.
Screen Backlight	Choose a backlight duration time: <i>15 seconds</i> , <i>30 seconds</i> , <i>45 seconds</i> , <i>1 minute</i> , or <i>2 minutes</i> . The longer the backlight time, the more battery power is consumed.
Message font size	To choose a font size for messages, select <i>Message font size</i> and press ENTER , then from the pop-up window that appears on screen, choose either <i>Normal</i> or <i>Large</i> , and press ENTER .

Table 7: Device Settings (continued)

Option	Description
Change PIN code	Changes your PIN code. Be sure to keep a record of your new code in a safe place.
Banner settings	Controls whether banners appear when you receive new messages or IM contacts come online. See 錯誤! 找不到參照來源。 on page 錯誤! 尚未定義書籤。 for more information.
Language	Choose your preferred language for your Ogo: <i>English</i> or <i>Türkçe</i> .
Reset Device	<p>Removes all personal and account information from your Ogo permanently (for example, if you are preparing to give the device to someone else). This option deletes all IM and e-mail accounts and all contact information, as well as restores all default settings (for sounds, alerts, etc.).</p> <p>To reset the device, from the pop-up window that appears on screen, select OK and press ENTER.</p> <p>Press OK at the confirmation pop-up window.</p> <p>NOTE: THE DEVICE WILL RESTART AFTER RESETTING.</p>
Confirm msg. delete	To have your Ogo ask you for confirmation when you delete a message, select <i>Confirm msg. delete</i> , then press ENTER to select or clear the checkbox.
Prompt to add contacts	<p>When you send an e-mail or SMS/text message to an address that is not already in your contacts list, you can have Ogo ask whether you want to add that address to your contacts list after sending the message.</p> <p>To activate or deactivate this setting, select <i>Prompt to add contacts</i>, then press ENTER to select or clear the checkbox.</p>
Restore canceled pop-ups	To restore canceled pop-up windows select <i>Restore canceled pop-up windows</i> and press ENTER . This option is unavailable.

Table 7: Device Settings (continued)

Option	Setting	Description
Bluetooth settings	<i>Local device name</i>	This is the designated Bluetooth name of the Ogo device. Other Bluetooth devices searching for this Ogo will recognize it by this designation.
	<i>Change name</i>	This is the setting used to change the <i>Local device name</i> . Select <i>Open</i> and press E N T E R ; a pop-up window appears in which the designated name may be changed.
	<i>My devices</i>	Select <i>Open</i> and press E N T E R ; a pop-up window appears exhibiting the names of all of the Bluetooth devices that are paired with the Ogo device, and offers the option of un-pairing them.
	<i>Search for devices</i>	This option scans the airwaves for available Bluetooth devices to connect to. Select <i>Scan</i> and press E N T E R ; a pop-up window appears showing that a search is in progress.
	<i>Temporary visibility</i>	To protect itself from undesired contacts, the Ogo is normally "invisible" to random searches. When you wish to be found, the Ogo must be made "visible" to the airwaves. Select <i>Enable</i> and press E N T E R ; a pop-up window appears informing you that your Ogo will be temporarily visible for 1 minute. After that one minute, it automatically goes back to being invisible.

Setting Sounds

Use the settings on the *Sounds* tab to control the different kinds of sounds your Ogo makes.

Table 8: Sound Settings

Option	Description
Volume	To set the volume level for all of Ogo's sounds, select <i>Volume</i> , then use the inner ring of the 8-Way Navigation key to increase (right) or decrease the volume (left). The volume level of Ogo's sounds changes immediately as you move from one level to the next. Choose from nine volume levels.
Mute	To make Ogo operate silently select <i>Mute</i> , then press ENTER to select the checkbox. <i>Note: When you select Mute, all of Ogo's sounds are muted, including key tones.</i>
Vibration	Alerts you when contacts come online or when you receive new messages by vibration. To turn vibration on or off, select <i>Vibration</i> , then press ENTER to select or clear the checkbox. Only occurs when your Ogo is powered on and closed. <i>Note: Vibration occurs only for events which are selected in your Banner Alert settings. Please refer to 錯誤! 找不到參照來源。 on page 錯誤! 尚未定義書籤。</i>
Key tones	To turn on or off the sounds Ogo makes whenever you press a key, select <i>Key tones</i> , and then press ENTER to select or clear the checkbox.
Alerticon sounds	To turn on or off the sounds associated with alerticons, select <i>Alerticon sounds</i> , and then press ENTER to select or clear the checkbox.
Message events	To turn on or off the sounds Ogo makes when messages are received, select <i>Message events</i> , and then press ENTER to select or clear the checkbox.
Presence events	To turn on or off the sounds Ogo makes when IM contacts sign on, select <i>Presence events</i> , then press ENTER to select or clear the checkbox.
System sounds	To turn on or off the sounds Ogo makes when you power on/off, or when you open or close the device, select <i>System sounds</i> , then press ENTER to select or clear the checkbox.

Using Volume/Vibration Shortcuts

You can set the volume, choose mute/un-mute, or turn on/off vibration for your Ogo from the Volume/Vibration pop-up window. You can activate the Volume/Vibration pop-up window (錯誤! 找不到參照來源。) from any screen by pressing **ALT** and any portion of the 8-Way Navigation key at the same time.

Note: After the Volume pop-up window appears, it remains visible for two seconds.

With the Volume/Vibration pop-up window displayed:

- Use the inner ring of the 8-Way Navigation key, and press up or down to increase or decrease the volume (with audio tone).
- To mute your Ogo, press down on the outer ring of the 8-Way Navigation key. To un-mute, press up.
- To turn vibration on or off, press left or right on the inner or outer ring of the 8-Way Navigation key.

Setting the Time and Date

When your Ogo is powered on, it automatically synchronizes with the current time from your carrier's network. If for some reason the network is not available, you can set the time and date manually using the settings on the *Time & Date* tab.

Note: If your network does not provide the time and date, the time and date settings are lost if you remove the battery.

Table 9: Time and date settings

Option	Description
Device Time	Displays the time as it is currently set on your Ogo.
Set time	<p>You can access the time manually or copy the network time. In most cases you want to copy the network time.</p> <p>To set the time by copying the network time:</p> <ol style="list-style-type: none">1. Select <i>Set time</i> and press ENTER.2. Select <i>Copy network time</i> and press ENTER.3. Select <i>Done</i> and press ENTER. <p>To set the time manually:</p> <ol style="list-style-type: none">1. Select <i>Set time</i> and press ENTER.2. Select <i>Time</i>.3. Type numbers for the hour and minute and press ENTER. <p><i>Note: Only numbers can be typed in the hour and minute fields, so using the ALT key to type numbers is not necessary.</i></p>

Table 9: Time and date settings (continued)

Option	Description
Set date	<p>You can set the date manually or copy the network date. In most cases you want to copy the network date. To set the date by copying the network date:</p> <ol style="list-style-type: none">1. Select <i>Set date</i> and press ENTER.2. Select <i>Copy network date</i> and press ENTER.3. Select <i>Done</i> and press ENTER.

	To set the date manually: 1. Select <i>Set date</i> and press ENTER . 2. Type numbers in the <i>Date</i> fields (for example, 28/04/2005). 3. Select <i>Done</i> and press ENTER .
Time format	Select the format you want to use for displaying the time.
Date format	Select the format you want to use for displaying the date.
Network time	Shows the current time and date on the network.

Setting Network Preferences

Network settings are primarily used by your carrier to help troubleshoot issues with your Ogo.

Table 10: Network Settings

Option	Description
Active network	Shows the name of the active network.
Network Selection	Select <i>Network Selection</i> and then press ENTER ; from the pop-up window that appears on screen, select <i>Auto</i> or <i>Manual</i> and then press ENTER .
Scan for networks	To scan for available networks, select <i>Scan for networks</i> and press ENTER . This option is disabled.
SMS settings	Select <i>Edit</i> and then press ENTER to enter the Username and Password for sending SMS/text messages; this information must be entered in order to send or receive SMS/text.
Network services	Select <i>Open</i> to open the <i>Network services</i> screen, where you can send a network command. The USSD (Unstructured Supplementary Service Data) mechanism allows you to execute commands such as pre-paid card activation, balance check, balance reload, or cost information manipulation.
GPRS status	Indicates the status of your GPRS connection (<i>Connected</i> , <i>Not connected</i> , <i>Connection denied</i> , <i>Paused</i> , or <i>Not available</i>). Customer Care uses this indicator of GPRS connection to troubleshoot your device.

Setting System Preferences

System settings show capacities and identifying characteristics for your Ogo.

Table 11: System Settings

Option	Description
Contact Records	Shows percentage of storage available for contact records.
Software	Shows the version number of the software on your Ogo (for example, 1.0.70.2750).
IMSI	Not used
IMEI	Not used
Battery	Shows battery level as a percentage (for example, 56% of full charge).
Check for updates	Enables you to manually check whether software updates are available for your Ogo. <ul style="list-style-type: none">• <i>Check</i> indicates that new software updates are available and ready to install.• <i>Checking...</i> indicates that your Ogo is checking for updates.• <i>Downloading upgrade</i> is displayed while software upgrades are being downloaded to your Ogo.• <i>Software update is ready</i> indicates that software download has been completed. The upgrade takes effect the next time you power on your Ogo.





Part # IXP00228 REV1

© 2007 IXI Mobile, Inc. All rights reserved.

FCC Regulations:

●This mobile phone complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

●This mobile phone has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

► RF Exposure Information (SAR)

This model phone meets the government's requirements for exposure to radio waves.

This phone is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg. *Tests for SAR are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

The highest SAR value for the model phone as reported to the FCC when tested for use at the ear is 0.905 W/kg and when worn on the body, as described in this user guide, is 1.33 W/kg (Body-worn measurements differ among phone models, depending upon available enhancements and FCC requirements.)

While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on FCC ID: SOW-OGOCT25C.

For body worn operation, this phone has been tested and meets the FCC RF exposure guidelines for use with an accessory that contains no metal and the handset a minimum of 1.5 cm from the body. Use of other enhancements may not ensure compliance with FCC RF exposure guidelines. If you do not use a body-worn accessory and are not holding the phone at the ear, position the handset a minimum of 1.5 cm from your body when the phone is switched on.